Multi-Function Copier User's Manual



- 1. Getting Started
- 2. Installing Your Machine
- 3. Operation
- 4. Customizing the Product's Configurations
- 5. Configuring the Printer's Features
- 6. Scanning From Your Computer
- 7. Maintaining the Product
- 8. Replacing the Consumables
- 9. Troubleshooting
- 10. Specification

Katusha

Safety During Operation

In this manual, the following important symbols are used:

⚠ WARNING:

Indicates potentially hazardous situations, which if instructions are not followed, could result in death or serious injury.

A CAUTION:

Indicates a potentially hazardous situation which, if instructions are not followed, may result in minor or moderate injury or damage to property.

Important:

Indicates operational requirements and restrictions. Please read and follow these instructions to ensure a proper operation and to avoid damage to the machine.

Note:

Indicates further explanation or clarification. Reading this is highly recommended.

⚠ WARNING:

To avoid hazardous electric shock or fire, do not remove any covers or screws other than those specified in this manual.

A CAUTION:

- ✓ To reduce the risk of fire, use only no.26AWG or larger telecommunication line cord.
- ✓ Disconnect the power plug by pulling the plug, not the cable.
- ✓ Do not touch the metal fingers of the ADF pad module. The edges are sharp and touching them may result in injury.

Notice

Important

- Do not make copies of any item for which copying is prohibited by law.
- Copying the following items are normally prohibited by the local law:
- Bank bills, revenue stamps, bonds, stock certificates, bank drafts, checks, passports, driver's licenses.
- This machine is equipped with a function that prevents making counterfeit bank bills. Due to this, images similar to bank bills may not be copied properly.

Copyrights and Trademarks

Ethernet is a registered trademark of Xerox Corporation.

Microsoft, Windows 7, Windows 8, Windows 10, and Windows 11 are registered trademarks of Microsoft Corporation in the United States and/or other countries.

Other product names used herein are for identification purposes only and may be trademarks of their respective companies. We disclaim any and all rights to those marks.

Warranty

The information contained in this document(s) is subject to change without notice.

The manufacturer makes no warranty of any kind with regard to this material, including, but not limited to, the implied warranties of fitness for a particular purpose.

The manufacturer shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this material.

When this printer has no operation for an extended period of time



Note: If the printer is idle for a period of time (for example, overnight), turn off the printer with the power switch. If the printer is idle for a longer period of time (such as holidays), unplug the power cord from the electrical outlet to prevent danger.

Take care to remove the paper from the paper tray and store it in the wrapper to prevent the paper from getting wet.

Disposal of Waste Equipment by Users in Private Union



This symbol on the product or on its packaging indicates that the product can not be disposed of with your other household waste. Instead it should be sent to appropriate facilities for recovery and recycling in an effort to protect human health and the environment. Fore more information about where you can drop off your waste equipment for recycling, please contact your local city office, your household waste disposal service or the shop where you purchased the product.

Federal Communications Commission (FCC) compliance information statement Part 15

The product has been tested and found to comply with the limits for a Class A digital device pursuant to Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference and (2) this device must accept any interference received including interference that may cause undesired operation.

The FCC Class A limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual may cause harmful interference in which case the user will be required to correct the interference at his own expense.



European Union Regulatory Notice

Products bearing the CE marking comply with the following EU Directives:

- Low Voltage Directive 2014/35/EC
- EMC Directive 2014/30/EC
- Restriction of the use of certain hazardous substances (RoHS) Directive 2011/65/EU
- RED (Radio Equipment Directive) (2014/53/EC)

CE compliance of this product is valid if powered with the correct CE-marked AC adapter provide by Katusha.

This product satisfies the Class A limits of EN55032, EN55035, and safety requirements of EN62368-1.

CE Warning

This is a class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

Safety Information

When using this equipment, the following safety precautions should always be followed.

Safety During Operation

In this manual, the following important symbols are used:



WARNING:

Indicates potentially hazardous situations, which if instructions are not followed, could result in death or serious injury.



CAUTION:

Indicates a potentially hazardous situation which, if instructions are not followed, may result in minor or moderate injury or damage to property.

Important:

Indicates operational requirements and restrictions. Please read and follow these instructions to ensure a proper operation and to avoid damage to the machine.

Note:

Indicates further explanation or clarification. Reading this is highly recommended.

The following symbols indicate that the related section includes safety warnings. Specific points of attention are indicated inside the symbol.

\triangle	[General warning]
	[Warning of high temperature]
A	[Warning of danger of electrical shock]

The following symbols indicate that the related section includes information on prohibited actions. Specifics of the prohibited action are indicated inside the symbol.

\Diamond	[Warning of prohibited action]
	[Disassembly prohibited]

The following symbols indicate that the related section includes information on actions which must be performed. Specifics of the required action are indicated inside the symbol.

0	[Alert of required action]
0 5	[Remove the power plug from the outlet]

Installation and the Operating Environment



Warning

Do not install the equipment near direct sun light, heating or air conditioning units. Direct sunlight or high temperature may damage the machine.	\Diamond
Do not install the equipment in a humid or dusty place. If dust or dust adheres to the power plug, clean the plug to avoid fire or electric shock.	\Diamond
Keep the vent hole on the back of the printer at least 10 cm away from the wall to avoid overheating and fire.	Ŵ
Do not place or store the device:	\Diamond
Place the equipment securely on an even, flat surface. Tilted or uneven surfaces may cause mechanical or paper-feeding problems.	\Diamond
Do not locate the device on rackety or aslope tables. Do not locate the device on unstable surface. The device may fall down and this may result in injury.	\Diamond
Place the device close enough to the computer so that the interface cable can easily reach between the device and the computer.	
Do not place a coffee cup, vase, or other liquid-filled container on the machine. Spillage can damage the machine's electrical parts and insulation.	\Diamond
Make good use of the recycled paper while printing.	

<u>^</u>

Caution

Place the device in an independent, well-ventilated area.	Ŵ
Place the device in a place with good environmental conditions. Operating the machine beyond the recommended temperature and humidity may cause an electrical fire.	A
Do not place heavy objects on the unit. It may cause unbalance and the device may fall down. This may result in injury.	\Diamond
Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions or equivalent.	
This product requires connection to protective earth by means of power cord(s) connected to socket-outlet(s) with protective earthing connection.	

Do not place the device in any position that may obstruct the output of the unit, as it may cause paper jams.




Safety Information During Operation



Warning

To prevent fires, do not use flammable sprays near the machine.	\bigcirc
Never attempt to open any fixed cover. Otherwise there is danger of electric shock, fire and laser beam and may cause blindness.	
Never disassemble, modify, or attempt to repair the device or device option by yourself, except as specifically explained in the device's documentation. This could cause fire, electrical shock, or injury.	0
Do not attempt to alter the machine or its parts. Avoid contact with the internal high voltage part or the laser light beam, it may cause electric shock or blindness.	
If this product becomes inordinately hot or emits smoke, or unusual odor or noise, immediately turn OFF the power switch, unplug the power cord from the power outlet, and then call your authorized service representative. If you keep on using it as is, a fire or electrical shock could result.	
Take care not to drop paper clips, staples, or any other metal objects into the machine.	<u>∧</u>
The inside of this product has areas subject to high temperature, which may cause burns. When checking the inside of the unit for malfunctions such as paper miss-feed, do not touch the locations (around the fusing unit, etc.) which are indicated by a "Caution! Hot Surface" caution label.	
Under normal conditions the small quantities of ozone gas produced by the machine are harmless. However, if the machine is used for an extended period or within a small room, you should make sure that the area is adequately ventilated. Also ventilate the room if you notice the machine smells after a period of frequent or extended use.	À
Do not attempt to remove the covers and panels which have been fixed to the product. Some products have a high-voltage part or a LSU beam source inside that could cause an electrical shock or blindness.	\triangle
Do not modify this product, as a fire, electrical shock, or breakdown could result. If the product employs a LSU print head, the LSU beam source could cause blindness.	<u> </u>
If this product has been dropped or its cover damaged, immediately turn OFF the power switch, unplug the power cord from the power outlet, and then call your authorized service representative. If you keep on using it as is, a fire or electrical shock could result.	0

Take appropriate emergency measures when the following conditions occur





- When the toner gets on your skin, wash it off with soap and rinse it off.
- When you are in the toner inlet, leave the dust location immediately and rinse with plenty of water.

 When the toner is in the abdomen, spit it out and consult a doctor. 	
Do not use the device with wet hands.	

Unplug the device and the USB cable, and refer servicing to qualified service personnel under the following conditions:



- Liquid has entered the device.
- Object has entered the device.
- The device has been dropped, or the case has been damaged.
- The device does not operate normally (i.e. appearance of smoke, strange smell, odd noise, etc.), or exhibits a distinct change in performance.



Caution

When there is paper jam inside the machine, be sure to remove it thoroughly. The remaining paper in the machine may cause a fire. When the paper is attached to an invisible or difficult-to-see area, do not remove it by force to avoid injury and contact the service personnel or dealer for help.

The temperature inside of the machine may be very hot. When the paper jam is released, note any warning labels and do not touch it to avoid burns. It is recommended to clear the jam after the machine has cooled down.

When clearing paper jams, refer to the instructions in this manual.



When using a large number of copies of the machine for a long time, keep the indoor air flow. Otherwise you may feel a headache.



Unplug the device's power cord and USB cable before cleaning.



About the Consumables



Caution

Do not unpack the consumables and store the machine's consumables in any of these locations:



- Outdoors
- Near excessive dirt or dust, water, or heat sources
- In locations subject to shocks, vibrations, high temperature or humidity, direct sunlight, strong light sources, or rapid changes in temperature or humidity

Do not throw the toner cartridge into the fire. After the toner remaining in the crucible comes into contact with the fire, the powder may explode and cause personal injury.





Caution

Do not discard the discarded toner cartridges. Please put the used waste toner cartridges in the supplied plastic bags and return them to the dealer or service personnel. (For the customer service locations around the company, please refer to our website.). The latter will recycle the used toner cartridge in accordance with relevant regulations.



The used consumables must be disposed of properly and in accordance with local environmental regulations, or disposed of by the company's designated dealer.



Safety Information When using power cord and the USB cable



Warning

Plug the power cord securely into the outlet. Do not touch the pins of the power cord plug with any metal objects as they may touch dangerous voltage points or short circuit. This can cause fire, electric shock or injury. Failure to do so may result in a fire or electric shock.	À
Before disconnecting the plug, turn the machine off. Make sure your hands are dry. Hold the plug itself, not its cord, when disconnecting it from the receptacle.	1
Do not share the power with other high-powered devices, as this may result in fire or electric shock.	A
Do not use extension cords as this may result in fire or electric shock.	
Always use the correct AC power source. For future transportation and handling, please keep all packaging materials for this product.	\bigcirc
Use only the USB cable that came with your device and avoid abrasions, cuts, fraying, crimping, and kinking. Using any other USB cable could cause fire, electrical shock, or injury.	\Diamond
 Do not store the cables in the following locations: Outdoors Near excessive dirt or dust, water, or heat sources In locations subject to shocks, vibrations, high temperature or humidity, direct sunlight, strong light sources, or rapid changes in temperature or humidity 	\Diamond
Keep the supplied USB cable, etc., in a location that is out of reach of children to avoid the risk of injury.	\bigcirc
Please put the packaging materials such as the supplied plastic bags in a place that children cannot obtain or discard them to avoid the risk of suffocation.	\bigcirc



If you are not using the device for a long time, remove the USB cable from the connector.	8 5
This product has a power-saving mode and a standby mode. The zero-energy state can be achieved only when the product is connected without any external input power.	
At least every year, please disconnect the power cord from the wall outlet to check whether the power cord is exposed, damaged, cracked, dent, hot, pin deformation or any burnt marks. If these conditions exist, please do not use the power cord again and contact the authorized service personnel or dealer.	0
Make sure the power cord is plugged into a grounded electrical outlet, otherwise it may cause a fire or electric shock.	
Be sure to fully plug the power cord into a wall outlet. Failure to completely insert may cause unstable connections and heat build-up, creating an unsafe condition.	
When disconnecting the power cord from the wall outlet, be sure to pull the plug, not the power cord, as this may damage the power cord and cause a fire or electric shock.	
To repair the machine, be sure to disconnect the power cord from the wall outlet.	_
Make sure the power cord is firmly secure and will not trip over.	

SAFETY INSTRUCTION

This printer is a page printer which is operated by means of a LSU (Laser Scanning Unit). There is no possibility of danger from the LSU, provided the printer is operated according to the instructions in this manual. Since radiation emitted by the laser beam is completely confined within protective housings and external covers, the laser beams cannot escape from the machine during any phase of user operation.

Table of Contents

1.	Getting Started 1
	Placing Your Document with Ease
	Removing the Box and Packing Material4
	Removing the Protective Tapes6
	Releasing the Lock Switch9
	External View 10 The Front View 10 The Rear View 11
	Package Contents
2.	Installing Your Machine
	Precautions14
	Removing the Locking Latch on the Machine15
	Installing the Toner Cartridge16
	Installing the Developing Unit18
	Installing the Drum Unit22
	Installing the Paper Stopper25
	Loading The Main Input Tray26
	Paper size and weights used for Tray 1~4
	Loading the Manual Tray30
	Paper size and weights used for Manual Tray
	Unlocking the Scan Unit
	Connecting to a Wired Network
	Connecting to Power
	Turning On The Machine37
	Turning Off the Machine37
	Set the Product's Date and Time
	Configure the Product's IP Address39
	Specifying the Product's Mail Server40
	Installing the Scanner/Printer Drivers42
	For USB Interface Users
3 .	Operation47
	Loading Paper47
	Notice on Using the ADF
	Placing Document(s) in the ADF48
	Placing Document(s) on the Glass
	Intelligent Copy (Drop N Take)50
	Using Auto Document Feeder50

	Flatbed Copy
	Using the [Bind] Feature
	ID Card Copy 57
	Scan 61
	Print Saved Job 68
	E-Mail
	Fax (Optional) 77
	Normal Copy 79
	Using Book Copy85
	Imposing watermark
	Network Scanning 88
•	Customizing the Product's Configurations 91
	Customizing the Product's Configurations by the Touch Screen 92
	Machine Information93
	Faults
	Supplies94 Billing Information95
	Tools96
	Customizing the Product's Configurations by the Product's Web
	Page
	Summary of the Web Pages 104
	How to set user authentication
	(1) Enable [User Authentication]111
	(2) Login with admin112
	(3) Change Admin's Password or Add the pin no. of your ID card112
	(4) Create a new user
	(5) Login with a new user on the touch panel115 Using the Administrative Mode116
•	Configuring the Printer's Features 118
	Displaying the Printer Driver Properties Dialog Box 118
	Configuring Printer Driver Settings 119
	The Basic Tab119
	The Paper Tab122
	The Layout Tab
	The Watermark Tab
	The Duplex Tab
	The More Tab134
•	Scanning From Your Computer
	System Requirements
	Operating Steps
	A Glance of the User Interface137
	Using The Image Tab138
	Using The Paper Tab141
	Using The Color Propert Teb
	Using The Color Dropout Tab143 Using The Information Tab143
	eonig inciniculation lab

7 .	Maintaining the Product	144
	Removing the Abnormal Line On an Image	. 144
	Cleaning the Document Glass	. 145
	Cleaning the ADF	
	Cleaning the EP Charger	. 147
	Cleaning the Paper Tray Rollers	
	Cleaning the Manual Tray Roller	
	Installation Step	
	Cleaning the Toner Cartridge	. 153
	Remove the Toner Cartridge	
	Install the Toner Cartridge Cleaning the Paper Path	
	Cleaning the Paper Path	. 155
8.	Replacing the Consumables	157
	Replacing the Snap-in Pad Module	. 158
	Replacing the ADF Roller	. 160
	Replacing the Waste Toner Can	. 162
	Removing the Waste Toner Can	
	Reinstalling the Waste Toner Can	
	Replacing Toner Cartridge	
	Removing the Toner Cartridge Installing the Toner Cartridge	
	Replacing the Paper Tray Rollers	
	The removing steps The reinstallation steps	
	Replacing the manual tray rollers and pad	
	The removing procedure	
	The reinstallation procedure	
	Replacing the Drum Unit	
	The Removing Procedure Reassembling Steps:	
	Replacing the Developing Unit	
	The Removing Steps:	
	Replacing the Fuser	. 181
	The Removing Steps	
	Reinstallation Steps	. 183
9.	Troubleshooting	187
	Monitoring Your Printer Using Printer Status Monitor	. 187
	Accessing Printer Status Monitor	
	Getting Printer Status Details	
	Setting Monitoring Preferences Clearing A Warning or Error Message	
	Technical Support	
	• •	
10	Specifications	230

1. Getting Started

Introduction - the World's Renown Intelligent Copier

Congratulations on your purchase of the world's renowned intelligent copier. With the innovative intelligent copy function, users no longer need to specify the size of document, worry about whether the document has been loaded straight and correct, or if the document should be faced down or up, the Katusha intelligent copier is able to crop your paper size, select the text side, straighten your image, and even select proper paper tray automatically! The Katusha intelligent copier truly makes your copy job perfect and easy!

What is best, the Katusha intelligent copier integrates scan, copy, and print functions into one single machine to streamline your workflow. Through the 8" color and clear LCD touch screen and the easy-to-use control panel, your task can be completed within seconds and your document can be distributed and shared very quickly in an unprecedented way!

Features

Placing Your Document with Ease

With the auto crop and straighten function, users no longer need to carefully placing document to the edge of paper guides. Even the document has been placed at a slight angle in the feeder or on the document glass, the image can be first scanned, cropped and then straightened automatically.





Easily placing your document to the feeder or on the flatbed glass

Automatically Detect the Text Side

With an advanced processor developed by Katusha, the front side and rear side of document can be scanned simultaneously and the text side will be automatically detected and copied and deleting the blank side.

Automatically Selecting Paper Tray

The preset tray is auto which means the product will automatically select the tray which contains the paper size most fit to the original document.

Intelligent Copy (Drop N Take)

With the "Intelligent Copy" feature, the Katusha intelligent copier can make copy automatically after detecting your document passing through the document feeder. Plus with the preview feature, user is able to choose one-side or two-side copy and verify if the image is correct.

Duplex (2-Sided) Capability

Use the automatic duplex printing feature to help save paper and reduce costs.

Scan to Product or USB Flash

The product offers an unprecedented document storage technology, transmitting paper documents electronically to the product's memory or a removable USB flash drive.

Scan-to-e-mail, host, USB, FTP or SMB

The product offers an unprecedented document delivery technology, transmitting paper documents electronically over the internet to various destinations including e-mail addresses, the MFP's memory, an USB flash drive, ftp servers, or someone else's computer on the network. The new way to distribute documents is faster, more cost effective, and safer than any traditional methods such as mail, or courier.

Faxing (Optional):

With a built-in fax board and an additional telephone line, the product is able to transmit your scanned document to a fax machine just like regular fax machine.

Remote Device Management through Embedded Web Page

The product provides an embedded web page to let the system administrator remotely monitor the product by managing a telephone book, address book, checking the supplies status of toner cartridge, scan count, copy count, and creating user password and privileges to prevent unauthorized access.

Standard items and optional items for this product:

Standard Package Items	
Auto Document Feeder	✓
The 1 st Tray	✓
The 2 nd Tray	✓
Toner Cartridge	✓
Drum	✓
Developing Unit	✓
Power Cord	✓
CD-ROM	✓
Optional Items	
The 3 rd & 4 th Tray	
Fax Module	

Removing the Box and Packing Material

The MFP carton is illustrated is shown in the figure below, which is divided into four parts:

- 1. Printer main unit (Packed inside the carton)
- 2. Pallet (Under the carton)
- **3.** All Accessories (packed inside the carton)



Unpacking Steps


- 1. Place the MFP carton on a flat, and horizontal surface and do not place any objects in front of the printer.
- 2. Open the carton with a utility knife, and then take out all the accessories [including (1)Developing Unit, (2) Power Cord/CD, (3) Drum Unit, (4)Toner Cartridge, as shown in below:



3. Remove four box supports.



4. Remove all buckles on the sides of the printer box and pull the printer box upward.



Removing the Protective Tapes

As shown in below, remove the protective tapes, films, and desiccanton the machine.




Remove the tapes on the front and rear side of the machine



Remove the tapes, and desiccanton on the left and right side of the machine







Pull the Paper Tray and remove the tapes on the Tray




Remove the tapes, and protective film on the top of the machine



Open the Document Cover and then remove the tapes on the glass platen




Pull down the manual tray and remove the tape



Open Side Door and remove the tapes on the fuser

Releasing the Lock Switch

The product is designed with a lock switch to protect the machine from damage during transportation. As a result, before using the product, please move the lock switch to the [Unlocking position], otherwise the product may not work.



External View

The Front View



1. Automatic Document Feeder	5. Paper Collector
2. USB flash port	6. Document Cover
3. Tray 1	7. Power Switch
4. Tray 2	8. Manual Tray

The Rear View



1.	USB Port	To connect a computer via a USB cable.
2.	LAN Port	To connect network with a network cable.
3.	Power Receptacle	To connect power via a power cable.

Package Contents





Drum Unit



Toner Cartridge



Power Cable



Developing Unit



USB Cable



Software CD (Printer Driver and Manual)

Touch Screen

Used to display information and provide access to the product's functions.



2. Installing Your Machine

Precautions


- Do not install the equipment near heating or air conditioning units.
- Do not install the equipment in a humid or dusty place.
- It is recommended to use recycled paper when printing.
- Place the equipment in a separate area with good ventilation.
- The equipment is equipped with both the power-saving and standby modes.
- The equipment can not achieve zero energy consumption state until it is not connected to any external power supply.
- Do not dispose of the waste toner can. Put the used waste toner can into the bundled plastic bag, and then return it to a dealer or service representative (About our customer service locations everywhere, please refer to our web site at www.Katusha.com). The latter recycles or deals with the collected waste toner cans in accordance with the relevant regulations.
- Be sure to use the correct AC power supply.
- Retain the box and packing materials for shipping purposes.

Removing the Locking Latch on the Machine

1. Pull the handle down to open the Side Door as shown.



2. Remove the Latch and its instruction sheet by pressing the bolt with one hand and pulling the latch with the other hand as shown in below. The latch is designed to protect the inside of the printer during transportation.



Installing the Toner Cartridge



Important!

When you unpack the machine, a toner cartridge has been packed separately besides the machine. Please remove the package cushion and tapes on the toner cartridge before using it.

Follow these steps to install the Toner Cartridge:

1. Remove the package cushion and tapes on the toner cartridge. Tilt the toner cartridge up and down and then right and left 10 times to distribute the toner evenly inside the toner cartridge.





WARNING!

- Be careful not to inhale toner.
- To avoid print quality problems, DO NOT touch the toner rollers.
- If toner gets on your clothing or other fabric, wipe off the toner with a dry cloth. Wash the items in cold water and dry them in the shade.
- To prevent the toner cartridge from damage, do not expose it more than several minutes.
- 2. Open the front cover by pulling the handle as shown.



3. Hold the handle of the toner cartridge and insert it to its proper position as shown.



4. Close the Front Cover.



Installing the Developing Unit


Follow these steps to install the Developing Unit:




Caution!

To prevent damage to the Developing Unit, do not expose it to light for more than a few minutes.

1. Remove the tape ①, protective film ②, and the plugs ③ on both sides.



2. Remove the tape in the upper right corner (4), and then remove the instruction card (5) and sponge (6).





Important!


Do not remove the transparent plastic protective cover on the surface of the developing unit as shown in the figure to avoid abnormal images.



3. Pull the handle down to open the Side Door as shown.



4. Open the paper guide latch in a clockwise direction **1**, and then push it up **2** to fix the paper guide.




5. Open the handle of the developing unit and hold the handle with both hands, as shown in the figure below.




6. Hold the handle with both hands, placing the front end of the developing unit to the top of the rails on both sides. Check if the arrows (triangles) on both sides of the developing unit are aligned with the arrows on the machine as indicated.







7. Gently push the developing unit into the machine along the rails. Make sure the handles are closed and left flat on the surface of the developing unit as shown in below.



Make sure the red arrows (triangles) on both sides are completely exposed.



8. Pull down the latch of the paper guide counterclockwise to restore the latch of the paper guide to its original status.



9. Close the Side Door and then the Manual Tray as shown.



Installing the Drum Unit

Follow these steps to install the drum unit:

1. Remove the plastic bag, tape, and then press down the Release Arms to pull out the protective film.



2. Pull up the Release Arms on both ends.






Caution!


To prevent damage to the Drum Unit, do not expose it to light for more than a few minutes.

3. Pull down the handle to open the side door as illustrated.




4. Hold the handle of the Drum Unit. Make sure the red arrows on both sides of the drum unit are aligned with the red arrows on the machine as indicated.






5. Insert the Drum Unit horizontally into the slot along the top of the support frame on both sides, as shown in the figure.



If install correctly, the arrows (triangles) will be completely exposed as indicated.



6. Close the Side Door and then the Manual Tray as shown.



Installing the Paper Stopper

Lift the Paper Stopper to collect the paper.




Loading The Main Input Tray

To insert paper to the input trays (The following instructions use the main input tray as an example.),

1. Fan your paper first to ensure that the pages do not stick together.



2. Align the edges of the documents by tapping the bottom of the stack against the table top. Rotate the stack 90 degrees and repeat.



3. Pull out the main input tray.



4. Push the center of the [Width guide tab] as shown, and move the width guide to the correct position for the paper size being loaded.



5. Unlock the length guide, squeeze the bottom of the [Length guide tab] inward as shown, and slide the guide to the correct position for the paper size being loaded.



6. Load the paper stack **face up**. Note the print side **face up** for single-sided printing.



7. Insert the tray.



Paper size and weights used for Tray 1~4

Paper capacity	500 sheets (70 g/m² plain paper)
Paper size	A3 (ISO) (297 x 420 mm)
	A4 (ISO) (297 x 210 mm)
	A5 (ISO) (148 x 210 mm)
	B4 (JIS) (257 x 364 mm)
	B5 (JIS) (257 x 182 mm)
	Letter (215.9 x 279.4)
	Legal (215.9x 355.6 mm)
	Legal 13 (216 x 330 mm)
	Oficio (216 x 343 mm)
	Ledger (Double Letter) (279.4 x 558 mm)
Paper weight	60 ~ 105 g/m² (16 ~ 28 lb.)



Note:

- To ensure the best quality printing and copying, please use the paper or media which we have recommended.
- Make sure to fan your paper before loading it to the paper tray.
- If there is instruction about the printing side on the packaging of your paper, please follow the instruction to load your paper properly with the correct printing side to the paper tray.
- If the printing quality is not satisfactory or paper jams are easily to occur, turn over the paper stack so that the top page is now on bottom and then reload it to the paper tray.
- Pack and seal the remaining paper with the original packaging and store the paper in a dark and dry location away from the sunshine. Paper which collects much moisture is easy to cause jam during printing.

Loading the Manual Tray

When you need to print different size paper, you can use the manual tray.

1. Open the manual tray by grasping the handle and pull it down.




2. Pull out the manual tray extension to meet your paper size.



3. Fan your paper first to ensure that the pages do not stick together.



4. Align the edges of the documents by tapping the bottom of the stack against the table top. Rotate the stack 90 degrees and repeat.



5. Load the paper stack **face down** and slide the paper guides so that they slightly touch the paper stack.



Paper size and weights used for Manual Tray

Paper capacity	100 sheets (70 g/m² plain paper)
Paper size	A3 (ISO) (297x420 mm)
-	A4 (ISO) (297x210 mm)
	A5 (ISO) (148 x 210 mm)
	A6 (ISO) (106x148 mm)
	B4 (JIS) (257x364 mm)
	B5(JIS) (257x182 mm)
	B6 (JIS) (128x182 mm)
	Letter (215.9x279.4)
	Legal (215.9x355.6 mm)
	Legal 13 (216x330 mm)
	Oficio (216 x 343 mm)
	Ledger (Double Letter) (279.4x431.8 mm)
	Statement (140x216 mm)
	8K (267x390 mm)
	16K (195x267 mm)
	PostCard (100x148 mm)
	Min. Custom Size: 100 x 145 mm
	Max. Custom Size: 304.8 x 558 mm
Paper weight	60 ~ 210 g/m² (16 ~ 56 lb.)

- * Statement D (LEF) is not supported.
- * A6 \(\sum_{\text{(SEF)}}\), B6 \(\sum_{\text{(SEF)}}\), and PostCard \(\sum_{\text{(SEF)}}\) are available only for single-sided print in the manual tray.



Note:

- To ensure the best quality printing and copying, please use the paper or media which we have recommended.
- Make sure to fan your paper before loading it to the paper tray.
- If there are instructions about the printing side on the package of your paper, please follow the instructions to load your paper properly with the correct printing side to the paper tray.
- If the printing quality is not satisfactory or paper jams are easily to occur, turn over the paper stack so that the top page is now on bottom and then reload it to the paper tray.
- Pack and seal the remaining paper with the original packaging and store the paper in a dark and dry location away from the sunshine. Paper which collects much moisture is easy to cause jam during printing.

Detectable Paper Size for Manual Tray


Paper Size in Manual Tray	Detectable Size
A3	A3 SEF
A.4. CEE	ISO 216 : A4 SEF
A4_SEF	North America : LTR SEF
A4_LEF	ISO 216 : A4 LEF
A4_LLI	North America : LTR LEF
A5_SEF	ISO 216 : A5 SEF
B4 (JIS)	B4 SEF
B5_SEF/EXEC (JIS)	B5 SEF
B5_LEF (JIS)	B5 LEF
LTD CEE	ISO 216 : A4 SEF
LTR_SEF	North America : LTR SEF
LTR_LEF	ISO 216 : A4 LEF
LIN_LLI	North America : LTR LEF
LGL	LGL SEF
Ledger (DLT)	Ledger SEF
A6 SEF (ISO)	A6 SEF
B6 SEF (JIS)	B6 SEF
Statement(ST)SEF	ISO 216 : A5 SEF
Legal 13 SEF	LGL SEF
8K SEF	Ledger SEF
4/// 055	ISO 216 : A4 SEF
16K SEF	North America : LTR SEF
PT SEF	A6 SEF

^{*}SEF (Short Edge First)

^{*}LEF (Long Edge First)

Unlocking the Scan Unit

The scan unit is locked during transport to protect the scanning mechanism from being damaged. Be sure to unlock the scan unit by moving the lock switch to the 「Unlock」 position before using the machine.





Note:


To move the MFP to another location, make sure the scan unit is at the home position which is at the left side of the glass before locking the scan unit. If the scan unit is not at its home position, turn on the MFP to let the scan unit move to its home position. Turn off the MFP and then lock the scan unit.

Connecting to a Wired Network

1. Connect one end of your network cable to an available port of your Ethernet Hub.



2. Connect the other end to the LAN port at the back of the product as shown.



Connecting to Power

- 1. Connect one end of the power cable to the power jack of your product.
- **2.** Connect the other end to an appropriate power outlet.




Turning On The Machine

Press the Power button on the bottom of the Control Panel to turn on the machine.




Turning Off the Machine

 To turn off the machine, press the Power button for 3 seconds. The following dialog box will be displayed.



2. Tap [**Power Off**]. The following confirmation dialog box appears. Tap [**OK**] to turn off the power.





Important!

When the product is not in use, be sure to turn off the power to get a zero power consumption state.


Set the Product's Date and Time

To ensure the machine reflect the current time, please first set correct date and time after the product is turned on for the first time.

1. When the product is turned on for the first time, the following Date/Time screen will be displayed.



- 2. Tap the 「Year」 field, a numeric key pad will be displayed. Enter correct number of the year. Tap the 「Month」 and 「Date」 field respectively, and enter the correct date. (You can also adjust the value using the up/down arrows.)
- **3.** After the year and date has been set, tap the 「**Time**] button to prompt the following Time Setting.




- **4.** Tap the **\[| Hour \]** field, a numeric key pad will be displayed. Enter the correct hour; Tape the **\[| Minute \]** field to enter the correct minute. (You can also adjust the value using the up/down arrows.)
- **5.** After the correct date and time has been set, tap the **Back** button to return to the main operational screen.

Configure the Product's IP Address

If you connect the product to your computer via a network cable, you need to specify an IP address for the product. An IP address can be obtained automatically through the DHCP server, or you can specify a static IP address. Please follow the steps in below to configure the IP address of the product.

1. Tap [More Settings] on main screen and then choose [Show Machine Status]. This will prompt the [Machine Status] page.



2. Touch the \(\textbf{Tools} \) tab, and then the \(\textbf{Network Settings} \) > \(\textbf{TCP/IP Settings} \) option. The following TCP/IP screen will be displayed.



- **3.** Touch 「IP address」, 「Subnet Mask」, 「Gateway」, and 「DNS Server」 fields to specify each of values. If you wish to disable DHCP, be sure to enter the address information in the 「IP address」, 「Subnet Mask」, and 「Gateway」 respectively.
- **4.** After TCP/IP settings have been completed, touch \(^\) Back \(_\) to leave the screen.
- **5.** Touch the 「**Home**」 button on the Control Panel to show the main operation screen.




Note:

- If you are using a DHCP server to automatically choose the IP address of the product, it is recommended that you set the host name for the product or use the default host name. Otherwise, after the product is used for a period of time, the DHCP server does not guarantee to choose the same IP address. If you want to change the default host name of the product, tap [More Settings] on the upper-right corner of the main screen, and then tap [Show Machine Status]>[Tools]>[Network Settings]>[Host Name] to enter your new host name.
- If you have further problems about the network setting, please contact your network administrator.


Specifying the Product's Mail Server

To send the scanned image to a recipient via E-mail, you need first specify your mail server information on the product. Follow these steps to set your mail server:

1. Tap [More Settings] on main screen and then choose [Show Machine Status]. This will prompt the [Machine Status] page.



2. Touch the 「Tools」 tab, and then the 「Network Settings」 > 「SMTP」 option. The following SMTP screen will be displayed.



3. Tap anywhere respectively on the **Login Name/Password/Mail Server/ Port#** field to bring up the soft keyboard and then enter the relevant values.

E-mail Server Setting		
Mail Server	Enter the IP address of your SMTP server.	
SMTP Port #	Enter the port number of the SMTP server.	
	* 25	

Authentication	Enter the email authentication method.
Method	Choice: *None, SMTP
Encrypt	Choose the encryption method of your emails to the SMTP server.
	Choice: *None, STARTTLAS, SSL/TLS
Login Name	Enter the login name for SMTP authentication.
Password	Enter the password for SMTP authentication.

- 4. Tap [Back] to save the setting and leave the screen.
- **5.** Touch the 「**Home**」 button on the Control Panel to enter the main operation screen.

Note:

The login name is case-sensitive and is up to 32 digits or characters.

The password is case-sensitive and is up to 16 characters.

Please check the SMTP server and LDAP server information with your Network Administrator.

Installing the Scanner/Printer Drivers

System Requirement

Windows 7, Windows 8, Windows 10, Windows 11

For USB Interface Users

Please follow these steps to install the scanner, and printer drivers if this machine is connected to your computer via a USB cable.




Important!

DO NOT connect the USB cable before installing the scanner, and printer drivers.


- Insert the supplied CD into your CD-ROM drive. The installation menu will be displayed.
- 2. To install the scanner /printer drivers:

Click 「Install Scanner Driver and Printer Driver」 and follow the on-screen instructions to complete the installation of the program.


3. When the Setup Type dialog box appears, select [USB].



4. Select if you wish to install Printer Status Monitor program. Choose **[Yes]** (recommended) and then click **[Next]**. Printer Status Monitor keeps you update about printer status and offer alert when you need to replace the consumables.



- **5.** During installation, the USB Connection dialog box will be prompted to instruct you to turn on the MFP and then connect the MFP to your computer with a USB cable.
 - a. Connect one end of the USB cable to your computer.
 - b. Connect the other end to the USB port of your product.



- **6.** When the Found New Hardware screen appears, click **Next** and follow the on-screen instruction to complete the installation.
- 7. When the **Finish** dialog box appears, click **Finish** to complete.


If you have successfully installed the printer's driver, you will find a printer, 「Katusha AM76XX Printer」, has been added in the 「Printers and Faxes」 option from the Control Panel. (XXXX indicates the model number)

For Network Interface Users


Please follow these steps to install the scanner, and printer drivers if this machine is connected to your computer via a network cable.

- 1. Insert the supplied CD into your CD-ROM drive. The installation menu wil be displayed.
- 2. To install the scanner driver and printer driver:
 - Click 「Install Scanner Driver and Printer Driver」 and follow the on-screen instructions to complete the installation of the program.
- 3. When the **Setup Type** dialog box appears, check [**TCP/IP**] and click [**Next**] to continue.


If you need to connect the product to a wireless network, check **[USB]** and **[TCP/IP]** since the **Network Setup Tool** is included in the USB driver and only available when the product is connecting to your computer through the USB cable.



4. Select your desired printer language.




5. Select if you wish to install Printer Status Monitor program. Choose [Yes] (recommended) and then click [Next]. Printer Status Monitor keeps you update about printer status and offer alert when you need to replace the consumables.




6. When the following **Set IP** dialog box appears, choose one of the following options and click [**Add**] to add to the printer list. When the desired option setting is completed, click [**OK**]. (Follow the preceding section – Checking the Product's Default IP Address to obtain the product's default IP address.





Host Name	Enter the product's host name to be connected
	in the blank box of the Host Name option.
IP Address	Enter the product's IP address to be connected
	in the blank box of the IP Address option.
Automatic Search	Searches the product's printers automatically,
	and all the product's host names found in the
	network will be displayed in the box of the
	Automatic Search. Use your mouse to choose
	your desired host name to be connected.

7. Select if you wish to create a Capture Tool shortcut on your desktop. (Capture Tool is a TWAIN-compliant Scanning Application.) Click [Next] to continue.



8. When the Finish dialog box appears, choose 「Finish」 to complete.

If you have successfully installed the printer's driver, you will find a printer,

「Katusha AM76XX NetWork」, has been added in the 「Printers and Faxes」

option from the Control Panel. (XXXX indicates your model number)

Uninstalling the Scanner Driver and Printer Driver

- 1. From the 「Start」menu, select 「All Programs」, 「Katusha AM76XX MFP」, and then 「Uninstall Driver」.
 - Or from the 「Start」menu, select 「Control Panel」, 「Add or Remove Programs」,「Katusha AM76XX MFP」, and then 「Remove」.
- 2. Follow the instructions on the screen to complete removing the scanner driver and the printer driver.

3. Operation

Loading Paper

The product can scan and send document(s) either in the ADF (Automatic Document Feeder) or on the glass. If you need to send multiple pages, please load your papers in the ADF. The ADF can hold up to 100 pages at one time. If you need to send pages from books, newspaper clippings, or paper with wrinkles or curls, please place your paper on the glass.

Notice on Using the ADF

Before using the ADF, please make sure that your paper meets the following specifications:

- Document(s) can range in size from 100 x 148 mm (3.94 x 5.83 in.) to 297 x 432 mm (11.7 x 17 in.).
- Document(s) should be square or rectangular and in good condition (not fragile or worn).
- Document(s) should be free of curl, wrinkle, tears, wet ink, or punch holes.
- Document(s) should be free of staples, paper clips, paper sticky notes.
- Keep the glass clean without document placed on it.




Note

To transmit irregular types of document(s), place the document(s) on the glass or make a copy first and then transmit the copy instead.

Notice on Using the Flatbed Glass

The maximum scan or copy area of the flatbed platform is A3 size. If the document is placed near the edge of the glass platen, as shown in the illustrated red rectangle, the content of the document that exceeds the scan range (as illustrated blue rectangle) cannot be scanned or copied.



Placing Document(s) in the ADF

1. Make sure your document is free of staples, paper clips and is not torn out.

2. If you have multiple pages, fan your document(s) to avoid occasional paper jam.



3. Align the edge of your paper against the Paper Guides and make sure the First Page feeds in first.





Note:

It is all right if the document is loaded to the feeder with a slight angle as shown in below. The product is designed with the auto crop and de-skew function, therefore, the image can be automatically cropped and straightened.



Placing Document(s) on the Glass

- 1. Open the document(s) cover to reveal the glass.
- 2. Place your document easily with the text **FACE DOWN** on the glass. The product is designed with the auto crop and deskew function, your scanned image will be automatically straightened though your document is placed with a slight angle.



3. Close the document cover.

Intelligent Copy (Drop N Take)

Using Auto Document Feeder

— Copy Single-Page Document

Single-Sided Document

1. Tap the **Drop N Take** button on the main screen, and the following **Copy** screen will be displayed.



2. Load document into the feeder. No need to worry about facing down or facing up since the Intelligent Copy System will automatically make a correct and perfect copy.



Note:

The product is built-in with the state-of-the-art image processor to provide an optimal default settings and image quality for common copy job. Change the default copy settings only when you need to perform an unusual copy task.


3. The product will automatically make one copy of your document and then the following screen will be prompted enquiring if any adjustment such as Density, Auto Fit, or Scaling needs to be made.




- a. If no adjustment is required, press $\lceil < \rfloor$ (Back) to return to the main Copy screen.
- b. If density, or scaling needs to be adjusted, select your desired value, enter your copy count and press [**Copy**] to complete.

Double-Sided Document

1. Tap the **Drop N Take** button on the main screen, and the following **Copy** screen will be displayed.



Load document into the feeder. No need to worry about facing down or facing up since the Intelligent Copy System will automatically make a correct and perfect copy.





Note:

The product is built-in with the state-of-the-art image processor to provide an optimal default settings and image quality for common copy job. Change the default copy settings only when you need to perform an unusual copy task.


3. The product will automatically make one copy of your document and then the following screen will be prompted enquiring if any adjustment such as Density, Auto Fit, or Scaling needs to be made.



- a. If no adjustment is required, press $\lceil < \rfloor$ (Back) to return to the main Copy screen.
- b. If density, or scaling needs to be adjusted, select your desired value, enter your copy count and press [Copy] to complete.

二、Copy Multiple Document

1. Tap the **Drop N Take** button on the main screen, and the following **Copy** screen will be displayed.



2. Load a stack of multi-page document to the feeder. The product will first automatically scan first page and the following screen will be displayed.



- (1) If you need to make 2-Side copy, press [Scan 2-Sided].
- (2) If you need to make single-side copy, choose your desired page.
- **3.** The product will continue the copy of the rest document.




Note:

Since the product detect only the first page, therefore, the document arrangement (such as odd page face up...) of the whole stack of documents must be consistent with the first page.

[More...] Button

(1) Click [More] to access more copy options.








(3) Choose one side or 2 sides, then the copy will begin.

Flatbed Copy

- 1. Make your document with text **FACE DOWN** on the document glass.
- **2.** Tap the **Drop N Take** button on the main screen, and the following **Copy** screen will be displayed.



Confirm or change Copy options as desired such as Paper Supply, Scaling, Density, Auto Fit, Bind, and Duplex Output.

3. Press to complete.

Using the [Bind] Feature




Important:

The [Bind] feature is only available for flatbed copy.

When the [**Bind**] feature is turned on, copy for the 1st sheet or 1st stack of document will be completed first. Then the following screen will be prompted indicating that the next sheet or stack of document is ready to be placed.

- >> To end your job, tap Finish .
- >> To copy next sheet or next stack, open the document cover to remove first sheet and then place next sheet on the glass, tap [Continue] to complete your copy; or place your next stack of document in the document feeder and then tap [Continue] to complete.



Copy Settings:

Common Ready Paper Supply 1 Auto Fit 100 **Paper Supply** Choose your paper supply. Choice: Auto, Tray 1, Tray 2, Manual Tray. **Density** Lighten or darken your original. Levels: 1~7 (default: 4) **Auto Fit** Check this option to automatically reduce or enlarge your original according to output paper. Choose if you wish duplex output to **Duplex Output** save paper. Bind Choose if you wish to open the 「Bind」 feature. The bind feature lets you scan multiple multi-page documents continuously from the ADF or multiple single-side paper continuously from the glass. Choice: On/Off Scale% Choose if you wish to reduce or enlarge your original. Range: 25~400% (default=100%) Count Enter your copy count. Choose if you wish to merge your multi-page document. Merge Choice: Off/2-in-1/4-in-1 2 in 1 4 in 1 1 2 3 4 1 Original 1 2 Copy Result 1 2 1 2 3 4

Collate



Collated: Place your copies in $\lceil Sort_{\perp} \rceil$ order (e.g. page 1,2,3 /1,2,3 /1,2,3).

Uncollated: Place your copies in $\lceil \text{Stack} \rfloor$ order (e.g. 1,1,1/2,2,2/3,3,3).

Advanced



The "Advanced" page provides more functions, such as document mode, watermark, etc.

Document mode: Text, Mixed Mode

Text: Sharpen the text of the original to make the text clearer.

Mixed Mode: Optimize the picture to make it look more vivid.

Watermark: Use the watermark function to add text such as confidential, important, draft etc. to the document. After turning on the function, you can enter the text of the watermark, set its size (large, medium, small) and angle (0 degrees, 45 degrees, 90 degrees, 135 degrees). Choice: On/*Off*

Ticket Mode: When [Ticket Mode] is turned on, if your original placing on the glass platen is smaller than A5 size, the system will retain the complete image and will not perform edge cropping. Choice: On/*Off*

Rotate Side 2: Enable [Rotate Side 2] when 2-Side copy is selected.


* Default settings is shown in italic bold style

ID Card Copy

The product is designed with the auto crop and deskew feature which allow you to easily place your document on the glass platen without the need to carefully align your document to the starting point. Even though the document is placed with a slight angle as illustrated in below, the front side and rear side of your ID card can be copied perfectly on a single sheet of paper.


The Operation Steps:

1. Place one side of your ID card **FACE DOWN**, aligned with the **ID Card** mark as indicated below:







2. Tap the **ID Card Copy** button on the main screen, and the following **ID Card Copy** screen will be displayed.



- Confirm or change ID Card Copy options.
- **4.** Enter your copy count with the Up **▲** /Down **▼** key.
- 5. Tape the [Copy] button copy on the touch panel to start copying your card.
- **6.** After the first side scanning is finished, the **Do you wish to continue?** J dialog box will be prompted.

7. Open the document cover and place the other side of your card, aligning it with the **ID Card** mark as illustrated.





8. Tap [Yes] on the touch panel to continue scanning the other side of your card or tap [Cancel] to leave the screen. The result showing up and down layout is illustrated in below:






Important!

The ID Card Copy feature does not support loading your cards from the auto document feeder.

ID Card Copy Settings



ID Card Copy Copy the front and rear side of your ID card on the (*Up/Down) upper and bottom half of one side of a sheet. Two scans are required to complete the task. The first scan of one side of card will be copied on the upper half while the second scan of the other side of card will be copied on the bottom half of one side of your sheet. **ID Card Copy** Copy the front and rear side of your ID card on the (Right/Left) right and left side of a sheet. Two scans are required to complete the task. The first scan of one side of card will be copied on the right side while the second scan of the other side of card will be copied on the left side of one side of your sheet. **ID Card Copy** Copy the front and rear side of your ID card on the (Front/Rear) front and rear side of a sheet. Two scans are required to complete the task. The first scan of one side of card will be copied on the front side while the second scan of the other side of card will be copied on the rear side of one side of your sheet.


^{*}Factory Default Setting

Scan

The scan function allows you to first scan your documents and then send the scanned image to a specified destinations such as Scan to Device (this product's memory), or Scan to USB (an inserted USB flash drive).

The Operational Steps:

- 1. Place your multi-page document **Face Up** and **Top First** in the auto document feeder or single-page **Face Down** on the document glass.
- 2. Tap the [Scan] button on the touch screen, and the [Scan] screen will be displayed.



- **3.** Tap \[Scan to Device \] to choose your scan-to destination.
 - **Scan to Device**: Send the scanned document to the product's memory. (Download the image through the embedded web page.)
 - Scan to USB: Send the scanned documents to the inserted USB flash drive.
- **4.** Tap [**Advanced Settings**] to confirm or change Scan options as desired such as Resolution, Output Color, Density, 1/2-Sided Scanning, File Format, Folder, or Original Size.

Resolution: Choose the resolution of the scanned image. The higher the value, the more details can be reviewed yet more disk space will be required. Choice: **150**/200/300/600 dpi

150 dpi: Suits to be viewed on the screen.

200 dpi: Suits for most business document.

300 dpi/600 dpi: High quality image helps increase OCR (optical

character recognition) accuracy.

Color Mode: Choose your desired color mode. Choice: Color Gray B&W

Original Size: Choose your scan size. Choice: *Auto*, A3\(\text{D}\), A4\(\text{D}\), A5\(\text{D}\), B4\(\text{D}\),


1/2-Sided: Choose if you wish to scan one side or both the front and rear side of your document. Choice: *1-Sided* • 2-Sided

Density: Lighten or darken your original. Levels: 1~7 (**default:** 4)

File Format: Choose your desired file format for the scanned image. Choice: M-PDF (Multi-Page PDF), PDF (Single-Page PDF), JPEG, BMP, TIFF.

- * The default settings is shown in italic bold style.
- **5.** Tap the **Scan** button on the touch screen to start scanning and sending your document.

Scan setting description:



File Destination

Choose the destination of your scanned document.



Choice: *Scan to Device*/Scan to USB/Scan to FTP/Scan to SMB

Scan to Device: Send the scanned document to the product's memory. (Download the image through the embedded web page.)



Tap \[\text{Add a new folder name} \] to create a new folder.

(To delete a current folder, open the embedded web page.)

File name Prefix: Tap the blank field to enter your desired prefix. Tap 「OK」 to leave the keyboard screen.



Naming Method: Prefix_YYMMDDHHMMSS_#N. For example, 「Marketing_150213144840_3.pdf」indicates Marketing(prefix) 2015 (year) 2 (February) 13 (date) 14 (hour) 48 (minute) 40 (second) 3(serial number) (the time the file has been sent) •

Scan to USB: The scanned image will be sent to the USB flash drive inserted to the product.



Tap \[\text{Add a new folder name} \] to create a new folder in the USB flash drive.

Naming Method: Prefix_YYMMDDHHMMSS_#N. For example, 「Marketing_150213144840_3.pdf」 indicates Marketing(prefix) 2015 (year) 2 (February) 13 (date) 14 (hour) 48 (minute) 40 (second) 3(serial number) (the time the file has been sent) •

Note: The disk format for the USB flash drive supports only FAT16, and FAT32.

Scan to FTP: Send the scanned image to FTP server in the network.

To edit (add/modify/delete) the FTP destination, please go to the product's embedded web site and then choose Filing destination as shown in below:



Naming Method:Prefix_YYMMDDHHMMSS_#N. For example, 「Marketing_150213144840_3.pdf_indicates Marketing(prefix) 2015 (year) 2 (February) 13 (date) 14 (hour) 48 (minute) 40 (second) 3(serial number) (the time the file has been sent).

Scan to SMB: Send the scanned image to the SMB server in the network.

Naming Method: Prefix_YYMMDDHHMMSS_#N. For example, 「Marketing_150213144840_3.pdf」 indicates Marketing(prefix) 2015 (year) 2 (February) 13 (date) 14 (hour) 48 (minute) 40 (second) 3(serial number) (the time the file has been sent) •

To edit (add/modify/delete) the SMB destination, please go to the product's embedded web site and then choose Filing destination as shown in below:



Destination

Display the default folder and file name. Tap the File Name Prefix field to enter your desired prefix.

Directory: Public – indicates root directory in the product's memory.

File name: DOC – indicates default prefix, the prefix can be changed as desired.

YYMMDDHHmmss –YY indicates the last two digits of year, MM indicates month, DD indicates date, MM indicates minutes, and SS indicates seconds.

#N - indicates series number.

Scan Settings:

The Common Tab




	Tal
File Format	Choose your desired file format. Choice: <i>M-PDF</i> (<i>Multi-Page PDF</i>) PDF (Single-Page PDF) JPG BMP TIF.
Original Size	Choose your scan size.
	Choice: <i>Auto Detect</i> /B5\(\subseteq\), B5\(\text{D}\/A3\(\supseteq\), A4\(\supseteq\), A4\(\text{D}\), A5\(\supseteq\),
Color Mode	Choose your color mode.
	Choice: <i>Color</i> , Gray, Black and White
1-Sided/	Choose if you wish to scan one side or both the front and
2-Sided	rear side of your document.
	Choice: 1-Sided 、2-Sided
Document	Chooses your document type.
Туре	Choice: Text/ <i>Photo</i> /Mixed/Remove Background Text: Select to sharpen your text. Photo: Select to enhance your photo quality. Mixed: Suitable for most typed originals. Remove Background: Select to remove background to sharpen your text.
Resolution	Choose the resolution of the scanned image. The higher the value, the more details can be reviewed yet more disk space will be required. Choice: 150/200/300/600 dpi 150 dpi: Suits to be viewed on the screen.
	200 dpi: Suits for most business document.
	300 dpi/600 dpi: High quality image helps increase OCR (optical character recognition) accuracy.
* Default settings to be shown in italic bold style	

The Image Tab



Saturation	The level of saturation decides if the color is pale or rich. Choice: 1~7 (default: 4)
Gamma	The midtones of the image.
	Choice: 1~2.4 (1.8)
Sharpness	Sharpen the scanned image.
	Choice: 1~7 (default: 1)
Color Matching	Adjusts the color quality of the image so that it comes close to the original. This function uses default parameters to adjust the image.
	Choice: Off/On
* Default settings to be shown in italic bold style	

The Advanced Tab



Auto Orientation	Choose if you wish to enable the function of automatically detecting the orientation of the original document. Choice: <i>Off</i> /On
Blank Page Removal	Choose if you wish to automatically remove blank pages of your document.
	Choice: Off/ <i>On</i>
* Default settings to be shown in italic bold style	

Print Saved Job

The Print Saved Job function allows you to print previously stored files directly from the machine. The previously stored files include the files in your computer and the files in your removable USB flash drive. Many frequently used forms can be saved into the product's memory and then use the [**Print Saved Job**] function to print the file on demand.


To save the file into the product's memory, you need to enable the [**Storage Copy**] from the Printer's [**Preference**] dialog box and then enter the document's ID number. Open the file and then choose Print>AM76XXi Printer, the file can be saved into the product's memory. (Refer to Chapter 5 for more detail in page 116)

To print the file in your removable flash drive, simply insert your removable USB flash drive into the USB port on the left end of the control panel and then choose the file from the [**Print Saved Job**] screen. Note: Only jpeg and pdf file formats are supported.

The Operation Steps:

- 1. Place your multi-page document **Face Up** and **Top First** in the auto document feeder or single-page **Face Down** on the document glass.
- 2. Swipe on the main screen and then tap the 「Print Saved Job」 button on the touch screen, and the 「Print Saved Job」 screen will be displayed as shown.





3. On the **File Destination** option, choose the destination of your file such as Public (the product's memory), or the inserted USB flash drive. You can also

type in your key word for a destination, and tap destination.



to search the

 Confirm or change print options as desired such as Paper Supply, 1/2-Sided, Count.

Paper Supply: Choice: Auto Select, Manual, Tray1, Tray2

1-Sided /2-Sided: Choose to print one side or two sides of your document.

Choice: 1-Sided, 2-Sided

- **5.** Enter your print count by sliding the Count roller.
- **6.** Tape the **Print** button on the touch panel to start printing your document.


^{*} The default settings will be displayed in italic bold style.


Add a New Document:


The **Add a New Document** function allows you to scan your document and save the copy job (the scanned image) temporarily in the product's memory. Print the file at a later date when necessary.

The Operation Steps:

- Place your document(s) with text FACE UP in the ADF or FACE DOWN on the glass.
- 2. Swipe on the main screen and then tap the 「Print Saved Job」 button on the touch screen to prompt the 「Print Saved Job」 main screen and then select [Add a new document]. The 「Add a new document」 screen will be displayed.







- **3.** Set up your desired options respectively. For detailed information about these tab options, please refer to the next page.
- **4.** Tap the **Print** button on the touch screen to start copying your document to the product's memory.

Setting Description

(The default settings is shown in Italic bold style)




Original Size	Choose your scan size. Choice: <i>Auto</i> , A3D, A4D, A4D,
2-Sided Copy	 A5b, B4b, B5b 1-Sided: Copy single-sided originals onto one side of one sheet of paper. 2-Sided: Copy double-sided original onto two sides of one sheet of paper.
Density	Lighten or darken your original. Levels: 1~7 (default: 4)
File Name	Store a file by your specified prefix filename. Naming Method: Prefix_YYYYMMDDHHMMSS.file format. For example, 「Marketing_150213144840.pdf」 indicates Marketing(prefix) 2015 (year) 2 (February) 13 (date) 14 (hour) 48 (minute) 40 (second) (the time the file has been sent)。
Select Folder	Select a folder to store the job (scanned image).


E-Mail

The **F-Mail** function allows you to scan your documents and send the scanned image to your recipients via e-mail.

The Operation Steps:

- 1. Place your multi-page document **Face Up** and **Top First** in the auto document feeder or single-page **Face Down** on the document glass.
- **2.** Swipe on the main screen and then tap the **[E-Mail]** button to prompt the **[E-Mail]** screen.







3. Tap the blank field of **To** option, and a soft keyboard screen appears. Enter your recipient's email address and press

to complete.



After completing entering the email address, displayed at the right corner.

a recycle bin icon will be

: Tapping the button allows you to instantly delete the current To addresses.

- **4.** If necessary, tap the blank field of the <code>[CC]</code> and <code>[BCC]</code> option to enter the e-mail address of the rest recipients.
- 5. Tap the blank field of Subject option, enter the e-mail subject, and tap [OK] to confirm the subject.
- **6.** Tap the blank field of From option, enter the sender's e-mail subject, and tap [OK] to complete.

Note: The sender's address is a must item you need to fill before sending the scanned image.

7. Tap \[Advanced Settings \] to confirm or change E-mail options as desired such as Resolution, Output Color, Original, 1/2-Sided Scan, File Format. Also touch other tabs for more options.

「Quality」: Choose the resolution of the scanned image. The higher the value, the more details can be reviewed yet more disk space will be required. Choice: 150/200/300/600 dpi

150 dpi: Suits to be viewed on the screen.

200 dpi: Suits for most business document.

300 dpi/600 dpi: High quality image helps increase OCR (optical character recognition) accuracy.

[Color Mode]: Choose your desired color mode. Choice: Color, Gray, B&W

「Original Size」: Choose your scan size. Choice: *Auto*, A3₺, A4₺, A4₺, A5₺, B4₺, B5₺

 \lceil **1-Sided/2-Sided** \rfloor : Choose if you wish to scan one side or both the front and rear side of your document. Choice: *1-Sided* \cdot 2-Sided

File Format]: Choose your desired file format for the scanned image. Choice: *Multi-Page PDF*, Single-Page PDF, JPEG, BMP, TIFF.

「Auto Detects the Original Orientation」: Choose if you wish to enable the function of automatically detecting the orientation of the original document. Choice: *Off*, On

- * Default settings is shown in italic bold style
- **8.** Tape the **[E-mail]** button sending your document.




on the touch panel to start scanning and



Notice:

- The product does not preset the sender's e-mail address. Users are free to enter their own favorite sender's e-mail address.
- The administrator of this product can preset a third-party's address as the sender's e-mail address to save user's time in typing the address. At the same time, add 「no reply」 in the original subject field to avoid recipients reply to the address. To preset the sender's e-mail address and the subject, press the 「Machine Status」 button on the control panel and press choose Tools>Service Settings>E-mail Service Settings>Feature Default in succession and modify the subject and sender's e-mail address.

Select one recipient from the Address Book



Advanced Settings: Tap \[\text{Advanced Settings} \] to set more settings for the scanned image that will be attached to the e-mail.



File Format	Choose your desired file format. Choice: M-PDF (Multi-Page PDF) PDF (Single-Page PDF) JPG BMP TIF.
Original Size	Choose your scan size.
	Choice: <i>Auto Detect</i> /B5\(\subseteq\), B5\(\text{D}/A3\subseteq\), A4\(\subseteq\), A4\(\text{D}\), A5\(\supseteq\), LTR\(\text{D}\)
Color Mode	Choose your color mode.
	Choice: <i>Color</i> 、Gray、Black and White
1-Sided/	Choose if you wish to scan one side or both the front and
2-Sided	rear side of your document.
	Choice: 1-Sided 2-Sided
Document	Chooses your document type.
Туре	Choice: Text/ <i>Photo</i> /Mixed/Remove Background
	Text: Select to sharpen your text.
	Photo: Select to enhance your photo quality.
	Mixed: Suitable for most typed originals.
	Remove Background: Select to remove background to
	sharpen your text.
Resolution	Choose the resolution of the scanned image. The higher the value, the more details can be reviewed yet more disk space will be required. Choice: 150 /200/300/600 dpi
	150 dpi: Suits to be viewed on the screen.
	200 dpi: Suits for most business document.
	300 dpi/600 dpi: High quality image helps increase OCR (optical character recognition) accuracy.
* Default set	tings to be shown in italic bold style

The Image Tab



Saturation	The level of saturation decides if the color is pale or rich. Choice: 1~7 <i>(default: 4)</i>
Gamma	The midtones of the image.
	Choice: 1~2.4 (1.8)
Sharpness	Sharpen the scanned image.
	Choice: 1~7 (default: 1)
Color Matching	Adjusts the color quality of the image so that it comes close to the original. This function uses default parameters to adjust the image.
	Choice: Off/On
* Default settings to be shown in italic bold style	

The Advanced Tab




Auto Orientation	Choose if you wish to enable the function of automatically detecting the orientation of the original document. Choice: <i>Off</i> /On
Blank Page Removal	Choose if you wish to automatically remove blank pages of your document.
	Choice: Off/ <i>On</i>
* Default settings to be shown in italic bold style	


Fax (Optional)

The fax function (optional) allows you to scan your document and then send the scanned image to a recipient's fax machine. The fax function will be available only when an optional fax modem and a telephone line have been installed.

The Operating Steps:

- 1. Place the originals **face up** in the document feeder or **face down** on the glass.
- 2. Swipe on the main screen and then tap 「Fax」 on the main screen to prompt the following Fax operation screen.







- 3. Enter the recipient's fax number or choose it from the Address Book.
 - * Note: To manually enter the recipient's fax number, only one number is allowed. If you wish to send your document to multiple recipients, you will have to choose them from the Address Book.
- **4.** Confirm or change Fax options as desired such as Redial internal, Redial count, or Density.

Redial interval: Sets the redial interval setting if the number dialed is busy. Choice: 1 minute, *2 minutes, 3 minutes.

Redial count: Sets the number of redial attempts if the number dialed is busy. Choice: *0, 1, 2

Density: Lighten or darken your original. Levels: 1~7 (*4)

* Factory Default Setting

5. Press the **Fax** button



to start scanning and faxing your document.

Operation from an extension telephone

To send a fax when the product's fax number is an extension phone number from your telephone exchange:

- 1. Place the originals face up in the document feeder or face down on the glass.
- 2. Touch \(\Gamma \) Fax \(\Lambda \) on the main screen.
- **3.** On the Fax main screen, enter the representative outside connection number of your telephone exchange, the 'P' code, and then the other party's fax number.

Example: OP5777017, where '0' represents a representative number, 'P' represents the 'P' code, and 5777017 represents the other party's fax number.



4. Press the **Fax** button

To send a fax to the other party's fax machine connected to an extension phone jack:

- 1. Place the originals **face up** in the document feeder or **face down** on the glass.
- **2.** Touch 「**Fax**」 on the main screen.
- **3.** On the Fax main screen, enter the other party's fax number, the 'P' code, and then the other party's extension number.

Example: 5777017P123, where 5777017 represents the other party's fax number, 'P' represents the 'P' code, and 123 represents the other party's extension number.



4. Press the Fax button




Note:


- Each 'P' code causes a 2-second delay.
- The delay caused by the other party's telephone exchange depends on how long it takes for the other party's telephone exchange to transfer the call.

Normal Copy

The Operating Steps:

- Place your multi-page document Face Up, Top First in the auto document feeder or place your single-page document Face Down on the document glass.
- 2. Swipe on the main screen and then tap the \[\textbf{Normal Copy} \] button, the following \[\textbf{Copy} \] screen will be displayed.





Confirm or change Copy options as desired such as Document Type, Paper Supply, 2-Sided Copy, and Density.

Document Type: Choose your document type. Choice: *Text*, Photo

Paper Supply: Choice: Auto, Tray 1, Tray 2, Manual Tray.

2-Sided Copy: Choose if you wish to copy one side or two sides (front and rear

sides) of your document.

Density: Lighten or darken your original. Levels: 1~7 (default: 4)

- * The default setting to be displayed in italic bold style
- **4.** Enter your copy count with the numeric keypad on the control panel. The number of copy count will appear on the upper right corner.
- 5. Tap the Copy button on the touch screen to start copying your document.

Copy Settings Description

Common Settings



Document Type	Chooses your copy mode. Choice: <i>Text</i> /Mixed Text: Select to sharpen your text. Mixed: Suitable for most typed originals.
Paper Supply	Choice: <i>Auto Select</i> , Tray 1, Tray 2, Manual. Auto Select automatically helps a user find the input tray that best meets the scanning paper size.
Output	1-Sided→1-Sided: Copy single-sided originals onto one side of one sheet. 1-Sided→2-Sided: Copy single-sided original onto two sides of one sheet. 1-Sided→2-Sided (Rotate Side 2): Copy single-sided original onto two sides of one sheet with back page upside down. 2-Sided→1 Sided: Copy double-sided original onto one side of one sheet. 2-Sided→2-Sided: Copy double-sided original onto two sides of one sheet. 2-Sided→2-Sided (Rotate Side 2): Copy double-sided original onto two sides of one sheet with back page upside down. 1-Sided→1-Sided 1-Sided→2-Sided 2-Sided→1-Sided (Rotate Side 2) 2-Sided→2-Sided (Rotate Side 2) 2-Sided→2-Sided (Rotate Side 2)
Density:	Choose your desired density level. Choice: 1~9 (4)
Count:	Enter your copy count.

Scale	Choose if you wish to reduce or enlarge your original. Range:
	25~400%; <i>100%</i>

^{*} The default setting to be displayed in italic bold style


Image Settings




Auto Contrast	Turn on to automatically optimize the contrast level.
	Choice: ON/ <i>Off</i>
Toner Save	Use less toner to copy your document. Choice: ON/ Off
Descreen	Remove the moiré patterns on the printing materials. Choice: ON/ <i>Off</i>
Sharpness	Choose your desired sharpness level. Range: 1~7 (4)

^{*} The default setting to be displayed in italic bold style

Output Settings




Collated




Collated: Choose your copies to be placed in "Sort" (e.g. pages 1,2,3/1,2,3/1,2,3) order.

Uncollated: Choose your copies to be placed in "Stack" (e.g. pages 1,1,1/2,2,2/3,3,3) order.

Rotate Collated: Choose your copies to be placed in "Rotate Collate" (e.g. pages 1,2,3/1,2,3 (rotated)/1,2,3/1,2,3 (rotated))order. Rotate Collated is only available when two trays with different paper orientation are applied.





* : Factory Default settings is displayed in italic bold style


Advanced Settings



Book Copy

When "Book Copy" is enabled, the product will perform auto-crop and rotation so that the orientation of each page is the same. In addition, the "Duplex Output" and "Bind" functions will also be enabled to allow you perform continue copy and duplex copy to save your paper. For details, refer to <u>Using Book Copy.</u>

Book Copying also provides clear images without shadows by setting 0~18mm margin at the **bookspine** area. For example, if you set 18mm, a total of 36 mm (right 18mm, left 18mm) will be cut. Choice: On/*Off*



Watermark	Choose to superimpose watermark such as CONFIDENTIAL, DRAFT) on document. For details, refer to Imposing Watermark. Choice: On/ <i>Off</i>
Preview	Choose if you wish to perform a test copy to check the printing quality. If enable, after pressing [Start], the printer will automatically print first page. If the printing quality is satisfactory, press [Start] to complete your copy job. Choice: On/ <i>Off</i>
Ticket Mode	When [Ticket Mode] is turned on, if your original placed on the glass platform is smaller than A5 size, the system will retain the complete image and will not perform edge cropping. Choice: On/Off

Bind	Choice: On/ <i>Off</i> The Bind feature allows you to scan and combine separate documents continuously at the same scan settings. If the [Bind] feature is turned on, after your first scan is finished, a dialog box will be prompted to ask you if you wish to continue scan.
	If you wish to continue scan, place your document on the flatbed or the ADF and then tap [Scan] button to combine your scan. Tap the [Finish] button to end your scan and the dialog box will not be prompted again.
Cover	Choose if you wish to add cover (a blank sheet, a specific sheet in tray) between each copy. For details, refer to Adding a cover page. Choice: On/Off

^{* :} Factory Default settings is displayed in italic bold style


Using Book Copy

Follow these steps to make book copy:


1. Tap [Normal Copy] on the main screen and then choose [Advanced]. Turn on the [Book Copy] feature.



2. Open document cover. Align the book spine on the center of the glass platen as shown.



3. The following dialog box will be prompted after 1st page is scanned, turn to next page and align the book spine with the edge of the glass platen and then press [Continue].




- **4.** Continue to copy the rest pages.
- **5**. Press [**Finish**] if the book copy is completed.

Imposing watermark

Use the [Watermark] function to add background text such as [Confidential], [Important], [Draft], etc. on your document. To perform the watermark function, please follow the steps below:

1. Press [Normal Copy] on the main screen and then choose [Advanced]. Turn on the [Watermark] feature. An [Enter text] screen will be prompted.



2. Enter your watermark text, such as [important]. Up to 16 digits can be entered.



- 3. Choose your font size (large, medium, small) and the angle (0/45/90/135 degree).
- **4.** Press $\lceil < \rfloor$ to return to home screen and then press "Normal Copy", the copy will be done with your watermark.



Adding a cover page

A cover sheet is used to add and separate each set of copy. To use this function, follow these steps:

1. Press [Normal Copy] on the main screen and then choose [Advanced]. Turn on the [Cover page] feature.



2. Choose type of cover sheet and paper tray.

Type of cover sheet:


*Blank cover: When this is turned on, a blank cover sheet will be added between each set of copy. *: Factory default

Cover page: When this is turned on, the paper tray option will be displayed to let you specify which tray to place your cover page.

Paper tray: Tray 1 . Tray 2 . Manual Tray

3. Press [Copy] to begin making copy including the cover sheet.

Note: The [Collated] function will also be enabled.




Network Scanning


The product allows you to perform network scanning via a TWAIN-compliant software application such as Capture Tool which is bundled together with the driver. Please follow these steps to use the function.

Connecting the Product with VSL:

- 1. Connect the product to a network with an Ethernet cable.
- 2. Make sure that Virtual Scanner Link (Network Setup Tool) has been installed onto your computer. The Network Setup Tool is included in the supplied software CD.
- Start [Virtual Scanner Link] by choosing Start>All Programs>Katusha
 Virtual Scanner>Virtual Scanner Link. The main window will be displayed and
 the scanners in your network will be searched automatically. In a few seconds,
 the result including the scanner model and scanner's IP address will be displayed
 as shown.




4. Choose the scanner you wish to connect and then press [Connect]. If connection is successful, a connection mark will be displayed as shown.




5. After the scanner has been connected successfully, launch your TWAIN-compliant image-editing software application such as Capture Tool to start a scan.

Starting a Scan via Capture Tool:

- 1. Start [Capture Tool] by choosing Start>All Programs>AM76 Series MFP>Capture Tool. A [Select Scanner Model] dialog box appears.
- 2. Choose your scanner model. The main window will be displayed.



3. Click the [Scan] button to start a scan or click [Setup] to prompt the following [Scanner Properties] dialog box to change the scan settings to fit your task.






Notice:

For more detailed information on using the scan settings in the [Scanner Properties] dialog box, please refer to Chapter 6 – Scanning from Your Computer.



Notice:

- The VSL program allows multiple users to connect to the network scanner at anytime. Yet, the scanner operation can be used by one user at a time. If the network scanner is being used by other user, you will be prompted with a message to connect the scanner later. When the scanner is available, you will also be prompted with a message to connect the scanner and start scanning your document.
- If the network scanner has not been found, it is probably the scanner and your computer are not in the same LAN. In this case, you can assign a specific IP address of the scanner to let [Virtual Scanner Link] automatically search the scanner. Click the [Option] button, type your IP address on the [Searching Address] field, then click the [+] button and finally click [OK] to complete.



- Searching Time: When the program is launched, it automatically searches the scanner in the network in 5 seconds (default). The searching time can be changed from a range of 5 to 20 seconds.
- If the [Virtual Scanner Link] program has been closed and then launched again, [Virtual Scanner Link] will automatically search and connect the network scanner it has previously connected to.
- The connection is always enabled, whether the scanner enters into the sleeping mode or turns off and on again. VSL will automatically detect the previously connected scanner and connect again.
- [Automatically searching and connecting device]: Check this option and enter your time (1~5 min.) to allow the VSL to reconnect to the device every specified minute(s) if the device has been woken up during sleep mode or the device has been turned off and on again.
- [Connecting the device with a specified name instead of a login name]: Check this option and enter your desired name for the computer. Yet you need to reconnect the device again to refresh the status.

4. Customizing the Product's Configurations

This chapter is specifically targeted to the persons who are responsible for the administration of the product. It is recommended that the administrator read this chapter before installing the machine.

The product's configurations can be customized via the touch screen and the control panel. In addition to using the touch screen, the product allows the administrator to remotely configure the machine by launching the product's embedded web page. How to customize the product's configurations via these two methods will be described in the following sections.




Note:

When installing the product for the first time, it is recommended that the Administrator retain the default system settings. The settings can be customized at a later date once you are familiar with the operation and functionality.

Customizing the Product's Configurations by the Touch Screen

Click [More Settings] and then choose [View Machine Status]. This will prompt the following [Machine Status] page which contains 5 tabs.



These 5 tabs displaying at the top are: Machine Information, Faults, Supplies, Billing Information, and Tools. For each respective option of the 5 tabs, refer to the descriptions of the next few pages.

Machine Information

General Information: Display the product's basic information.

Item	Description
Host Name	Displays the product's host name.
IP Address	Displays the product's IP address.
MAC Address	Displays the product's MAC address.
System Version	Displays the product's system version.
Engine Version	Displays the product's engine version.
UI Version	Displays the product's UI version.
Homepage Version	Displays the product's home page version.
Wi-Fi Mac Address	Displays the product's Wi-Fi Mac address.
Wi-Fi Address	Displays the product's Wi-Fi address.

Paper Tray Status: Display the product's paper tray status.

Item	Description
Tray	Displays the paper tray's number including
	Manual tray.
Status	Displays the remaining paper in the tray.
Paper Size	Displays the paper size with its orientation.
Media Type	Displays the media type to use.

Information Pages: Print out the product's various reports.

Item	Description
Demo Page	Prints the product's demo page.
System Configuration Page	Prints the product's configuration page.
Network Settings Report	Prints the product's network settings
	report.
System Menu Map	Prints the product's menu map.
System Usage Page	Prints the product's usage report.
Fax Activity Log Report	Prints the product's fax activity report.
Storage Job List Report	Prints the product's storage list.
Address Book	Prints the product's address book.
System Supplies page	Prints the product's supplies page.
Send Meter	Prints the product's usage page.

Installed Options: Display the enabled or disabled status of the product's functions. Enable or disable the product's functions only via the embedded web page.

Item	Description
Drop N Take	Displays the enabled or disabled status of the
	function.
ID Copy	Displays the enabled or disabled status of the
	function.
Scan	Displays the enabled or disabled status of the
	function.
E-mail	Displays the enabled or disabled status of the
	function.
Reprint Saved Job	Displays the enabled or disabled status of the
	function.
Fax	Displays the enabled or disabled status of the
	function.
Normal Copy	Displays the enabled or disabled status of the
	function.

Faults

Faults: Display the current error items or warning message list.

To view each error's detailed information and troubleshooting methods, select each error item and touch the **Instruction** button on the screen.

Supplies

Supplies: Display the supplies' status.

Item	Description
Toner usage remain	Displays the current remaining toner capacity in
	percentage.
Developing unit usage	Displays the current remaining Developing Unit
remain	capacity in percentage.
Fuser usage remain	Displays the current remaining fuser capacity in
	percentage.
Drum unit usage	Displays the current remaining drum capacity in
remain	percentage.

Billing Information

Billing Information: Used to display the usage status of the product's functions.

Item	Description
Machine serial	Displays the product's serial number.
Number	
Total Page Counts	Displays the total page counts.
Usage Counters	The types of counters are classified as Copy,
	Printer engine, and Scanner Module.
Counters/Count	Displays the respective total cumulative usage
	number of the copy, printer engine, and scanner
	module.

Tools

Device Settings: Display the basic settings on the product.

Device Settings	
Item	Description
Language	Changes the language on the touch screen.
	Supported languages: English, Traditional
	Chinese, Simplified Chinese
Date / Time	Sets up the current date and time on the product.
	The time format is 24-hour system.
Time Zone	Specify local time zone.
Selectable Paper Size	Specify auto detectable paper size for paper tray option (Auto Select).
	Choice: *A3, B4, *A4, B5, *A5, LGL, LTR, DLT (*: Default)
Size Spec	Selects paper size detection format.
	Supported detection format: *ISO 216, North America
Tray Contents	Presets paper size and orientation on the input
	trays.
	[Auto] means the product will automatically detect
	the paper size a user uses.
Sleep Mode	Choose how long to enter the energy saving mode
	after your last action.
	Choice: *Eco Mode, 5Min, 15Min, 30Min, 1Hr
	As Eco mode requires more time to return to the
	ready mode, to reduce the waiting time, you can
	change the default mode to other options.
Auto Power Off	Choose how long to enter the energy saving mode
	after your last action.
	Choice: * None, 5Min, 15Min, 30Min, 1Hr,
	2Hr, 4Hr
Schedule Restart	Enable or disable automatically restart the product
	on a preset schedule.
	Choice: On/Off
Management	Reset Default: All settings in Tools are back to the
	factory defaults.
	Recalibration: Calibrate the scan module.

System Timeout	When the touch screen has not been operated for a period of time, the system will
	automatically reset all settings in the touch screen back to the preset values and return to
	the main screen.
	System Timeout values available: From 5
	seconds to 600 seconds. Each selectable
	interval range is 5 seconds. (*: 30 sec.)
Display Brightness	Sets up the brightness on the touch screen.
Default Operating Mode	Set the default operating mode (function) on
	the touch screen. After timeout arrives, the
	specified default operating mode will be
	displayed. (* Copy)
Heater	Turn on the heater and specify the humidity
	level of the sensor to keep the inside of the
	printer operate in the correct environment.
	Choice: *Off/RH 80%/RH 70%/RH
	60%/RH 50%/On

^{*:} Factory Default Settings

Default Settings: presets the settings and defaults for each function features.

Default Settings	
Item	Description
Copy Default Settings	Presets the default settings for Copy.
Scan Default Settings	Presets the default settings for Scan.
E-mail Default Settings	Presets default settings for E-mail.
Address Book	Presets the address book.
ID Card Copy Default Settings	Presets default settings for ID Card Copy.

Fax Default Settings



Presets the default settings of the fax function.

Header:

Sets header information for outgoing faxes. The header information is limited to 20 alphanumeric characters or symbols. Only six symbols are allowed: ". (dot), – (hyphen), _ (underscore), @,; (semicolon) and blank".

Country:

Sets fax country settings (Taiwan, China, Indonesia, Korea, United States, Germany, Singapore, Malaysia, Thailand, and South Africa).

Header Phone Number:

Set the fax number of the machine, up to 40 characters. Only numbers, uppercase and lowercase letters P(p) and symbols are allowed. Symbols are allowed only for "! * # 3".

Footer:

Sets ON if you wish to show footer information for all receiving faxes.

ECM:

Choose ON if you wish to enable the Error Correction Mode to correct errors in transmission due to bad lines.

Tx Level:

Sets the level of transmission signal. Choice: 0 dbm, -1dbm, -2dbm, ..., -15dbm

Speed:

Choose your desired speed during transmission. Choice: V.27ter 4.8k bps, V.29 9.6k bps, V.7ter 14.4k bps

Protocol Report:

Choose if you wish to print the fax protocol formation. Choice: Error, ON, OFF

Error	Report will be printed only when the	
	transmission fails.	
ON	Report will be printed after each	
	transmission.	
OFF	Report will not be printed after each	
	transmission.	

Transmit Report:

Choose if you wish to print the fax transmission report. Choice: Error, ON, OFF

Error	Report will be printed only when the
	transmission fails.
ON	Report will be printed after each
	transmission.
OFF	Report will not be printed after each
	transmission.

E-mail Default Settings	Presets the default parameter settings of E-mail. Confirmation Report: Determines whether to print the report by choosing these options: Always Print, Off, Print on Error.
Address Book :	Edits the email or fax contact person information. Individuals: Edit the contact information. Up to 500 contacts can be edited. Groups: Add an existing contact to a Group. Up to 10 groups can be entered.

Network Settings: presets the network default settings.

Network Settings	
Item	Description
Enable	Enables or disables the product's Ethernet or Wi-Fi function. Choice: Off, Ethernet, Wi-Fi Wi-Fi: Available for Wi-Fi Station Mode. [Station] mode: In Station mode, this product
	acts as a client that connects to a Wi-Fi Access Point (usually a Wi-Fi enabled router). Note: Ethernet mode and Wi-Fi mode can not be working at the same time.
Host Name	Sets up a host name for the product.
TCP / IP Settings	Sets the connection methods and parameters of the product's network. DHCP: Enables or disables the DHCP. You don't need to specify the Static IP if you enable DHCP. IP Address/ Subnet Mask/ Gateway: if you disables DHCP, set up IP Address, Subnet Mask, and Gateway for your Static IP. DNS Server: Sets up a DNS server address for the product.

SMTP	Sets SMTP parameters of the product's network.
	Login Name: Input a login name for the product's SMTP server.
	Password: Enter a password for the product's SMTP server.
	Mail Server: Input an IP address or host name for the product's mail server.
	Port: Input a port number for the product's mail server.
	Authentication Method: Sets an authentication method (SMTP) for the product's mail server. Selecting None will not use an authentication method.
WI-FI	Choose the network name (SSID), channel, and authentication method.
	Enter the authentication key in the Key Setting box.
Network Security Setup	Enable or disable filter. Please go to the product' embedded web page to specify filter IP address.
User Authentication	
Item	Description
User Authentication	Enables or disables the user authentication function.

Customizing the Product's Configurations by the Product's Web Page

- 1. Specify the network parameters by referring to the previous section, Specifying the Product's IP address and other Network Settings.
- 2. The product is designed with an embedded web page to allow the system administrator to remotely manage the product. Simply type the IP address of the product in the URL field of your browser and then press Enter. The product's embedded web page appears as shown below.



3. Click each item under these tabs to set up relevant values. For details on each setting, please refer to the subsequent section, Summary of the Web Pages.

Summary of the Web Pages

The embedded web page contains the following five tabs, the Status tab, the Job tab, the Scan tab, the Print tab, and the Properties tab. Each of the tabs will be described in this section.

The Status Tab: The Status tab contains the following options: General Information, System Usage Page, System Supplies Page.

General Information: displays the product's general information.

Item	Description
Host Name	Displays the product's name.
Machine Serial	Displays the machine serial number.
Number	
System Version	Displays the product's system version.
Engine Version	Displays the product's engine version.
UI Version	Displays the product's UI version.
Homepage Version	Displays the product's home page version.
IP Address	Displays the product's IP address.
MAC Address	Displays the product's MAC address.
Toner Remain	Displays the current remaining toner capacity in
	percentage.
Machine Status	Displays the product's machine status.
Wi-Fi Address	Displays the product's Wi-Fi address.
Wi-Fi Mac Address	Displays the product's Wi-Fi Mac address.
Wi-Fi SSID	Displays the product's Wi-Fi SSID.
Tray Status	Tray Status: Displays the following information in
	Tray1~Tray4 and Manual Tray:
	Status: shows the remaining paper.
	Paper Size: shows paper size with its orientation.
	Media Type: shows the media type to use.
	inicula Type, shows the media type to use.

System Usage Page: displays the product's usage report.

Item	Description
System	Displays the product's system information including Product Name, Product Serial Number,
	and Continue Power On Time (hr,min).
Сору	Displays the product's copy count.
Printer Engine	Displays the product's print count.
Scanner Module	Displays the product's scan count.
Fax Module	Displays the product's fax count.

System Supplies Page: displays the product's supplies status.

Item	Description
System	Displays the product's system information
	including Product Name, Product Serial Number,
	and Continue Power On Time (hr,min).
Toner Cartridge	Displays the serial number, and the usage
	remaining information.
Developing Unit	Displays the serial number, and the usage
	remaining information.
Drum Unit	Displays the serial number, and the usage
	remaining information.

The Jobs Tab: The Jobs tab contains the following options: Active Jobs and Saved Jobs.

Active Jobs: displays the product's active jobs.

Item	Description
Owner	Displays the local or remote users.
Name	Displays the function name that is performed.
Status	Displays the function status.
Timeout Settings	Choice: Immediate Cleanup All Jobs, Schedule Cleanup all Jobs
	Option: Delete all jobs now or at a specified period.

Saved Jobs: Used to display or reprint current saved jobs.

Item	Description
Create New Folder	Creates a new folder to save a print job.
Manage Folders	Deletes a folder of the saved print job.
Folders	Displays the job name, paper size, number of pages, and date & time in a folder. Also prints or deletes the job in a folder. Print options include: the number of copies, 1-Sided, 2-Sided, and 2-Sided, Rotate Sided2.

The Scan Tab: The **Scan** tab contains the following filing destination including **FTP/SMB Setup** and **MFP's Storage**.

FTP/SMB Setup: Used to display all destinations or create a new FTP or SMB destination to store the scanned images.

Item	Description
Add New	Click to add a new destination. Please enter your
	settings for the following items.
Filing	Type your file name.
Name	
Protocol	Choice: FTP, SMB
URL	Input the URL of a filing server.
Port	Type the port number of your filing server.
Login Name	Type the login name of your filing server if required.
Password	Type the password of your filing server if required.
Retype	Retype your password.
Password	
Сору	Check a file destination, and click this button to copy this
	destination settings including Protocol, URL, Port, Login
	Name, and Password.

MFP's Storage: Used to download and delete files stored in the machine's memory.

Item	Description
Action	Download and delete files in a folder.

The Print Tab: The **Print** tab allows the administrator to print a file from a computer.

Item	Description
File Name	Select a file name from a computer.
Print Size	Select a print size.
2-Sided	Select the 1-sided or 2 sided printing.

Print: Used to print a file in a computer.

Item	Description
File Name	Click Browse to select the file you want to print from a computer. Print options include: number of copies, 1 sided/2 sided printing, and print size.
Submit Job	Print a file in your computer.
Clear	Recover the default option status.

The Properties Tab: The Properties tab contains the following options: Address Book, Network, Service Registration, User Authentication, Cloning, Device Settings, SysLog, FW Update, and App Plug-In.

Address Book: Used to import /export an e-mail address book or a telephone directory.

Item	Description
Import Address	Import an e-mail or a phone address book file in .csv
Book	file from your computer.
Export Address	Export an e-mail or a phone address book file in the
Book	product to .csv file. The address book file can be
	opened or modified via the Excel software.

Network: Used to specify the network parameters of the machine.

Item	Description
Host Name	Display or specify the host name.
TCP/IP Setting	Display or specify the TCP/IP information including DHCP, host name, IP address, subnet mask, gateway address, domain name, primary DNS server, secondary DNS server, primary WINS server, and secondary WINS server for TCP/IP Settings.
SMTP	Display or specify the IP address/host name, port number, authentication method, login name, password, and time zone on a SMTP server.
Network Security Setup	Display or specify the security configuration, filter configuration, IP address filter configuration, and Mac address filter configuration.
LDAP Server	Display or specify the name of the LDAP server, Base DN, IP/URL, port number, server type, search attribute, from e-mail address, search timeout, login name, password, and authentication type.
SNMP	
Enable SNMPv1/v2	On/Off
Community name	Define your community name.
Enable SNMPV3	On/Off
User Name	Enter your user name. (1~32 characters)
Authentication Protocol	MD5/SHA
Invalid URL	Enter your invalid URL address. (8~32 characters)
Privacy Protocol	DES/AES-128
Password	Enter your password. (8~32 characters)
Context Name	Enter your context name.
Certificate Management	Allow you to upload certificate or enter password to access a specific server.
Ethernet Speed	Choice: 10M, 100M, 1G

Service Registration: Choose the service items you wish to display on the touch screen.

Item	Description
Name	Check to enable Copy, Storage Copy, Scan, Reprint Saved Job, ID Card Copy, Fax, E-mail, or CSA6 respectively on the touch screen.
Function Lock	Disable a designated unction.
Туре	Standard Service.

User Authentication: Used to setup user account and specify user privileges.

Item	Description
Enablement	Enable/ disable the account and over quota function.
	「Enable User Authentication」 allows the administrator to specify user's privileges and limitation to use a certain function.
	Fenable over quota allows a user to complete the job which happens to exceed his or her limitation.
Users	Used to enter a user name, edit a password, or choose a user's role (System Administrator/ Account Administrator/ User).
	System Administrator: The default login name and password for a system administrator are both admin. A system administrator can modify all settings on the product.
	Account Administrator: An account administrator cannot disable Account function, set up Over Quota, specify User Role, and edit other people's user names/passwords. All settings in Tools of Machine Status can not be set up, either.
	User: A user can edit only his or her user names/passwords. All settings in Tools of Machine Status can not be set up.
	Click Add New User to specify the usage limits for print, and copy.

Report and Reset: Used to generate a usage report and reset all usage data to zero or default.

Item	Description
Generate Report	Generate a usage report in .csv format.
Reset Usage Data	Reset all usage data to be zero.
Reset to Default	Reset all usage data to default.

Cloning: Used to create a .bin file for current configurations of the product and to apply the same configurations to other products. All products must have the same model name and version of firmware for the .bin file to be accepted.

The firmware version is located on the Status tab, under Device Description.

Item	Description
Create Clone File	To clone all the features, click the Clone button.
	To clone individual feature, check the desired feature respectively, and then click the Clone button.
	These features include: Device Settings, Network Settings, Timeout Setting, Service Registration, Service Settings, Account, and FTP / SMB.
Install Clone File	Choose a clone file from your computer, and then click the "Install" button.
	When you start installing a clone file, all the network functions including web pages on the product are temporarily unavailable.

Device Settings: Specify basic settings of the device.

Item	Description
Time Zone	Used to select your time zone.
A+ Manager	If desired, enter a specified server's IP address to send a log file for a quick troubleshooting.
Reset Fuser Count	Use to reset fuser count after fuser replacement.
Send Meter	Allow users to convert the usage report into a meter.CSV file and send it to the administrator by email.
NTP Server	If desired, enter the IP address of your NTP server.
USB Control	USB Host: Enable or disable the port of USB Host. USB Device: Enable or disable the port of USB Device.

FW Update: Used to download the latest firmware to the MFP.

SysLog: Select [Enable] to save the system log files to your specified server for a quick troubleshooting.

App Plug-In: Select [Enable] to install a third-party application on the product. The third-party plug-in app allows users to complete the scan tasks according to its own workflow. For more detailed information, please contact the manufacturer first.


How to set user authentication

The product allows administrator to set user authentication by login either with password or ID card. To set the user authentication, please follow these steps.

- (1) Enable [User Authentication]
- (2) Login with admin
- (3) Change Your Password or Add the pin no. of your ID card
- (4) Add a New User
- (5) Login with New User

(1) Enable [User Authentication]

Enable the [User authentication] function by taping the [More Setting]
 option on the Home Screen and then choose Tools>User Authentication and
 choose [Enable].



2. Tap [Back] to return to the home screen.

(2) Login with admin

- 1. Follow steps # 1 \sim 6 in the previous section Enabling user authentication.
- 2. Click [Login] on the home screen. A login screen will be displayed.






3. Login with the factory's default user name and password – admin. For the first time login, you must enter [admin] to be your user name and password. Click to finish. After successful login, the new user name [admin] will be shown in the upper left corner as indicated.



(3) Change Admin's Password or Add the pin no. of your ID card

Tap the [admin] icon on the upper-left corner of the home screen. An [Account Details] screen will be displayed.



2. Tap the [Edit Account] button. A [New Password] dialog box will be displayed. Enter your new password. If required, enter your PIN number and tap to complete. You may enter your PIN number by placing your ID card near the sensor zone to read your ID card. If successful, the numbers will be indicated as shown. Tap to complete.



Note:

- 1. If you wish to keep your previous password, simply leave the password blank without entering any password.
- 2. Our MiFare Card reader supports the following specifications:
- ISO18092(NFCIP-1)
- ISO14443A, B
- ISO15693
- FeliCa
- 3. Tap [Back] to return to the home screen.
- 4. When the following Login screen appears, place your ID card near the sensor zone of the operator's panel. If successful, you will hear a bee sound.




(4) Create a new user

1. Open your browser and type the product's IP address in the URL address and then press Enter. The product's embedded web page appears as shown below.




2. Click [Login] on the upper-right corner and then enter the administrator's user name [admin] and password to login.




Click [Properties], and select [User Authentication] > [Account Manager] > [Add New User] in succession.



4. Enter new user name (for example, bess 2) and select user role (for example, user) and then click [Apply] to complete. If successful, a new user [bess 2] will be added in the user list.





According to the privileges, there are three types of user roles:

(1) System Administrator:	Have all privileges of managing the web page and touch screen.
(2) Account Administrator:	In the [Properties] page, only the information of [Account] can be seen; the [Settings] option in the touch screen cannot be modified.
(3) User:	In the [Properties] page, only the information of [My Account] can be seen; the [Settings] option in the touch screen cannot be modified.

(5) Login with a new user on the touch panel

On the touch panel, log in with new user name and password. Note password is the same with user name as illustrated in below.




Important: If you want to change your password, you can change it only through the touch panel.


Using the Administrative Mode

The Administrative Mode allows administrator to set more settings for the machine.

To switch to administrative mode,

1. Tap [More Settings] on the center of the main screen and then choose [View Machine Status]. This will prompt the [Machine Status] page.





2. Press [Tools] to prompt the [Tools] page. Choose [Device Settings] and then double click on [Feature] to prompt the [Administrative Mode] page.





Options in the Administrative Mode:


Items	Description /Selection
Power Saving Off	Turn off the power saving (energy saving) mode.
	Factory default settings: ON
Format Storage	Format the SD card in the device. The SD card saves the
	current jobs including storage print, storage copy, and
	scan to device on the machine.
	Format the SD card when there is no job waiting or the
	function can not be executed. After pressing this option,
	a confirmation dialog box will be prompted. Choose Yes
	to continue. After the formatting is finished, you need to
	reboot the system to complete.
Reset Admin.	Press to reset the password of the Administrator (if this is
Password	enabled) back to default – [admin].
Reset Counter	Reset the counter of consumable components including
	Fuser and ADF pad after replacement. If the counter has
	not been reset, the [Fuser near end] or [Fuser life
	end] warning message will be continuously displayed.
	Choice: Fuser/ADF Pad
	Note you need to enter the S/N of the new fuser while
	reset the fuser counter.
Save Temporary	Set to store the temporary jobs from PC Print, Webpage
Print Storage	print.
	Choice: On/Off
	On: The temporary print jobs from PC, or Webpage will
	be stored after turning off and then on the machine.
	Off: The temporary print jobs from PC, or Webpage will
	be deleted after turning off and then on the machine.
	Factory default setting: On

5. Configuring the Printer's Features

Displaying the Printer Driver Properties Dialog Box

To display the Printer Driver Properties dialog box,

- Click Start on the system tray and choose Printers and Faxes.
- 2. Right-click the product's printer name and choose **Printer Preferences**.
- 3. The following **Printing Preferences** dialog box will be displayed.




Configuring Printer Driver Settings

The Printing Preferences dialog box consists of the Basic tab, the Paper tab, the Layout tab, the Watermark tab, the Duplex tab, the Storage Print tab, the Authentication tab, and the More tab. The contents of each tab will be explained in the following sections.


The Basic Tab

The Basic tab contains settings for Orientation, Copies, Effect, Density, Toner Save, and Invert.




Orientation

Choose your orientation. Choice: Portrait, Landscape



Copies

Choose the number of copies to be printed. You can enter up to 999.




Effect

Resolution:	Choice: *600 dpi, 1200 dpi HQ, 2400 dpi Standard, 2400 dpi Fine *Option varies due to your printer mode. 600 dpi: for normal document. 1200 dpi/2400 dpi: Choose 1200 dpi/2400 dpi Standard/2400 dpi Fine if you wish to enhance the print quality.	
Print Settings:	Normal: **Picture Mode: *Text as Black: **Enhance Text: ** These featur GDI printer lange	Normal mode. Suitable for your document containing pictures. Print color text in pure black. Make the text bold. es are only available for juage.
Density:	Click to lighten or Density level (1~	darken your document. 7). Default: 3
Toner Save:	Allows you to print your document using the toner saving mode.	
Invert:	Invert makes each image pixel inverted to its complementary color. For example: the original black text on white background becomes white text on black background.	

^{*} Factory default setting

The Paper Tab

The Paper tab contains settings for Original Size, Tray, and Media Type.




Paper


Original Size:	Choose the size of paper loaded in the designated tray. Choice: *A4, A5, A6, B5 (JIS), B6 (JIS), Legal, Legal 13, Oficio, Letter, User Define Click [Add/New] to create up to 20 sets of custom sizes.
Tray:	Choice: Auto Selection, Manual Tray, Main Tray, Tray 2 Auto Selection means automatically select available paper tray. (Priority: 1. Tray 1; 2. Manual tray; 3. Tray 2) Manual Tray First means automatically select available paper tray. (Priority: 1. Manual Tray; 2. Tray 1; 3. Tray 2)
Media Type:	Choose the type of media to be used for printing. Choice: Any Type, Plain, Thick, Thin, Laser Printer Any Type: Any type of media can be printed.
Fixed paper size:	Check to specify all output paper to the fixed paper size based on the Original Size option.


The Layout Tab

The Layout tab contains settings for N-up, and Output Paper Size.



N-up






Output Paper Size

User Define Scale	You can reduce or enlarge your printed image using the Slider Bar. Scaling rate: 25%~400%
Fit to Paper	Output the full page of the selected original including the four margins.
Center	Print your image in the center of the output paper.

The Watermark Tab

The Watermark tab allows you to add some text or image (such as CONFIDENTIAL, IMPORTANT, DRAFT, etc) for your document.




First Page only	Check to print watermark only on the first page. Clear the check box will print watermark on all pages.
Text	Choose and click New/Add to add new watermark text. Click the Edit button to change or the Remove button to delete.
Image	Choose and click New/Add to add watermark image. Click the Edit button to change or the Remove button to delete. You can choose your image in file format such as BMP, TIFF, or JPEG.

Adding a new watermark text

To add a new watermark text,

 Choose Text and then click the Add/New button. The following Watermark dialog box appears.



Name	Name your watermark text. This name will be shown in the Watermark text list.
String	Enter your watermark text, such as confidential, important, and so on.
Typeface	Choose your font type for your watermark text.
Style	Choose the style of your watermark text. Choice: Regular, Bold, Italic, Bold Italic.
Position	Choose the position of your watermark text. Choice: Center, Tile.

Angle	Specify the angle of the watermark text from 0° to 360°
Size	Specify the size of your watermark text from 1 to 288.
Shading	Specify a relative density for the watermark text. Choice: Lightest, Light, Medium, Dark, Darkest.

2. Click the **OK** button to save the settings. If the new watermark text is created successfully, the watermark name will be shown in the Text list.

Editing a current watermark text

To edit a current watermark text,

- 1. Choose the watermark name that you wish to edit from the Text list.
- 2. Click the Edit button. The Watermark Edit dialog box appears.
- **3.** Change your settings for the selected watermark text and choose **OK** to complete.

Removing a current watermark text


To remove a current watermark text,

- 1. Choose the watermark name that you wish to remove from the Text list.
- 2. Click the **Remove** button. The watermark text will be removed.

Adding a new watermark image

To add a new watermark image,

 Choose Image and then click the Add/New button. The following Watermark dialog box appears.



Name	Name your watermark image. This name will be shown in the Watermark image list.
File	Click the Browse button to locate your watermark image.
Size	Specify the size of your watermark image. Choice: Actural Size, Fit to Page, Tile.
Position	Choose the position of your watermark image. Choice: Top-Left, Top-Center, Top-Right, Center, Center-Left, Center-Right, Bottom-Center, Bottom-Right, Bottom-Left.
Shading	Specify a relative density for the watermark text. Choice: Lightest, Light, Medium, Dark, Darkest.

2. Click the **OK** button to save the settings. If the new watermark image is created successfully, the watermark name will be shown in the Image list.

Editing a current watermark image

To edit a current watermark image,

- 1. Choose the watermark name that you wish to edit from the Image list.
- 2. Click the Edit button. The Watermark Edit dialog box appears.
- **3.** Change your settings for the selected watermark image and choose **OK** to complete.


Removing a current watermark Image

To remove a current watermark image,


- 1. Choose the watermark name that you wish to remove from the Image list.
- 2. Click the **Remove** button. The watermark image will be removed.

The Duplex Tab

The Duplex tab allows you to print your document on two sides of the paper.



When using **Two-Sided** printing, you can select whether to bind copies on the long-edge or short-edge.



Booklet

Booklet (No Reduction)

The feature allows you to print your documents as a booklet. Choose <code>[Booklet]</code>, the contents of the file will be automatically reduced to fit your output paper. Choose <code>[Booklet (No Reduction)]</code>, the contents of the file will be kept the same with the output paper.


For example, to print an A4-sized document to an A4-sized booklet, choose \[\text{Booklet} \] (No Reduction) \], the product will automatically choose output paper to be A3 size to keep the original size.

On the other hand, if you wish to print an A4-sized document to an A5-sized booklet, choose 「Booklet」, the contents of the document will be reduced to fit your output paper.

Booklet Layout:

Portrait Orientation


Left Binding/Right Binding: Select Left Binding or Right Binding for your booklet printing.



Landscape Orientation

Top Binding/Bottom Binding: Select Top Binding or Bottom Binding for your booklet printing.

A booklet is a document which is printed in a way that when you fold the printed pages in the middle and staple them, the pages will be in correct order as a book would be.




Booklet

Booklet (No Reduction)

Number of sheet to divide/All Pages at Once:

Check [Number of sheet to divide] to separate your pages into sets and press the Arrow key to enter number of pages.

All Pages at Once: Check [All Pages at Once] to print all pages in one set.




^{*} Booklet: The feature is only available for PCL and GDI printer language.

The Job Build Tab

The Job Build tab allows you to combine multiple types of files into a cohesive single file and to be printed together from your PC. (The feature is only available for GDI printer driver.)

For some cases, it is time-consuming and labor-intense to manually combine and print certain pages from multiple documents such as a picture file from an image editing software and a text document from a word-processing software. Enabling the Job Build function allows you to efficiently do this in just a single file.



Enable Job Build	Check to enable the Job Build function.	
	Each time you perform printing your file, a print job for the file is temporarily stored in your PC memory.	
Print	Click to print the single combined file for all of your print jobs stored in your PC.	
Erase	Click to erase all of your print jobs temporarily stored in your PC	

The More Tab

On the **More** tab, a **Wait Timeout** option is provided to set the amount of time the MFP waits for data to come from computer during a job. If the data stream pauses for longer than the specified number of seconds, the job is cancelled.


Permitted timeout values: 60~1800 seconds, default timeout values: 300 seconds

Clean Mode: If unwanted image appears in the blank space, you can check "Clean Mode" to improve the printing quality.

Uniform Mode: If uneven shading appears in the image area, you can check "Uniform Mode" to improve the printing quality.

Defaults: Press to change all setting values back to factory default.

Defaults: Press to resume all settings to factory default.



Scanning From Your Computer

After installing the scanner driver and connecting the USB cable to your computer, the product can be used as a fine scanner. You can use various scanning features to modify your scanned image.

System Requirements

CPU: Intel[®] Core[™] 2 Duo or higher

Memory: 32 bit: 1 GB

64 bit: 2 GB

Optical Drive: DVD-ROM Drive

USB Port: USB port 2.0 (compatible with USB 3.0)

Compatible Microsoft Windows 10 (32-bit/64-bit),
Operating Windows 8.x (32-bit/64-bit), Windows 7

System: (32-bit/64-bit)

Operating Steps

- 4. Start your image editing application.
- 5. Pull down the File menu and choose Select Source.

If the **Select Source** command is not available on the **File** menu, see your application's user's guide to determine how the TWAIN link is used. A dialog box with a list of scanning sources appears.


6. Select the model name of your product.

You need to select the source only once, unless you want o choose another scanner.

Place the document FACE DOWN on the flatbed glass.


8. Pull down the File menu and choose Acquire.

A dialog box containing scanning features appears.



- **9.** Select the scanning method you want to use on the **Scan Source** drop-down menu.
- **10.** Select the mode you want to use for your scans on the **I mage Mode** drop-down menu.
- 11. Select a scanning resolution on the **Resolution** drop-down menu.
- **12.** Select the setting for the scanning features (e.g. Brightness, Contrast, Original Layout, etc.) that you want to use.
- 13. Click on **Preview** or **Scan** to preview or scan you documents.

A Glance of the User Interface



1. Mode	Choice: Black & White, 8-Bit Gray, 24-Bit Color
2. Resolution	Choice: 50, 72, 100, 144, 150, 200, 300, 600 (dpi).
3. Brightness	Adjust the brightness level from -100 to +100.
4. Contrast	Adjust the contrast level from -100 to +100.
5. Scan Source	Choice: Auto, ADF, Flatbed
6. Original Layout	Choice: Simplex, Duplex
7. Preview Window	Used to display the scanned image in low resolution.
8. Preview	Resize your scanned area.

Using The Image Tab

Selecting A Proper I mage Mode

- → Black & White: Choose B&W if your original contains only B&W text, pencil or ink sketch.
- **8-bit Gray:** 8-bit Gray images contain actual shades of gray.
- **24-bit Color:** Choose 24-bit Color if you wish to scan a color image.







B&W Gray Color

Dither (Simulate Grays):

This is the process of converting a grayscale or color image to a bi-tonal image. There are several different methods of performing this conversion. **Options: None**, **Halftone 1~5**, **Diffusion**. Default setting is none.

Halftone:

In addition to the black and white display, halftone can present a somehow gray shade of image by using different size of dots. Halftone image looks like the picture you have seen in the newspaper. **Options include Halftone 1, Halftone 2, Halftone 3, Halftone 4, Halftone 5.**

Diffusion:

Diffusion is a type of halftone. Diffusion gives good image texture and makes text in images more readable than halftone.



Error Diffusion Image



Halftone Image

Determining Proper Resolution

A proper resolution reproduces a clear image with good details. The resolution is measured by dots per inch (dpi). The resolution is measured in pixels per inch (ppi) (sometimes referred to as dots per inch or dpi). Higher resolutions result in more detail in the scan, slower scanning and in general, greater file sizes. For example, an A4 size color image scanned at 300 dpi with color mode consumes approximately 25 MB of disk space. When OCR (Optical Character Recognition) is to be performed on a scan, 300dpi should be used for most languages except Asian languages. For Asian languages, 400 dpi is recommended.

Choose a resolution value from the drop down list. The default value is 200 dpi. Available resolutions are 75, 100, 150, 200,300, 400 and 600.



Resolution: 75 dpi



Resolution: 150 dpi


Adjusting Brightness And Contrast

Brightness

Adjusts the lightness or darkness of an image. The higher the value, the brighter the image. Drag the slider to the right or left to increase or decrease the brightness. The range is from -100 to +100. The default value is 0.

Contrast

Adjusts the range between the darkest and the lightest shades in the image. The higher the contrast, the bigger the different grayscale. Drag the slider to the right or left to increase or decrease the contrast. The range is from –100 to +100. The default value is 0.



Brightness: -50



Contrast: -50




Brightness: 0 (Normal)



Contrast: 0 (Normal)



Brightness: +50



Contrast: +50

Choosing Scan Source

Choice:

Flatbed: Select this setting if you need to scan a single page from the flatbed.

*Auto, ADF—Use this setting if you are using the automatic document feeder (ADF) to scan documents at a time.

Preview Window

Click the Preview button to get a scanned image in a low resolution. You can use this window to select your scan area.

Using The Paper Tab

Selecting Your Scan Size

- Automatic: Choose Automatic from the Cropping drop-down list on the Paper tab. The scanner will capture an image according to the actual size of your original.
- **Deskew:** Use this option to let the scanner automatically determine if a page is skewed, and then straighten the image. This option will be available only when **Automatic Cropping** is selected.
- Custom: Choose Custom from the Cropping drop-down list on the Paper tab. This feature allows you to define the area or zone to be scanned. If you select this option, you can enter the x and y offset values, width and length to redefine your scanned area. The Display window will show the size as you change the values.

Choose your scan size from the **Scan Size** drop-down list.

None		
US Letter- 8.5"x 11"		
US Legal – 8.5″ x 14″		
ISO A4 – 21 x 29.7 cm		
ISO A5 – 14.8 x 21 cm		
ISO A6 – 10.5 x 14.8cm		
ISO A7 – 7.4 x 10/5 cm		
ISO B5 – 17.6 x 25 cm		
ISO B6 – 12.5 x 17.6 cm		
ISO B7 – 8.8 x 12.5 cm		
JIS B5 – 18.2 x 25.7 cm		
JIS B6 – 12.8 x 18.2 cm		
JIS B7 – 9.1 x 12.8 cm		
Scanner Maximum		
Long Page (<118")		

The following options are only available when **Custom** is selected.

- → X-Offset the distance from the left end of the scanner to the left edge of the scanning area.
- **Y-Offset** the position from the top end of the document to the top end of the scanning area.
- → Width the width of the scanning area.
- → Length the length of the scanning area.
- **Center** automatically calculates the x-offset for center-fed feeding based upon document size selected.

Unit: Define your measurement system. **Inches, Millimeters,** and **Pixels** are available.

Using The More Tab

Enabling Multi-Feed detection

The multi-feed detection feature allows you to detect overlapped documents that go through the scanner. Multi-Feed usually occurs due to stapled documents, adhesives on documents, or electro-statically charged documents.

- Additional Length Detection: Additional Length Detection allows you to define
 the length of document being multi-fed. This value indicates the additional
 length exceeding your scan area. A value of 0 indicates no additional length
 detection. For the specified measuring unit, please refer to the Unit drop-down
 list box on the Paper tab.
- **Ultrasonic Detection**: Ultrasonic Detection allows you to set overlapped document by detecting paper thickness between documents. Note: The availability of this feature varied depending on scanner type.

Once multi-feed is detected, the scanning operation will not be stopped. Instead, a multi-feed detection message will be displayed.

Using The Color Dropout Tab

Color Dropout tab allows you to filter out a color channel (red, green, or blue). For example, if you are scanning a document with a red watermark, you can choose to filter out the red channel so the scanned image just shows the text and not the red watermark. Removing colors from the scan might reduce the scan file size and improve optical character recognition (OCR) result.



Note:

Color dropout only applies to gray scans and to black and white scans.



After removing the G channel



After removing the R channel

Using The Information Tab

The **Information** Tab allows you to view all the information about the scanner including serial number, pad count, roller count, and firmware version. These are helpful information when you report a problem to the service personnel.


7. Maintaining the Product

The following table shows the parts and their suggested cleaning cycle.

Parts	STANDARD CLEANING CYCLE
Glass Platen	When the scanned image is shown with abnormal lines
Document Glass	Visual Check
Auto Document Feeder	When feeding is not smooth
Snap-in Pad Module	When paper feeding is not smooth
EP Charger	10,000 sheets
Paper Tray Roller	5,000 prints
Paper Path	20,000 prints

Removing the Abnormal Line On an Image

When the scanned image is shown with abnormal lines on it, clean the rectangular glass area on the left of the document glass as indicated below with a clean lint-free cloth.




Cleaning the Document Glass

The product is designed to be almost maintenance-free. However, it still needs to be cleaned occasionally to ensure optimum image quality and performance.

To clean the glass,

- 1. Open the document cover as shown below.
- 2. Dip a soft clean cloth with isopropyl alcohol (95%).
- **3.** Gently wipe the document glass to remove the dust or any toner particles.
- **4.** Close the document cover. Your machine is now ready to use.




- 1. Document Cover
- 2. Document Glass

Cleaning the ADF

From time to time the feeding rollers may become contaminated with ink, toner particles or paper dust. In this case the product may not feed documents smoothly. If this occurs please follow the cleaning procedures to return your machine to its original state.

- 1. Moisten a clean lint-free cloth with isopropyl alcohol (95%).
- 2. Gently open the ADF front cover. Wipe the feeding rollers from side to side. Rotate the rollers forward with your finger and repeat the above cleaning procedures until the rollers are clean. Be careful not to snag or damage the pick springs.
- 3. Wipe the rubber part of the ADF snap-in pad.
- **4.** Close the ADF unit. Your machine is now ready to use.





Feeding Roller


Cleaning the EP Charger

After copying about 10,000 pages, it is recommended to clean the developing unit. Follow these steps to clean the charger.

1. Open the Side Door by pulling the handle as shown.




2. Remove the Drum Unit.





3. Pull out the charger to the end and then back to its original position.



4. Repeat step 3 for three times. Make sure the charger is back to its original position. Otherwise, there is trouble to install the Drum Unit back to the machine.

Cleaning the Paper Tray Rollers

If the paper tray rollers are is dirty, paper powder is attached to it, or after 5,000 prints or copies, paper may not be fed properly or paper jam. In this case, clean the paper tray rollers.

The Cleaning Steps:

1. Move the paper tray to reveal the rollers.



- 2. Slightly wet a soft and lint-free cloth with isopropyl alcohol (95%).
- **3.** Wipe the surface of the pickup roller, feeding roller, and the reverse roller until they are thoroughly cleaned.




Wipe the surface of the pickuproller from left to right and then from right to left. **4.** Open the Roller cover as illustrated and wipe the surface of the Feeding Roller from left to right and then from right to left.






5. As shown in below, The Reverse Roller is located at the other side of the Feeding Roller. Hold two ends of the Reverse Roller Cover and remove the cover.





6. Wipe and rotate the surface of the roller to make sure they are thoroughly cleaned.



7. Hold two ends of the Reverse Roller Cover to install the Reverse Roller Cover back to the machine.



Important!

Make sure to clean the rollers with a soft and lint-free cloth in case the fibers may remain on the surface of the rollers.


Cleaning the Manual Tray Roller

If the paper tray rollers are is dirty, paper powder is attached to it, or after 5,000 prints or copies, paper may not be fed properly or paper jam. In this case, clean the paper tray rollers.


- 1. Slightly wet a soft and lint-free cloth with isopropyl alcohol (95%).
- 2. Pull down the manual tray as shown.



3. Push the roller internally and remove the roller.



4. Wipe the surface of the roller from left to right and then right to left until the roller is completely cleaned.




Installation Step

Install the left end of the roller to the left hole and then the right end to the right hole. Note the notch on the right end has to be aligned with the tab as indicated in below.







Cleaning the Toner Cartridge


If there is toner leaking on the machine, slightly wet a soft and lint-free cloth with isopropyl alcohol (95%) and wipe the toner off in case you may touch the toner which is harmful to human health.

Remove the Toner Cartridge

1. Open the front cover by pulling the handle as shown.



2. Use your right hand to unlock the toner cartridge by pressing down the Flock switch and at the same time use your left hand to hold the handle of the toner cartridge and pull it out of the printer.



Lock Switch


3. Slightly wet a soft and lint-free cloth with isopropyl alcohol (95%) and wipe the toner off the cartridge.



Toner Leakage

Install the Toner Cartridge

1. Hold the handle of the toner cartridge and insert it to its proper position as shown.



- 2. Push the Toner Cartridge to the end. A "click" sound means the installation was successful.
- 3. Close the Front Cover.



Important!

- Be careful not to spill toner from the waste toner can. Do not inhale toner or allow toner to get into your eyes.
- If toner gets on your clothing or other fabric, wipe off the toner with a
 dry cloth. Wash the items in cold water and air dry. Hot water causes
 the toner to penetrate the fibers of the clothes.

Cleaning the Paper Path

During the printing process, paper powder, toner, and dust particles can accumulate inside the product. Over time, this buildup can cause print quality issues such as toner specks, smears, or dust particles on the edge of paper. If you are experiencing these problems, clean the paper path. To keep optimal printing quality, the paper path needs to be cleaned after approximately every 20,000 prints. However, the guideline might vary based on the type of paper you are printing (for example, visible paper powder on paper or paper has not been cut evenly).




To clean the paper path, follow these steps:

- 1. Turn off the product, disconnect the power cord, and then wait for the product to cool.
- Open the side door.




Pull down the lock latches on the top of the fuser to open the Fuser Cover.





4. Gently wipe the surface of the rollers and paper path as illustrated with a soft, dry cloth that is lightly dampened with isopropyl alcohol.



8. Replacing the Consumables

The following table shows the parts and their suggested cleaning cycle. The replacement cycles above are rough guidelines for the case using A4/Letter sized woodfree or wood containing paper of 70 g/m² (20 lbs) in weight. These cycles vary according to the type of paper used and how frequently the product is used and cleaned. Please replenish the consumables from the store where you purchased the product or a Katusha authorized service provider.

NAME OF COMPONENT	RECOMMENDED REPLACEMENT CYCLE
Snap-in Pad Module	50K sheets (5% Coverage)
4 1	
ADF Roller	200K sheets
Waste Toner Can	
	When waste toner is full
Toner Cartridge	
	20K sheets (5% Coverage)
Paper Tray Roller	
	200K sheets
Manual Tray Roller	50K sheets
Drum Unit	
	150K sheets



Replacing the Snap-in Pad Module

After scanning about 50,000 sheets through the ADF, the pad may be worn out and you may experience problems with document feeding. In this case, it is highly recommended to replace the pad module with a new one. For ordering the pad module, please consult your nearest dealer and follow the procedure below to replace it.

After the replacement has been finished, be sure to reset ADF pad count. To reset ADF pad count, tap [More Settings] on the upper-right corner of the main screen, and then tap [Show Machine Status]>[Tools]>[Device Settings] and then double click [Feature], the [Administrative Mode] will be displayed. Choose [Reset Counter] and then [ADF Pad] to reset the ADF pad count.

Disassembling Procedure

- Gently open the ADF front cover.
- 2. Remove the ADF snap-in pad module by pressing the lock upward.





Assembling Procedure

- 1. Gently open the ADF front cover to the left.
- 2. Remove the ADF pad module from the box.
- **3.** Place it into the holes until it snaps into place.

Replacing the ADF Roller


After scanning approximately 200,000 pages through the ADF, the ADF roller may be worn out and you may experience problems with document feeding. In this case, it is highly recommended to replace the roller with a new one. Please follow these steps to replace and install the ADF roller.

Disassembling Procedure

1. Open the ADF front cover.



2. Move the clamp at the right end **UPWARD** to detach the ADF roller.




3. Detach the left end of the ADF Roller from its slot to remove it.



Assembling Procedure

1. Insert the left end of the ADF roller to its slot (\mathbb{Q}) , place the right clamp at its slot and move it DOWNWARD (\mathbb{Q}) . If it is properly installed, you will hear a clear snap-in sound.



2. Close the ADF front cover.

Replacing the Waste Toner Can

Follow these steps to replace the waste toner can:



Important!

- DO NOT reuse the waste toner can.
- DO NOT put the waste toner can into a fire. It could explode.
- Be careful not to spill the toner. DO NOT inhale or allow it to get into your eyes.

Removing the Waste Toner Can


1. Open the front door by pulling the handle as shown.



2. Squeeze the top of the waste toner can and remvoe it from the machine as shown.



3. Insert the cap of the waste toner can and seal it with tape to let the cap firmly secured.



4. Place the waste toner can into its original plastic bag to ensure the toner will not spill.



Important!

- Be careful not to spill the toner. DO NOT inhale or allow it to get into your eyes.
- As the waste toner may be hazardous to both environment and human health, please place the waste toner can into a plastic bag and the original toner cartridge box, and then deliver to our authorized distributors or service personnel.




Reinstalling the Waste Toner Can

1. Open the cap.



2. Hold the handle of the waste toner can and insert it to its original place. A "click" sound means the installation was successful.



3. Close the Front Cover as shown.



Replacing Toner Cartridge

Follow these steps to replace the toner cartridge:



Important!


To maintain the EP Charger in good condition, please clean the EP charger each time after replacing the toner cartridge. Refer to the following section, Cleaning the EP Charger – on how to clean the charger.

Removing the Toner Cartridge

1. Open the front cover by pulling the handle as shown.



2. Use your right hand to unlock the toner cartridge by pressing down the 「lock switch」 and at the same time use your left hand to hold the handle of the toner cartridge and pull it out of the printer.



Lock Switch

Installing the Toner Cartridge

1. Remove the package cushion and tapes on the toner cartridge. Tilt the toner cartridge up and down and then right and left 10 times to distribute the toner evenly inside the cartridge.



2. Hold the handle of the toner cartridge and insert it to its proper position as shown.



3. Close the front cover.



Important!

- Be careful not to spill the toner. DO NOT inhale or allow it to get into your eyes.
- If toner gets on your clothing or other fabric, wipe off the toner with a dry cloth. Wash the items in cold water and air dry. Hot water causes the toner to penetrate the fibers of the clothes.
- Do not dispose of the toner cartridge. Put the used toner cartridge into the bundled plastic bag, and then return it to a dealer or service representative. The latter recycles or deals with the collected toner cartridges in accordance with the relevant regulations.



Replacing the Paper Tray Rollers

After approximately 200,000 prints or copies, the roller may be worn out and you may have difficult in feeding paper properly. In this case, please replace the roller with a new one and follow the steps in below to complete the replacement.

The removing steps

1. Lift the front side of the paper tray, and then pull the paper tray out of the product. Locate the feeding roller as indicated.




2. Press the front end of the Roller Cover inward to open the cover. Lift the Feeding Roller upward to remove it.





3. Press two ends of the Reverse Roller inward to remove the Reverse Roller.



The reinstallation steps

1. Insert the Feeding Roller vertically to its original slot.




2. Close the Roller Cover as shown.





3. Hold two ends of the Reverse Roller Assembly and insert it to its original slot as shown.





Replacing the manual tray rollers and pad

After approximately 200,000 prints or copies, the roller may be worn out and you may have difficult in feeding paper properly. In this case, please replace the roller with a new one and follow the steps in below to complete the replacement.

The removing procedure

1. Pull down the manual tray.



4. Press down the tab at the end of the roller as shown.







The reinstallation procedure

Install the left end of the roller to the left hole and then the right end to the right hole. Note the notch on the right end has to be aligned with the tab as indicated in below.








Replacing the Drum Unit

The Removing Procedure

1. Turn off the power and disconnect the power cable. Wait for 10 minutes to cool down the machine. Pull down the Handle to open the Side Door as shown.



2. Hold the handle of the Drum Unit and remove it from the machine as shown.



Reassembling Steps:

1. Remove the plastic bag, tape, and then press down the Release Arms to pull out the protective film.



2. Pull up the Release Arms on both ends.







Important!

- To avoid damage the drum unit, please install it after removing the protection cushions. Do not expose the drum unit to light.
- Deliver the old drum unit to an approved recycling center.
- **3.** Holding the handle of the Drum Unit. Make sure the red arrows on both sides of the drum unit are aligned with the red arrows on the machine as indicated.






4. Insert the Drum Unit horizontally into the slot along the top of the support frame on both sides, as shown in the figure.



If install correctly, the arrows (triangles) will be completely exposed as indicated.



5. Close the Side Door and then the Manual Tray as shown.



Replacing the Developing Unit


Follow these steps to replace the Developing Unit:

The Removing Steps:


- 1. Turn off the machine until it has been cooled down.
- 2. Open the Side Door by pulling down the handle as shown.



3. Hold the handle of the Drum unit and pull it out.



4. Open the paper guide latch in a clockwise direction **1**, and then push it up **2** to fix the paper guide.



5. Hold the handles of the developing unit and gently remove it from the machine as shown.








Notice to return the used developing unit!

Insert the protective film from the original package into the roller of the developing unit, and stick the tape ①, insert the pin into the reserved hole ②, insert the sponge ② to the toner exit hole, finally stick the tape ③ on the sponge to avoid vibration during transportation, and then put the developing unit into its original plastic bag, foam, and packing box to return to the manufacturer.



Reassembling Steps:


Follow these steps to install the Developing Unit:




Caution!

To prevent damage to the Developing Unit, do not expose it to light for more than a few minutes.

1. Remove the tape \mathbb{Q} , protective film \mathbb{Q} , and the plugs \mathbb{Q} on both sides.



2. Remove the tape in the upper right corner ①, and then remove the instruction card ⑤ and sponge ⑥.





Important!


Do not remove the transparent plastic protective cover on the surface of the developing unit as shown in the figure to avoid abnormal images.



3. Pull the handle down to open the Side Door as shown.




4. Open the paper guide latch in a clockwise direction **1**, and then push it up **2** to fix the paper guide.



5. Open the handle of the developing unit and hold the handle with both hands, as shown in the figure below.




6. Hold the handle with both hands, placing the front end of the developing unit to the top of the rails on both sides. Check if the arrows (triangles) on both sides of the developing unit are aligned with the arrows on the machine as indicated.






7. Gently push the developing unit into the machine along the rails. Make sure the handles are closed and left flat on the surface of the developing unit as shown in below.






Make sure the red arrows (triangles) on both sides are completely exposed.



8. Pull down the latch of the paper guide counterclockwise to restore the latch of the paper guide to its original status.



9. Close the Side Door and then the Manual Tray as shown.



Replacing the Fuser

The Removing Steps




Important:

After the product has been used for a while, please do not touch the inside of the product since the temperature is very high. To replace the fuser, please first turn the machine off and wait until it has been cooled down.



- 1. Turn off the machine and wait until it has been cooled down.
- 2. Open the Side Door by pulling down the handle as shown.



3. Pull down the handles on both sides of the fuser.






4. Pull down the tabs to open the cover.




5. Press the latch of the cover and remove the cover as shown in below.



6. Remove the red cable and then the black cable.






7. Close the fuser cover and then press the blue latch on both sides inwardly as illustrated.



8. Hold the handles on both sides of the fuser and remove the fuser from the machine.





Important!

Do not dispose of the toner cartridge. Stick the cables with tape, put it in the original plastic bag and box, and then return to the authorized dealer or service personnel. The latter will follow Recycling or disposing of the collected fusers according to relevant regulations.



Reinstallation Steps


1. Remove the protective tape of the new fuser.



2. Turn over the fuser to find the serial number (AXXXXXXXXXX). Write it down as it is required to reset the fuser count.



3. Pull down the handles of the fuser and then hold the handles with two hands to install it back to the original place in the machine.



4. Press the latches on both sides outward as illustrated.




5. Pull down the fuser cover.



6. Connect the black cable and then the red cable. Close the cable cover.





7. Close the fuser cover.



8. Pull up the handles on both sides.



9. Close the Side Door and then the Manual Tray as shown.



- **10.** Press the Power button to turn on the machine.
- 11. Reset the fuser count on the product's web page as described in below:
 - 1). Connect the product to a network via an ethernet cable.
 - 2). Open your browser and type the product's IP address on the URL address. Press OK and the product's web page will be displayed.



3). Click [Properties] and then click [Reset Fuser Count]. Enter fuser's serial number and then press [Apply], finally enter the administrator's password to reset the fuser count.



9. Troubleshooting

Monitoring Your Printer Using Printer Status Monitor


The Printer Status Monitor allows you to monitor your printer's status, get information on consumable parts, and alerts you when printer errors occur.

Printer Status Monitor is available when the printer is connected directly to a host computer via the USB port or a network port.

Printer Status Monitor is installed when you install the printer driver as described in the preceding section.

Accessing Printer Status Monitor


Double-click the **Printer Status Monitor** icon on the system tray. The following printer status window appears.



Printer Status Window

Getting Printer Status Details


You can monitor printer status and get information on consumable products using the Printer Status Monitor dialog box.



a Port Name	Port name for the specified printer.
b Progress Bar	The progress bar to access the latest data of the specified printer.
c Text Box	Display the warning message.
h Text Box	Display the notice message.
e Save Errors to CSV	Save error message to a CSV file.
f Delete Errors	Delete all the error messages.
g Enable	Check the box to enable accessing the status of a specified printer.
h Printer	Display connected printers.
i Consumables	Click to show the information of the paper tray and the consumables parts such as Drum(EP), Toner.
j Get Errors Now	Refresh the printer status.

Setting Monitoring Preferences

To make specific monitoring settings, click the Setting tab on the Katusha Status Monitor window.



Language	Displays the language of the window.
Status Alert	
Update Time	Define the interval to refresh the printer error status.
	Choice: 1, 5, 10 (minute), Custom (1 ~ 86400) second
Show pop-up window – warning message	Check the box to automatically show the warning status in a pop-up window on the system tray.
Show pop-up window – notice message	Check the box to automatically show the notice message in a pop-up window on the system tray.

Clearing A Warning or Error Message

If a problem occurs during operation, a warning or error message will display on the LCD panel. In addition, the Error LED will be flashing or solidly lit to indicate a warning or an error status. To solve the problem, please follow the on-screen instruction or the following table for more detailed information.

Warning

Error Codes	Possible Causes	Solution
200030	No toner is installed or detected. Possible cause of failure detection: sensor problem on the toner cartridge.	Please install a cartridge.
200031	Toner has run out.	Replace a new toner cartridge.
200032	Toner that remains is lower than 10%. The machine can still perform printing or copying function yet with poor quality.	(Refer to Chapter 8 Replacing the Consumables)
200033	No waste toner can is installed or detected.	Install waste toner can. (Refer to Chapter 8 Replacing the Consumables)
200034	The waste toner can is full.	Replace an empty waste toner can.
200035	The waste toner can is nearly full.	(Refer to Chapter 8 Replacing the Consumables)
200036	Toner cartridge error. (incorrect S/N)	Replace toner cartridge from the original manufacturer.
200039	Toner cartridge error. (incorrect vendor name)	Replace toner cartridge from the original manufacturer.
200040	Drum unit sensor fails. Since toner will not continue being filled into the drum unit, resulting in less toner in the drum unit, the print quality is getting worse.	Reboot the system ∘
200041	No developing unit	Please install developing unit.

	-	
200042	Developing unit lifetime ends,	Replace developing unit.
200043	Developing unit lifetime near end (less than 10%)	Order developing unit.
200044	Invalid developing unit	Order genuine developing unit from the original manufacturer.
200141	No drum unit	Install drum unit.
200142	Drum unit life exhausted.	Replace drum unit.
200143	Drum unit life near end.(less than 10%)	Replace drum unit.
200144	Invalid drum unit. (incorrect S/N)	Order and replace genuine drum unit from the original manufacturer.
	Invalid fuser. Please use the original fuser from the vendor.	Use the original fuser from the vendor.
201503 201513	Invalid developer unit. Please use the original developer unit from the vendor.	Use the original developer unit from the vendor.
	Invalid drum. Please use the original drum from the vendor.	Use the original drum from the vendor.
201505 201515	Invalid toner cartridge. Please use the original toner cartridge from the vendor.	Use the original toner cartridge from the vendor.
201611	Toner empty: Toner level sensor always off.	Replace toner level sensor.
201619	Fuser life has been exhausted.	Call the service personnel to order
201620	Fuser lifetime near end (less than 10%.)	and replace the fuser. (Refer to Chapter 8 <u>Replacing the</u> <u>Consumables</u>)

System Error Codes

Error Codes	Possible Causes	Solution
200000	Multi-fed paper happens.	Open the Side Door, clear papers, and adjust paper size and orientation. Possible causes: 1. The paper length in a paper tray is greater than the specified paper length for printing. 2. If the problem persists, call the service personnel to check the pick up roller and spare sensor.
200050	Side door is open.	Close side cover.
200051	Front cover is open.	Close the front cover.
200052	Tray 2 cover is open.	Close tray 2 cover.
200053	Tray 3 cover is open.	Close tray 3 cover.
200060	Tray 1 error.	
200061	Tray 2 error.	
200062	Tray 3 error.	Please open and close tray to recover it.
200063	Tray 4 error.	
200070	Tray 1 is open.	
200071	Tray 2 is open.	Close tray correctly.
200072	Tray 3 is open.	
200073	Tray 4 is open.	
200080	Manual tray paper empty	
200081	Tray 1 paper empty	Any of the printer paper trays has run out.
200082	Tray 2 paper empty	Load paper to the empty tray.
200083	Tray 3 paper empty	Loud paper to the empty tray.
200084	Tray 4 paper empty	
200090	Fan 1 fails (fan for fuser).	When any one of the fans stops or has
200091	Fan 2 fails (fan for main board).	abnormal rotation speed, Call the service personnel to order and replace the fan.
200092	Fan 3 fails (fan for developing unit and drum).	

Scanner Errors

Error Codes	Possible Causes	Solution
000001	The motor is damaged, or runs incorrect steps.	Replace the motor.
000002	Lamp error (ADF)	The ADF CIS lamp is damaged or not lit. Replace the CIS unit.
000113	Scanner module error. An expected error from scanner parts occurs.	Restart MFP or replace scanner parts that fail.
002007	Lamp error (FB)	The flatbed CIS lamp is damaged or not lit. Replace the flatbed CIS unit.
002008	Scanning unit is locked.	Move the lock switch near the glass platen to the used position.
002013	ADF paper jam occurs during scanning process.	 Open ADF cover. Remove the jammed paper. Close ADF cover.
002014	ADF cover opens.	Close ADF cover.
100000	Job full.	When the number of jobs in the Job status reaches 100, this error occurs. Delete some jobs to make the total number of jobs less than 100.
100111	MFP error	When MFP is booted, the scanner and printer engine Initialization fail. Restart MFP.
200001	No Matching Paper	No tray is matched and found during printing or copying process. Replace the wrong paper with correct one in the tray.
300380	Error in printing PDF file over 32MB	Printing/ reprinting a PDF file over 32MB is not allowed. Reduce page number in a PDF file.
600320	Paper empty. Job Abort.	All Trays are empty during printing. Fill paper to the paper trays.
600330	No Matching Paper	No tray is matched and found during printing or copying process. Replace the wrong paper with correct one in the tray.
600340	Paper not support	When printing the Demo page, the paper size in Tray1 is not A4. Place the A4-sized paper into Tray1.

600350	Number of Address book exceeds limitation	The number of contacts in the Address Book exceeds limitation. Delete some contacts in the Address Book to make the total number of contacts less than 500.
600360	Number of groups exceeds limitation	The number of groups in the Address Book exceeds limitation. Delete some groups in the Address Book to make the total number of groups less than 10.
600680	Receiver exceed allowable limit	The number of email receivers added exceeds the upper limit. Delete some email receivers to make the total number of receivers less than 20.

PaperJam Errors

When paperjam error occurs, check the jammed positions indicated in the message to clear the jam error.



Notice when removing the jammed paper:

1. As shown in the figure below, gently remove the paper by holding the edges of paper with both hands according to the arrow direction. Removing jammed paper by force in other directions (up · right · or left) might cause damage to the machine.



2. Check if the paper is complete. If it is incomplete, check if any scraps left inside the machine and remove the scraps. Otherwise, the scraps might affect document feeding and also the print quality.

Paperjam Areas


Area A: Fuser

Area B: Paper Exit on Tray 1

Area C: Duplex Unit

Area D: Side Cover of Tray 2 Area E: Side Cover of Tray 3


Area F: Drum Unit



Error Code	Cause	Solution
200301	Paperjam in the manual tray	 Remove the jammed paper. Fan your paper and reload it to the manual tray. If the problem still persists, clean the Feeding Roller in the manual tray.
	in the manual tray.	

Error Code	Cause	Solution
200302	Paperjam in Tray 1	 Open the Side Door. Check if there is jammed paper in the paper exit of Tray 1 (Area B). If so, remove the paper. Open Tray 1 to remove the jammed paper. Close Tray 1 and the Side Door.
	4. Close Tray 1 and the Side Door. Area B	

Error Code	Cause	Solution
200303	Paperjam in Tray 2	 Open the Side Door of Tray 2 as shown. If there is paper on Area D (paper exit on Tray 2), remove the paper. Open Tray 2 to remove if there is further paper.
		4. Close Tray 2 and the Side Door of Tray 2.



Error Code	Cause	Solution
200306	Paperjam in deskew sensor	 Open the Side Door. If there is paper on Area B (paper exit on Tray 1), remove it. Be careful not to touch the area marked the temperature. Close the Side Door.
Area B		

Error Code	Cause	Solution
200309	Paperjam in paper exit sensor of fuser.	 Turn off the machine and wait for a few minutes to let the operating temperature drop and then open the Side Door. Check Area A (Fuser area) and remove the paper. Pay attention the temperature is high in the fuser. Close the fuser cover and the Side Door.
Area A		

Error Code	Cause	Solution
200317	Paperjam in Tray 3	 Open the Side Door of the 3rd and 4th Tray. If there is paper in the exit of the 3rd Tray, pull the paper out a bit and then remove the paper. If there is no paper in the exit of the 3rd Tray, open Tray 3 to remove paper. Then close Tray 3. Close the Side Door of the 3rd and 4th Tray.
Area E		

Error Code	Cause	Solution
200318	Paperjam in Tray 4	 Open the Side Door of the 3rd and 4th Tray. If there is paper in the exit of the 3rd Tray, pull the paper out a bit and then remove the paper. If there is no paper in the exit of the 3rd Tray, open Tray 3 to remove paper. Then close Tray 3. Close the Side Door of the 3rd and 4th Tray.

Error Code	Cause	Solution
200340	Paperjam in the sensor of Tray 1	 Open the Side Door. If there is paper on Area B (paper exit on Tray 1), remove it. The temperature near the fuser is very high. Do not touch those areas. Close the Side Door.
200341	Paperjam between Tray 1 Sensor and Deskew Sensor	
Area B		

Error Code	Cause	Solution
200342	Paperjam in Tray 2	 Open the Side Door. If there is paper on Paper Exit of Tray 2, pull the paper out and then remove it. If there is no paper on Paper Exit of Tray 2, pull out Tray 2 to remove the paper. Close Side Door and Tray 2.
200343	Paperjam between Tray 1 sensor and Tray 2 sensor	Same as above





Error Code	Cause	Solution
200344	Paperjam in Tray 3 sensor	 Open the Side Door of Tray 2. If there is paper on Area D (paper exit of Tray 2), pull the paper out and remove it. If there is no paper, pull Tray 3 to remove all paper. Close the Side Door of Tray 2.
200345	Paperjam between Tray 2 sensor and Tray 3 sensor	Save as above



Error Code	Cause	Solution
200346	Paperjam in Tray 4 sensor	1. Open the Side Door of Tray 3. 2. If there is paper on Area E (Paper exit of Tray 3), pull the paper out and then remove the paper. 3. If no paper, open Tray 3 to check and remove paper. 4. Close the Side Door of Tray 3 and Tray 3.
200347	Paperjam between Tray 3 sensor and Tray 4 sensor	
Area E		

Error Code	Cause	Solution
200348	Paperjam in the Duplex Unit	 Open the Side Door of the Duplex Unit. If there is paper in area C (Duplex Unit), pull the paper gently and remove the paper. If the problem repeats, please clean the pickup rollers of the Duplex Unit.
of the Duplex Unit. Area C		


Error Code	Cause	Solution
200349	Paperjam in Duplex Sensor and Deskew Sesnor	 Open the Side Door of the Duplex Unit. If there is paper in area B and area C (Tray 1 exit, Duplex unit), remove the paper. Be careful not to touch the places marked high temperature. If the problem persisits, clean the pickup roller of the Duplex Unit.
		Area B Area C

Error Code	Cause	Solution
200351	Paperjam between Fuser Sensor and Duplex Sensor	 Open the Side Door of the Duplex Unit. If there is paper in area C (Duplex Unit), pull the papergently and remove the paper. If the problem repeats, please clean the pickup rollers of the Duplex Unit.
or the Duplex Unit. Area C		

Error Code	Cause	Solution
200352	Paperjam between Deskew Sensor and Drum Jam Sensor	 Open Side Door. Remove the drum unit and check area F. Remove paper. Be careful not to touch the places marked high temperature. Close Side Door and Manual Tray Side Door.
200353	Paperjam in Drum Jam Sensor	
200354	Paperjam between Drum Jam Sensor and Fuser Out Sensor	
Area F		

How to remove the jammed paper in the drum unit

1. Open the Side Door and remove the drum unit as shown.






2. Release the roller by pressing down the Release Arms on two ends and then gently remove the paper.




3. After removing the paper, pull up the Release Arms on both ends. Then grapse the handle of the drum unit and install it horizontally to the original place in the printer as shown.






How to remove the jammed paper in the fuser


 Open the Side Door. Release the fuser by pressing down two lock hooks on both sides as shown.




2. Open the fuser cover by pressing down two lock tabs on the top. Gently remove the jammed paper.



3. After the jammed paper has been removed, close the fuser cover. A snap-in sound will be heared.



4. Finally, push the lock hooks back into its original places as shown. Then close the Side Door.



Fuser Errors

Error Code	Problem Cause on Fuser	Solution
201600	A3 or A4 lamp heating exceeds the upper temperature limit (210 degrees).	
201604	Analog to Digital conversion (ADC) adjustment not ready.	
201605	Analog to digital conversion not ready: In a non-initial state, query on the A3 and A4 lamps' ADC values per 500ms fails.	
201607	The temperature difference between A3 and A4 lamps is more than 50 degrees.	
201612	The difference between the current and last temperatures of the A3 lamp is more than 20 degrees.	
201613	The difference between the current and last temperatures of the A4 lamp is more than 20 degrees.	 Reboot the machine. If the error code
201614	In the warming state, the A3 lamp does not heat up over 5 degrees in 10 seconds, which means a heating error occurs.	persists, replace the fuser.
201615	In the warming state, the A4 lamp does not heat up over 7 degrees in 10 seconds, which means a heating error occurs.	
201616	Fuser heating from ready to print status is over 20 seconds.	
201617	Fuser heating from warming to ready status is over 155 seconds.	
201618	Fuser heating from starting to ready status is over 100 seconds.	
201621	The machine detects that the A4 lamp's thermistor is not connected.	
201624	The machine detects that the A3 lamp's thermistor is not connected.	

Runtime Errors

Error Code	Problem Cause on Runtime Error	Problem-solving Solution	
200100	Api_nvram_rw_test_fail, I/O action fails.		
200101	Api_nvram_write_fail, write fails.		
200102	Api_nvram_read_fail, read fails.	1. Delegat the machine	
200200	Flash error, flash unknown error.	1. Reboot the machine.	
200201	Flash_block_erase_failed, chunk erasing fails.	2. If the error code persists, call the service personnel to replacethe main board.	
200202	Flash_chip_erase_failed, chip erasing fails.	the main board.	
200203	flash_program_failed, Flash write-in fails.		
201610	LPH Error. The LPH flat cable has not been properly installed.	 Reboot the machine. If the error code persists, call the service personnel to check the LPH flat cable. 	
201650	Printer Runtime error.	 Reboot the machine. If the error code persists, call the service personnel to replace the main board. 	
201701	MB NVRAM : A reading error occurs.		
201702	MB NVRAM: A writing error occurs.	1. Reboot the machine.	
201703	MB NVRAM: Write-in is normal, but a reading error occurs during comparison.	2. If the error code persists, call the	
201704	MB NVRAM: Both write-in and read are normal, but an error occurs during comparison.	service personnel to replace the main board.	
201711	EP NVRAM: A reading error occurs.		
201712	EP NVRAM: A writing error occurs.	1. Reboot the machine.	
201713	EP NVRAM: Write in is normal, but a read error occurs during comparison.	2. Check if the EP has been properly installed. 3. If the error code persists, call the content of the property of the content of the conten	
201714	EP NVRAM: Both write-in and read are normal, but an error occurs during comparison.	service personnel to replace the main board.	

201721 Toner NVRAM: A reading error occurs. 201722 Toner NVRAM: A writing error occurs. 201723 Toner NVRAM: Write in is normal, but a read error occurs during comparison. 3. If the error code installed.	oner
201723 Toner NVRAM : Write in is normal, but a read error occurs during comparison. cartridge has been installed.	
201723 error occurs during comparison. installed.	on proporty
3. If the error co	en property
Toner NVRAM: Both write-in and read are persists, call the normal, but an error occurs during comparison. personnel to repl main board.	service
201730 The wrong NVRAM Address is used.	
Network_INIT_Fail The network initialization 202651 fails. 1. Reboot the ma	
201801 Backup PDL setting fails. persists, call the	service
201802 Backup GDI setting fails personnel to repl	lace the
The product will check if the serial numbers of main board. 201803 PDL and GDI are the same while it is starting. The error will occur if they are different.	main board.
Eeng Error _polymotoraction Error: only occurs on the LPH machine because Polygonmotor does not run properly. 1. Reboot the material 2. If the error compersists, call the personnel to replace the personnel to replace the material 2. If the error compension is the personnel to replace the material 2. If the error compension is the personnel to replace the material 2. If the error compension is the material 2.	de service
205101 205101 1. Pull out and bacharger repeated least 3 times to corona wire. 205101 2051	dly for at clean the achine. de
800001 Security chip error 1. Reboot the ma	
800002 Storage security check error	
Storage security check error persists, call the	

System Errors

Error Code	Problem Cause	Solution
200000	Continue Feed Error: This error is displayed when multiple-feed occurs during printing.	Open the side door to remove the paper, and then load the paper with the correct size, orientation, and type in the specified tray.
200050	Side door Open: The side door is not closed properly.	Close the side door properly.
200051	Upper Cover Open: The printer's upper cover is opened	Close the printer's upper cover properly.
200052	Tray 2's Upper Cover Open: The side door of the second tray is opened.	Close the 2 nd tray's side door properly.
200053	Tray 3's Upper Cover Open: The side door of the third and forth trays is opened.	Close the side door of the 3 rd and 4 th input trays properly.
200060	Tray 1 Error: Paper-lifting on the main input tray fails.	 Open and close the main input tray again, and make sure the tray is firmly closed. If the error persists, call the service personnel to check.
200061	Tray 2 Error: Paper-lifting on the second tray fails.	1. Open and close the 2 nd input tray again, and make sure the tray is firmly closed. 2. If the error persists, call the service personnel to check.
200062	Tray 3 Error: Paper-lifting on the third tray fails.	 Open and close the 3rd input tray again, and make sure the tray is firmly closed. If the error persists, call the service personnel to check.

200063	Tray 4 Error: Paper-lifting on the forth tray fails.	 Open and close the forth tray again, and make sure the tray is firmly closed. If the error persists, call the service personnel to check.
200070	Tray 1 Open: The first tray is opened.	Close the 1 st tray firmly.
200071	Tray 2 Open: The second tray is opened.	Close the 2 nd tray firmly.
200072	Tray 3 Open: The third tray is opened.	Close the 3 rd tray firmly.
200073	Tray 4 Open: The forth tray is opened.	Close the 4 th tray firmly.
200080	Manual Tray Empty: There is no paper in the manual tray.	Check if the paper is loaded in the manual tray with correct size and orientation.
200081	Tray 1 Empty: There is no paper in the main input tray.	Place the paper with correct size and orientation in the 1 st input tray.
200082	Tray 2 Empty: There is no paper in the second tray.	Place the paper with correct size and orientation in the 2 nd input tray.
200083	Tray 3 Empty: There is no paper in the third tray.	Place the paper with correct size and orientation in the 3 rd tray.
200084	Tray 4 Empty: There is no paper in the forth tray.	Place the paper with correct size and orientation in the 4 th tray.
200090	Fan 1 fails: The product detects the first fan rotates abnormally.	This is a warning type of error message.
200091	Fan 2 fails: The product detects the 2 nd fan rotates abnormally.	The machine can still run normally. If this error continues to occur, call the service personnel to perform the replacement handling.
200092	Fan 3 fails: The product detects the 3 rd fan rotates abnormally.	This is a warning type of error message. The machine can still run normally. If this error continues to occur, call the service personnel to perform the replacement handling.

Network Errors

500000	IP Conflict: The same IP address is detected in the network environment by the product.	DHCP: require a new set of unique IP address from DHCP Server. Static IP: reset the native IP address.
500001	Net Cable Unplug: The RJ-45 port without a network cable plugged in is detected.	Connect the network cable.
500002	DHCP has no response: When the product is connected to the network via DHCP, the DHCP Server has no response to the request from the product.	Network connection failure. The solution: Use the static IP or connect to a network environment with a DHCP server.
569033	Incorrect shared path Check settings	Please check URL or if IP is correct.
569020	No response and time out. Check target PC	Check target PC.
540020 540021	Ctrl connection is broken. Check network	1. Contact server administrator to check ftp server log. 2. Contact network administrator to check network environment.

External Device Error

Error Code	Message	Solution
400000	CSA6 paper jam	Remove the paper in the CSA6.
400001	CSA6 memory error	Please unplug and then plug the USB cable that connects the CSA6 to the MFP.
400002	CSA6 timeout error	Insert card and try again.

Network Error Codes

Error Code	Message	Solution
500000	IP Conflict	Change your IP address.
500002	DHCP no response	Check your DHCP server or try again.
500003	Can not connect to Network	Check your network and try again.
530001	E-Mail	Reboot the machine, and try again. If the error is still there, contact service personnel to replace the UI board.
530002	E-Mail	Please consult your SMTP administrator. The server returns Error code 002.
531001	E-Mail	Check if the account and password are correct.
530421 531421 532421 533421 534421 536421	E-Mail	Please consult your SMTP administrator. The server returns Error code 421.
530440	E-Mail	The sender must be the same with its login accounts.
531501 532501 533501 534501	E-Mail	 Check the sender's email address. Check the recipient e-mail address. Please consult your SMTP administrator. The server returns Error code 501.
531504	E-Mail	 Check the sender's email address. Check the recipient e-mail address. Please consult your SMTP administrator. The server returns error code 504.
532450 533450	E-Mail	Please consult your SMTP administrator. The server returns Error code 450.
532451 533451 534451 535451 537451	E-Mail	Please consult your SMTP administrator. The server returns Error code 451.

533452 535452 537452	E-Mail	Please consult your SMTP administrator. The server returns Error code 452.	
533550	E-Mail	Please consult your SMTP administrator. The server returns Error code 550.	
533551	E-Mail	 Check the sender email address. The sender must not be the same with the recipient. The server returns error code 551. 	
533552 535552 537552	E-Mail	 Check the sender email address. Check whether mail attachments exceeds allowed size. Please consult your SMTP administrator. The server returns error code 552. 	
533553	E-Mail	Check the recipient e-mail address.	
534554 535554 537554	E-Mail	Please consult your SMTP administrator. The server returns Error code 554.	
538001	E-Mail	 Check whether the network is working. Check whether the attachment exceeds allowable size. 	
540001 540008 540009 540010 540011 540012 540013 540014 540960 540976 543501 545501 545504	FTP	Reboot the machine, and try again. If the error is still there, contact service personnel to replace the UI board.	
540002 540003	FTP	 Confirm the FTP server is not closed and FTP port is correct. If this message still appears, consult your network administrator. The server returns error codes 002, 003. 	
540004	FTP	Check the login name and try again.	
540005	FTP	Check the login name and try again.	
540006	FTP	For a path problem, contact your network administrator.	
540007	FTP	Enter a file name during the time.	

540015	FTP	Check if the network is working properly.	
540978	FTP	Check if the network is working properly.	
541421 542421 543421 544421 545421 546421	FTP	Too many people connected to the FTP server at the same time. Contact your network administrator.	
544450 546450	FTP	The file already exists and is locked by Windows (the file is opened by a specific software application)	
546452	FTP	Ask your FTP administrator to increase allotted storage space, or delete some files.	
541500 542500 543500 544500 545500 546500 547500	FTP	Please consult your SMTP administrator. The server returns Error code 500.	
541501 542501 544501 546501	FTP	Verify your input parameter has invalid characters.	
541502 542502 544502	FTP	Ftp server does not support this command. Consult your network administrator. The server returns error code 502.	
541550 542550 546550	FTP	Verify that you are attempting to connect to a correct server/location. A remote server administrator should provide your permission through FTP connection.	
546553	FTP	Change the file name, delete spaces, or there are special characters in the file name.	
561003	SMB (SMB)	Wrong URL Path	
561012	SMB (SMB)	Wrong user account and password	
561019	SMB (SMB)	The user account does not have permission to create a folder.	
561032	SMB (SMB)	Wrong shared folder name	

F/1024	SMB (SMB)	The file is in use	
561034		The file is in use.	
561183	SMB (SMB)	The folder name is duplicated.	
562088	SMB (SMB)	Server busy. Try scan-to SMB again later.	
563021	SMB (SMB)	SMB service is not ready.	
563039	SMB (SMB)	The disk space to write to is full.	
564019	SMB (SMB)	The user account does not have permission to write the files.	
564183	SMB (SMB)	The file name is duplicated.	
59000x 59030x(SMTP) 59040x(FTP) 59060x(SMB) 59100x	Network	Reboot the machine, and try again. If the error is still there, contact service personnel to replace the UI board.	
592301	E-Mail	Mail server is NULL. 1. Check "Mail server" setting. 2. Contact your SMTP administrator for further help.	

Please note the fax error code will not be displayed in the LCD display. Check the error code from the Activity report. (Press the 「Machine Status」 button on the control panel and then select Machine Information>Information Page>Fax Activity Log Report in succession on the LCD screen.)

Error code		Description or Problem solving steps
202504		Memory space is not enough.
302501	Fax	Firmware execution error. Please reboot and try again.
202502		Stop execution.
302503	Fax	Firmware execution error. Please reboot and try again.
		Timeout
302504	Fax	Firmware execution error. Please reboot and try again.
305504	Fax	Unable to store incoming fax data There is some problem on FW or a SD card. FW execution error. Reboot and try again, or replace the SD card. If the problem continues, have the service personnel replace the SD card on the main board and update the firmware after replacement.
305505	There is some problem in opening a file. Something wrong with FW or the SD card. FW execution error. Reboot and try again, or replace the card. If the problem continues, have the service person replace the SD card on the main board and update the firmware after replacement.	

		The uncompressed image data is incorrect.
		There is some problem on FW or a SD card.
305506	Fax	FW execution error. Reboot and try again, or replace the SD
	Tux	card. If the problem continues, have the service personnel
		replace the SD card on the main board and update the
		firmware after replacement.
305634	Fax	User Abort
		User has cancelled the job during faxing.
		No Answer
		This code indicates that fax signal is not received after dialing.
	Fax	Confirm that remote fax number is correct.
305649		If the fax number is correct, try to extend 「Connect time」 by
303049		pressing 「Machine Status」on the control panel and then choose
		Machine Information>Tools>Service Settings>Fax Service
		Settings>Connection Time in succession on the LCD screen.
	Fax Line not connected	
305860		Check if the telephone line cord has been firmly connected.
305861	Fax	digital line; cannot proceed
305862	Fax	LSD fault during off hook
305863	Fax	data not sent until guard timer expire
305873	Fax	No answer
		No Dial Tone
	Fax	Press 「Service Home」 on the control panel. Choose 「Hook」
205074		on the main screen and then the Thook key to confirm whether
305874		you can hear the dial tone or not.
		If you can not hear the dial tone, check if your telephone cord
		has been correctly connected.

305875	Fax	Line Busy
		Please wait a few seconds and try again.
305633		Communication Error
305650		This problem is caused probably due to poor line
305665~305676		quality. Wait a few minutes and try again.
305713~305717		If this problem persists, please call service.
305721~305737	Fax	
305745~305748		
305777		
305793~305794		
305796		
305856~305859		
305861~305863		
305873		
305876~305877		
305880		

The following message will be displayed when a selected setting is unavailable for a specific copying feature or you have failed to enter necessary information in an operating step:

Selected Setting/Operating Step	Message
(1) Custom Zoom · Ratio	
(2) Rotate Collate	These selections are not
(3) Custom Size Copy	available when Auto Select
(4) Cover Page (Copy)	(paper tray) is enabled.
Auto Select (Paper Tray)	These selections are not available when Reduce/Enlarge is not 100%.
(1) Paper Saver (N-Up) · ID Card	
(2) Custom Zoom · Ratio · Full Page	These selections are not
(3) Auto Select	available when Book Copy is
(4) Auto Detect · Custom Scan Areas ·	enabled.
A3 · B4 · 8K · DLT · LGL · LG13 Size	
(1) Custom Zoom · Ratio · Full Page	These selections are not
(2) Auto Select	available when Paper Saver
(3) Cover Page (Copy)	(N-Up) is enabled.
	These selections are not
Auto Select (Paper Tray)	available when Custom Scan
	Areas is enabled.
[Rotate Side 2] is not available when 1->1	or 2->1 Sided copying are
selected.	
Previously select A6 · B6 · PT · Custom	
size in Paper Size	These paper sizes are not
Previously select A6 · B6 · PT · Custom	available for 2-Sided output.
size in Paper Tray	
(1) JPEG (File Format)	These selections are not
(2) Saturation (Image Options)	available with the Black &
(3) File Size (Quality)	White output.

(1) Saturation (Image Options)	These selections are not	
(2) BMP (File Format)	available for Grayscale output.	
This selection (Black and White) is not availa	able for JPEG File Format.	
In new recipient address		
In From address	Invalid e-mail addresses have	
In [Reply to] address	been entered in these fields.	
In E-mail address book	Enter an valid E-mail address.	
A blank name. Reenter a name to continue.		
(Failed to enter a name for a recipient in Ad	dress Book.)	
(1) Auto Select (Paper Tray)	These selections are not	
	available when [Rotate	
(2) Cover Page (Copy)	Collate] is enabled.	
CopyingCan not leave interrupt print.		
(The job of an interrupted copy has not been	n finished.)	
The selection (cover page) is not available w	hen [Uncollated] is enabled.	
[Uncollated] is not available when Cover Pag	ge is selected.	
Manual tray is not available when custom size	ze is selected for ID Card Copy.	
Selected paper tray with paper size of A6 \		
B6 · PT · Custom size	These selections are not	
Selected paper tray with media type	available when 1->2 or 2->2	
(Transparency · Bond · Cardstock) sided copying is selected.		
The selection (custom size) is not available	when Auto is selected in	
[Reduce/Enlarge].		
When Auto is selected in [Reduce/Enlarge],	custom size is not available.	
1. Copy	2-Sided copying or printing is	
т. сору	not available when the media	
2. Reprint saved job	types (transparency, bond,	
2. Reprint Saved Job	cardstock) are selected.	
A6 · B6 · PT size & the media types (transparency, bond, cardstock) are not		
available for 2-Sided Copy.		
Duplex copy is not available for the currently selected paper size (A6 · B6 ·		
PT size).		
Duplex copy is not available for the currently selected media type		
(transparency, bond, cardstock).		
2-Sided output is not available for the selected paper size (A6 · B6 · PT size).		
, , , , , , , , , , , , , , , , , , , ,		

Ethernet cannot be turn on when Wi-Fi station mode is enabled.

Please connect the network cable and enable the ethernet.

The selection (BMP) is not available for the Color Output.

The selection (Color output) is not available for the BMP File Format.

Image Problem Troubleshooting

Problem	Image Example	Solution
Paper curls	Will of the state	 Use paper of standard weight: If you are using thin paper, try to use paper of standard weight (70 g/m²). Refer to paper specifications. Use paper with less moisture: Load the paper to the paper tray immediately after removing them from the packaging. Seal the remaining paper with the original packaging to keep from the moisture absorption.
Light print(entire page)	ABCD ABCD ABCD	 Make sure that the toner cartridge is fully installed. Make sure that the Toner Save setting is turned off in the printer driver. Try using a different type of paper. The toner cartridge might be almost empty. Replace the toner cartridge.
Light print(partial page)	ABCD ABCD ABCD	 Make sure that the toner cartridge is fully installed. The toner level might be low. Replace the toner cartridge. The paper might not meet the printer's specifications (for example, the paper is too moist or too rough). Refer to paper specifications.
Vertical white lines	ABCD ABCD ABCD	Call the service personnel for help to clean the drum unit.

Vertical black lines	ABCD ABCD ABCD	Please clean the EP charger according to the procedure described in the preceding section <u>Cleaning the EP charger</u> .
-------------------------	----------------------	--

Image Problem Troubleshooting

Problem	Image Example	Solution
Dirty background(partial page)	ABCD ABCD ABCD	Check if toner is not leaked from the toner cartridge. If so, replace the toner cartridge.
Dirty background(entire page)	ABCD ABCD ABCD	The paper might not meet the printer's specifications (for example, the paper is too thin). Refer to paper specifications.
Print blank page		Check if there is enough toner in the toner cartridge. If not, please replace the toner cartridge. If this error happens again, call service for help.
Defective image of regular interval	ABCD ABCD ABCD	Clean the inside of the product (Refer to preceding section <u>Cleaning</u> the Paper Path).

Loose toner	ABCD ABCD	 If you have observed a rougher texture on one side of your paper, try printing on the smoother side. The paper might not meet the printer's specifications (for example, the paper surface is not smooth or paper too thick). Media type incorrect. Please choose proper media type for your paper.
Black lines on edge	ABCD ABCD ABCD	The image is slightly skew. Make sure the edge of your document is properly aligned and slightly touch the paper guides in the auto document feeder.
Black borders on edge	ABCD ABCD ABCD	Your original may not be a square sheet of paper. The scanner will fill the space with black background.

Technical Support

If your problem still exists after trying the above solution, please contact our technical support.

Before contact Katusha, please prepare the following information:

- Scanner serial & revision number (located on the bottom of the scanner);
- Hardware configuration (e.g., your host CPU type, RAM size, free disk space, display card, interface card);

http://www.Katusha.ru

10. Specifications

All specifications are subject to change without notice.

General		
Туре		4-in-1 Multi-function Copier
Functions		Copier-Printer-Scanner-E-mail
CPU		800MHz Dual Core
SDRAM		2048MB DDR III
Flash Memory		8G
Dimension (WxDxH)		575 x 568 x 786 mm
Weight		45 kgs (includes two trays)
Power Consumption		<490 W
LCM		8 in. TFT
Connectivity		Hi-speed USB 2.0 (Device/Host)/ RJ-45
Operating Environment	Temperature	10°C to 35 °C
	Humidity	15% ~ 85% RPH
Storage Environment	Temperature	-40°C ~ 40°C
	Humidity	10% ~ 90% RPH
Current Consumption		110V Input: 100-127Vac, 50/60Hz, 13A 220V Input: 220-240Vac, 50/60Hz, 6.5A
Copy Function	s	
Copy size		A3, Legal, Letter, A4, A5, B4(JIS), B5(JIS), 8K, 16K, Postcard, LGL, Ledger
Max scanning size		A3 (297 x 420 mm)
Copy resolution		600 x 600dpi

Copy speed		45 cpm (A4 LEF)
Copy count		up to 999, Auto Reset to 1
Zoom		25 ~ 400%
N-up copy		2 in1 / 4 in 1 / ID card
Copy mode		Text/Photo/Mixed
Auto size detection		Yes (A3、A4、A5、A6、B4、B5、B6、LGL、LTR、DLT)
Print Function		
Printing method		Mono Laser
Printing speed		45 ppm (A4 LEF)
Max print size		279 x 413 mm (Ledger, Double Letter)
Min print size		100 x 148 mm (3.92 x 5.82 in.)
Resolution		600x600 dpi, 1200x1200 dpi
Max paper capacity Paper capacity		500 (tray 1) (70 g/m², plain paper) 500 (tray 2) (70 g/m², plain paper) (optional for AM5630i/AM5640i) 500 (tray 3/4, optional) (70 g/m², plain paper) 100 (manual tray) (70 g/m², plain paper) 100 pages (70g/m² plain paper) A3, Double Letter (Ledger), Statement (SEF),
Manual tray	Paper size	8K, 16K, A6, A4, B6(JIS), B4(JIS), A5, B5(JIS), Letter, Legal 13, Legal, Officio, Japanese PostCard, Customized size: 100x148 ~ 297x420 mm (3.93"x5.82"~11.6"x16.5")
	Paper weight	60~300 g/m²
	Paper capacity	500 pages (70g/m² plain paper)
1~4	Paper size	A3, A4, B4(JIS), A5, B5(JIS), Letter, Legal 13, Legal, Officio, Double Letter
	Paper weight	60~105 g/m² (16~28 lbs)
Support paper tray		Standard 500 pages input tray
Paper output capacity		530 pages
PCLs/Emulations		GDI
First print out time		<5 seconds

Edge erase	4.3 mm (top, bottom, left, right)
Scaling	25 ~ 400%
Duplex print	Yes
Storage print	Yes
Security print	Yes
Network print	Yes
Scan Function	
Scanner type	Flatbed/ADF/CIS type, Color/BW
Max scanning size	A3
Optical resolution	600 x 600 dpi
ADF Capacity	100 pages (70 g/m², plain paper)
Scanning bit depth	Color - 24bit(output)/48bit (input) Gray - 8bit(output)/16bit (input) B/W - 1bit
File format	Color/Gray - JPEG, MPDF, TIFF B/W - MPDF, TIFF, BMP
Consumables Life	
Toner	20,000 pages (A4 5% cover rate)
Drum unit	150,000 pages
Developing unit	150,000 pages
Fuser	300,000 pages