


Flatbed Scanner

User's Manual



Regulatory model: BT-1007B

Avision Inc.

Trademarks

Microsoft is a U.S. registered trademark of Microsoft Corporation. Windows, Windows Vista, Windows 7, Windows 8 and Windows 10 are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.

Energy Star[®] is a registered trademark of the U.S. government. IBM, IBM PC are registered trademarks of International Business Machines Corp.

Other brands and product names herein are trademarks or registered trademarks of their respective holders.

Copyright

All rights reserved. No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, electronic, mechanical, magnetic, optical, chemical, manual, or otherwise, without the prior written permission of Avision Inc.

Material scanned by this product may be protected by governmental laws and other regulations, such as copyright laws, the customer is solely responsible for complying with all such laws and regulations.

Warranty

The information contained in this document is subject to change without notice.

Avision makes no warranty of any kind with regard to this material, including, but not limited to, the implied warranties of fitness for a particular purpose.

Avision shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this material.

Federal Communications Commission (FCC) compliance information statement Part 15

The product has been tested and found to comply with the limits for a Class A digital device pursuant to Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference and (2) this device must accept any interference received including interference that may cause undesired operation.

The FCC Class A limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual may cause harmful interference in which case the user will be required to correct the interference at his own expense.



As an ENERGY STAR[®] Partner, Avision Inc. has determined that this product meets the ENERGY STAR guidelines for energy efficiency.

CE

European Union Regulatory Notice

Products bearing the CE marking comply with the following EU Directives:

- Low Voltage Directive 2014/35/EC
- EMC Directive 2014/30/EC
- Restriction of the use of certain hazardous substances (RoHS) Directive 2011/65/EU

CE compliance of this product is valid if powered with the correct CE-marked AC adapter provide by Avision.

This product satisfies the Class A limits of EN55022, EN55024, safety requirements of EN 60950 and ROHS requirements of EN50581.

*This machine is certified as Class 1 LED product.

CE Warning

This is a class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

Disposal of Waste Equipment by Users in Private Union



This symbol on the product or on its packaging indicates that the product can not be disposed of with your other household waste. Instead it should be sent to appropriate facilities for recovery and recycling in an effort to protect human health and the environment. Fore more information about where you can drop off your waste equipment for recycling, please contact your local city office, your household waste disposal service or the shop where you purchased the product.

System Requirements

CPU:	Intel [®] Core™ 2 Duo or higher
Memory:	32 bit: 2 GB 64 bit: 4 GB
Optical Drive:	DVD-ROM Drive
USB Port:	USB port 2.0 (compatible with USB 1.1)
	Microsoft Windows XP(SP3), Windows Vista, Windows 7, Windows 8.x (32-bit/64-bit), Windows 10 (32-bit/64-bit)

Product Safety Guide

Please clearly read all these instructions, and follow all instructions and warnings before installing and using the device.

The following indications are used in this document to obviate any chance of accident or damage to you and/or the device.

A WARNING	Indicates potentially hazardous situations, which if instructions are not followed, could result in death or serious injury.
riangle caution	Indicates a potentially hazardous situation which, if instructions are not followed, may result in minor or moderate injury or damage to property.

- Use only the AC power adapter that came with your device. Using any other AC power adapter could cause fire, electrical shock, or injury.
- Use only the AC power cord and USB cable that came with your device and avoid abrasions, cuts, fraying, crimping, and kinking. Using any other AC power cord and USB cable could cause fire, electrical shock, or injury.
- Do not place objects on top of the AC power cord, and do not allow the AC power adapter or the AC power cord to be stepped on or run over.
- Place the device and its AC power adapter near an electrical outlet where the AC power adapter can easily be unplugged.
- If you use an extension cord with the device, make sure that the total ampere rating of the devices plugged into the extension cord does not exceed the cord's ampere rating.
- Place the device close enough to the computer so that the interface cable can easily reach between the device and the computer.

- Do not place or store the device or its AC power adapter:
 - Outdoors
 - Near excessive dirt or dust, water, or heat sources
 - In locations subject to shocks, vibrations, high temperature or humidity, direct sunlight, strong light sources, or rapid changes in temperature or humidity
- Do not use the device with wet hands.
- Never disassemble, modify, or attempt to repair the AC power adapter, device, or device option by yourself, except as specifically explained in the device's documentation. This could cause fire, electrical shock, or injury.
- Do not insert objects into any opening, as they may touch dangerous voltage points or short-out components. Beware of electrical shock hazards.
- Unplug the device and the AC power adapter, and refer servicing to qualified service personnel under the following conditions:
 - The AC power adapter or plug is damaged.
 - Liquid has entered the device or the AC power adapter.
 - Object has entered the device or the AC power adapter.
 - The device or the AC power adapter has been dropped, or the case has been damaged.
 - The device or the AC power adapter does not operate normally (i.e. appearance of smoke, strange smell, odd noise, etc.), or exhibits a distinct change in performance
- Unplug the device and the AC power adapter before cleaning.

A CAUTION:

- Do not locate the device on rackety or aslope tables. Do not locate the device on unstable surface. The device may fall down and this may result in injury.
- Do not place heavy objects on the unit. It may cause unbalance and the device may fall down. This may result in injury.
- Store the AC Power cord/USB cable bundled out of the reach of children to avoid the risk of injury.
- Keep plastic bags bundled out of the reach of children or throw them away to avoid the danger of suffocation.
- If you are not going to use the device for a long period, unplug the AC power adapter from the electrical outlet.


1. Introduction

Congratulations on your purchase of the Avision's A3-sized flatbed image scanner. Avision is one of the leading companies to make high quality color image scanner.

Before you install and operate the new scanner, please take a few minutes to read through this manual. It provides proper instructions for you to unpack, install, operate and maintain the scanner.

1.1 Package Contents

The following figure indicates the package contents. Please check all the items against your checklist. If you do not receive all the items, please contact your authorized local dealer immediately.





- 1. Scanner main unit
- 2. Quick guide/CD
- 3. USB cable
- 4. Power cord/ Power adapter

Note:

- 1. Only use the AC adapter DA-48M24 by APD included in the machine. Using other AC adapters may damage the machine and void the warranty.
- 2. Please unpack the packing carefully, and check the contents against the checklist. If any items are missing or damaged, please contact your dealer immediately.
- 3. To access more service supports, visit www.avision.com to register your Avision's product.

2. Scanner Installation

Precautions

- Keep the scanner out of direct sunlight. Direct exposure to the sun or excessive heat may cause damage to the unit.
- Do not install the scanner in a humid or dusty place.
- Be sure to use the proper AC power source.
- Place the scanner securely on an even, flat surface. Tilted or uneven surfaces may cause mechanical or paper-feeding problems.
- Retain the scanner box and packing materials for shipping purposes.

2.1 Unlocking your scanner

To protect the scanning unit from damage during transportation, a lock switch is designed to keep the scanning unit from moving. To unlock the scanner, move the lock switch up as shown in Fig. 2-1.




Figure 2-1 Unlocking the Scanner





Figure 2-2 Home position

Note: If the scanning unit is not located at the front of the scanner before transporting the scanner, be sure to do the follows:

- 1. Turn on the scanner. The scanning unit should move to the front of the scanner.
- 2. Press the lock switch down to the "Lock position".
- 3. The scanner is now ready to transport.

2.2 Connecting to Power

Plug the small end of the power adaptor into the power jack of your scanner. Insert the other end to an appropriate power outlet.



2.3 Turning on the Power

After the power cable has been connected, press the power switch button on the panel to turn on the scanner. The LED indicator will be lit up. To turn off the scanner, press the power switch button again. The LED indicator will be shut off.

2.4 Installing the Scanner Driver

NOTE:

- 1. The Windows system CD may be required when installing on some PC's.
- 2. To ensure your computer can identify the USB scanner, please install scanner driver first before connecting the scanner to your computer.
- 3. The scanner driver contains both TWAIN driver and WIA driver. This scanner allows you to scan via a TWAIN user interface or a WIA (Windows Image Acquisition) interface. Start your TWAIN-compatible image editing software application to select a TWAIN or WIA user interface. Or you might launch Microsoft's Scanner and Camera Wizard to scan via a WIA user interface.
- **1.** Place the supplied CD-ROM onto your CD-ROM drive.
- The software installation graphic appears. If not, run "setup.exe".




Contents on the installation graphic:

- **Install Scanner Driver:** To communicate with your scanner, you need to install the scanner driver.
- Install Button Manager V2: To use the buttons on the scanner, you need to install Button Manager V2. To ensure Button Manager V2 works properly, please FIRST install the scanner driver before installing Button Manager V2.
- **Install AVScan X:** To scan and organize your multipage document(s), you can install the software application to manage them easily and effectively.
- Install Adobe Reader: To view the user's manuals for the scanner and Button Manager V2, you need to use Adobe Reader to open and view the manuals in pdf file format. If you already have Adobe Reader installed on your computer, you may disregard this item.
- View Manual: Click "View Manual" to view or print the detailed user manual for the scanner and Button Manager V2 respectively.
- 3. Install Scanner Driver to install the scanner driver on your computer and then click Install Button Manager V2 to install the Button Manager V2.

2.5 Connecting to Computer

1. Connect the **square end** of the USB cable to the USB port of your scanner. Connect the **rectangle end** to the USB port at the rear side of your computer.



- The computer should detect a new USB device and prompt a "New Hardware Found" message.
- **3.** By following the on-screen instructions, click the **Next** button to continue. When the certification screen appears, click **Continue Anyway** to complete the installation.
- 4. When the Finish dialog is prompted, click the Finish button.


Note:

The rectangle USB port on the product is a USB hub, capable to connect Avision's sheetfed scanners with the dual driver.

3. Completing Your First Scan

3.1 Placing Your Paper

- 1. Open the document cover then place your original face down on the document glass as shown in Fig. 3-1.
- 2. Make sure the top of your original near the document alignment mark.



- 3. Your original
- 4. Document glass

Figure 3-1 Placing the original

3.2 Verifying Your Scanner Installation

To verify if your scanner installation is correct, Avision provides you a useful test program called Avision Capture Tool. With this tool, you can perform simple scans and view the captured images. In addition, it helps you complete your scan at a rated speed.


The following procedure describes how to verify your scanner installation. If the installation is not correct, please review the preceding section to check if the cable connection and scanner driver have been successfully installed.

Before you begin, be sure the scanner is on.

1. Select Start>Programs>Avision xxx Scanner>Avision Capture Tool. The Select Scanner Model dialog box will be displayed.

Select Scanner Mode	1 🛛 🔀
Driver Type: TWAIN	
Scanner Model:	
Avision xxxx	
	OK Cancel

 Select your driver type and scanner model and click OK. The following Avision Capture Tool dialog box will be displayed.



- Choose your desired file format from the File Format drop down list box. (Default is JPEG, other choice includes TIFF, MTIFF, PDF, MPDF, GIF, and BMP.) The supported file formats vary depending on your scanner model.
- Type your desired folder name and file name in the File Path box. (Default is C:\Documents and Settings\User Name\My Documents\My Scan\Image.)

Note: If you do not wish to save the scanned image, deselect the Save button since default is Save Enable. In this case, the thumbnail view will be disabled. And therefore, after viewing all the scanned images, only the last one will remain on the screen.

5. Click the Setup button (^{Setup}) or choose Setup from the File menu to prompt the Scanner Properties dialog box.

	Scanner Properties	1		
Image Selection Box	Front Auto Color Detection Front Calor Front Gain Front	Dinatzation: Senstivity; Bigbliness: Contrast: Resolution (dol): Invert:	Dynamic Threshold 20 4 0 4 200 8 200 8 200 Black on Whee	• • • •
	Same settings for both sides Scan Source Profiles_ Defaults	(Auto Document Feeder	•]	OK Cancel

- 6. From the Image Selection Box, choose your desired image type for your scanned image. (Default is Front B&W) If you have a duplex scanner, choose Front and Rear to scan both sides of your document.
- 7. Click OK to quit the Scanner Properties dialog box. (To learn more details about the Scanner Properties dialog box, please see the subsequent chapter, *Using the Scanner Properties Dialog Box*.)
- 8. Place your document face down on the document glass or face up in the auto document feeder.
- In the Scan Validation dialog box, click the Scan button
 (scan
) or choose Scan from the File menu.
- 10. The document will be scanned and displayed in the Scan Validation screen. After the scanned images have been displayed, your scanner installation verification is completed.

g ture Tool(TWAIN) - X Yang About	KOK					
Detup 🥜 Dom	File Formet	JPEG 👻 C	Wy Scarlimage	Ð		
	to the wort Thirty-one abelets. Who are th Friends. M People why Reverand J Becurd B H possies couple why who south Walson too becurd B H possies couple why who south Strangers, there yes Nove a stat Bornoo, th to controll Nove a nud Kichon is i Medican is Medican is M	to on purchs of chimmen exclusions, damperind with the increase of the increase of the the increase of the increase of the the increase of the increase of the the increase of the increase of the increase of the increase of the increase of the increase of the increase of the increase of the increase of the increase of	very scalar/print/jet smoke. In flur days our work in the wholese, basic on windowsill and heat of the second scalar second of the second scalar second scalar second of the second scalar second scalar second scalar second scalar scalar second scalar scalar second scalar scalar scalar scalar scalar scalar second scalar scalar scalar scalar scalar scalar s	done, and Arro Is L be wro by as the wro by as the set of the set of the set		
					Display Vi	ew/
	onail Vie				- copiag vi	

- 11. You can view the scanned image in Fit Page (E) or Actual Size (100%) button () from the Viewing toolbars at the right side.
- 12. Click the Close box or Quit from the File menu to exit the Scan Validation Tool.

3.3 A Glance of the Scanner Properties Dialog Box

Front Auto Color Detection	Binarization:	Dynamic	Threshold	-	
Front Color	Sensitivity:	20	٠		۲
Front Gray	Brightness:	0	•		۴
	Contrast		•		۲
Rear Auto Color Detection	Resolution (dpi):	200		•][
Rear Color	Invert:	Black on	White	*	
Rear Gray					
Same settings for both sides					
Scan Sc	ource: Auto Document Feede	ar	-		
Profiles	Custom		•		

1. Tab Options	Choice: Image, Compression, Color Dropout, Paper, Multi-Feed Detection, Preview, Options, Settings, Information.
2. Image Selection Box	Choose your image type and the side of document you wish to scan. Options vary based on type of scanner.
3. Brightness	Adjust the brightness level from -100 to +100.
4. Contrast	Adjust the contrast level from -100 to +100.
5. Resolution	Determine the quality of the scanned image. The industry standard is 200 dpi.
6. Invert	Reverse the color of your scanned image.
7. Scan Source	Choice: Auto Document Feeder, Flatbed, Flatbed (Book), Automatic (varies due to different scanner model)
8. Defaults	Reset all values on the tabs to the factory default settings.

4. Using the Scanner Properties Dialog Box

The Scanner Properties dialog box allows you to configure the scanner's settings. It consists of several tabbed windows each of which will be described in this chapter.

Note: In this chapter, all options are available based on a duplex (double-side) scanner. If you have purchased a simplex (single-side) scanner, all options are available for single sided only.

mage Pa	per Setting	Information					
Front	Auto Color Det	tection	Binarization:	Dynamic	Threshold	•]	
Front	Color		Sensitivity:	20	•		۰.
Front	Gray		Brightness:	0			F
Front	B&W		Contrast:				
			Contrast				
	Auto Color Det	ection	Resolution (dpi):	200		•	
Rear	Color		Invert:	Black on	White	*	
			HIVCIL.	Didort off		31	
	Gray		invert.	Lucot on			
	Gray B&W		ilver.	Luder on			
Rear	B&W settings for both	n sides	Auto Document Feede		▼.		
Rear	B&W settings for both Sc	n sides			• •		
Rear	B&W settings for both Sc	n sides can Source:	Auto Document Feede		•		
Rear	B&W settings for both Sc	n sides can Source:	Auto Document Feede		•		
Rear	B&W settings for both Sc	n sides can Source:	Auto Document Feede		•		

The Scanner Properties dialog box

			201 (2. 1997)		
Front Auto Color Detection	Binarization:	Dynamic	Threshold	•	
Front Color	Sensitivity:	20	•		•
Front Gray	Brightness:	0	4		F
	Contrast:		4		۴
Rear Auto Color Detection	Resolution (dpi):	200		•	
Rear Color	Invert:	Black on	White	•	
near Gray					
Rear B&W]				
Rear B&W Same settings for both sides Scan Source	Ce: Auto Document Feede	ar	•		
Same settings for both sides	ce: Auto Document Feede	ar	• •		
Same settings for both sides Scan Source		ar			
Same settings for both sides Scan Source		<u>अ</u>			

4.1 Buttons on the Scanner Properties Dialog Box

The buttons on the Scanner Properties dialog box

Buttons	Description
Defaults	Click the Defaults button, the factory default settings will be shown on each tab.
Cancel	Click the Cancel button to leave the Scanner Properties dialog box.

The following table shows the default settings :

Tab name	Default settings
Image	Image : Front B&W
	Binarization : Dynamic Threshold
	Resolution : 200 dpi
	Invert : Blank on White
	Scan Source : Auto Document Feeder
	Threshold : None
	Brightness : None
	Contrast : None
Compression	None
Color Dropout	None
Paper	Cropping : Automatic
	Deskew : Yes
	Orientation : Portrait
	OverScan: 0.00
	Note: The availability of this option
	varies due to scanner model.
	Unit : Inch
Multi-Feed Detection	None
Preview	None
Options	Rotation Degrees : None
	Blank Page Removal : None
	Edge Fill: White, 0 mm
	Image Control Option : None
Setting	Enable Energy Saver : Enable, 15
	minutes after last scan action
	Show Scanning Progress : Yes
	Show Warning Message : Yes
	Save Settings after Closing : Yes
Imprinter	Digital Imprinter

4.2 Showing or Hiding Tabs

The [**Scanner Properties**] dialog box is displayed in default with three basic tabs - Image, Paper, and Information. To show more tabs, click the [**Scanner Properties**] icon to access more scan settings.

To show more tabs,

- Click the [Scanner Properties] icon () on the upper left corner, and choose [Tab] to show available tab names. The available tabs include Compression, Color Drop out, Preview, Rotation, Separation, Multi-Feed, Options, Settings, and Imprinter. (Note: the options vary based on scanner model.)
- Choose the tab you want to display. The selected tab will be shown with a check mark and then displayed in the [Scanner Properties] dialog box.
- 3. To access the settings, click the selected tab on the top of the [Scanner Properties] dialog box. The page of the selected tab will be displayed.

To hide a tab window,

- 1. Click the [Scanner Properties] icon () on the upper left corner, and choose [Tabs] to show available tab names.
- 2. Choose the tab you want to hide. Then, the selected tab will be hided in the [Scanner Properties] dialog box.

Note: The [Image], [Paper], and [Information] tab can not be hided since they preprogrammed to be displayed by default.

User's Manual

Tabs Move	•	Compression Color Dropout Multi-Feed Detection		Threshold		
Close Alt	+F4	Preview	20			•
Front Gray		Rotation Separation		4		Þ
Front B&W	 Image: A start of the start of	Enhancement Setting		•		Þ
Rear Auto Color	r Detec	Imprinter	00		•][
Rear Color		Invert:	Black on	White	•	
Rear B&W	both eidee					
Same settings for						
Same settings for	Scan Sour	rce: Auto Document Feeder		•		
Same settings for		ce: Auto Document Feeder		•		
Same settings for	Scan Sour	Allo Docament recuei				
Same settings for	Scan Sour	Allo Docament recuei				
Same settings for	Scan Sour	Allo Docament recuei				

4.3 The Image Tab

The Image tab allows you to choose the front side and (or) the rear side of your document, the type of image, and to set several basic scan settings. Note that except for the resolution, you can set individual scan settings for the front side and the rear side. For example, all settings in the Image tab, Compression tab, Color Dropout tab can be set individually for the front and the rear side. However, the settings in the Paper tab, the Option tab, and the Setting tab have to be set the same for the front and rear side.

nage	Paper	Setting	Information					
	Front Auto	Color De	tection	Binarization:	Dynamic	Threshold	•	
•	Front Colo	r		Sensitivity:	20	•		۲
	Front Gray Front B&W]	Brightness: Contrast:	0	4		4
6	Rear Auto		tection	Resolution (dpi):	200		•	
Rear Color Rear Gray		Invert:	Black on White					
	Rear B&W	r						
	Rear B&W ame settin	gs for botl		Auto Document Feede	r	•]		
_ (gs for botl S		Auto Document Feede	1	•		
		gs for botl S	can Source:		ť	•		


The Image tab dialog box

4.3.1 The Image Selection Box

Front Auto Color Detectio	n
Front Color	
Front Gray	
Front B&W	
Rear Auto Color Detectio	n
Rear Auto Color Detectio	n
	n

The Image Selection box includes the image type and document side option. If you wish to scan both the front side and the rear side of your color document, you can check both Front Color and Rear Color at the same time. Note the options vary based on type of scanner.

Example 1 : Scanning a two-sided color document, both sides in color



Example 2 : Scanning a two-sided color document, one in B&W, the other in color




Image Type	Description
Color	Choose Color if you wish to scan a color image for your original in color.
Gray	Choose Gray image if your original contains actual shades of gray.
B&W	Choose B&W if your original contains only text, pencil or ink sketch.


— conserve the the first of groups and the first of

Measurement anguing. The second secon

Notice the point of the point of a three last local the could be reverses were never seen any other distribution the dwarf last and lagsly any calculation. Local point of sharp the point of the point

B&W





Gray

Color

Front/Rear Auto Color Detection:

Click to automatically detect and scan the front or the rear page of your color document in color image mode. If your document is in colors, the scanner will automatically scan the document into a color image. If your document is non-color, you can choose the output to be either B&W or Gray from the Non-Color Selection option. This option is useful when you have a mixture of color and non-color document.

Note: If you choose Front Rear Auto Color Detection, you can not specify the image mode of your rear page and vice versas.

Modes of Auto Color Detection:

If [Front/Rear Auto Color Detection] is selected, its modes will be displayed. Choice includes Normal, Ignore Paper Color. For paper with background color such as invoices, choosing [Ignore Paper Color] will automatically remove the background color and enhance the detection accuracy.


	INVOICE		INVOICE	
	68% etb.323.43 INVOICE of 55mb Spare Facto for Antoneolite Soulo	Bule : 3-dy 20, 2002	(FSN: 0.0-1.12.4.3 Bells : July 38, 2002 ENVOICE of 5 feb Typer Twels for Anternative Tests	
	For account and sink of Moores. APC Manuf actuaing Co., Lab		Fer account and task of Masors. AFC Manufacturing Co., Ltt.	
	3236 Illiett Asenue, South, Wk 9061 U.S.A. Tol : 253-923-66	P9 est 2336 Tux : 253-922-6680	3236 Ellinit Annue, Smille, WX 9061 U.S.A. 34: 253-923-6699 ed.2336 Fax: 253-922-6608	
	Alls. Mr. Beall Wang		Adh.: Mr. Dedd Worg	
	Shipped by SST Technologies Inc.	Bur U-Line Express	Shippel by SST Todashegies Inc. Der U.Line Express	
	Sulling on or aboutJuby 20, 2002 Brons Tairone, R. D.C	B USA.	Salling on or about 3 day 20, 2002 Room Takows, R.O.C. in U.S.A.	
	L/C No. Contract No. A1233		L/C No. Contract No. A1233	
	Made & Nec. Decembring of Cools	Quality This hire Amend	Marko & Nov. Beerzigtien et Goods Quantity Unit histo Assessed	
	Juncet (Ren Ho. 500)	3 ++++ 010 20 30 000 40 00	Amout (hen No. 500) 3 ora: UED-00.00 UED-00.00	
	ABC Ameri(Isra Ho. 201)	3 edu 0052 30 10 0052 40 00 3 edu 0052 30 10 0052 40 00	ASC Amount han No. 301 3 ont 03220200 03240100 Amount han No. 302 3 ont 03220200 03240100	
	Settle	3 560 012 20 20 00 00 00	fath	
	P/0 No. A2233 C04o. 1		P/036.41233 CA9.1	
	Made in Taiwas. R.O.C.		Made in Talavan	
	Tetal	S and UX 31 20 60	ROC. Serie VIDE20 00	
			546 5466 5502710	
	Surgited To Consumid Wite. Value for Custom Pargine Baly. Constry of Reigin. Televes, R. O. C. N.W.: C.W.: Decomment I.		raga kar di scrave andre Alan a Constructione di Alan andre A Alan andre Alan andre Al	
No	ormal		Ignore single backgrout color	nd

Sensitivity of Auto Color Detection

If your documents contain primarily B&W text and small amount of light or pale colors and you do not wish them to be recognized as color image to save the file size, you can increase the sensitivity value by moving the bar to the right to let these images to be detected as B&W. The value ranges from 1 to 100. The default is 37.



Original



Sensitivity: 1Sensitivity: 100(The image is recognized
as a color one)(The image is recognized
as a black and white one)

Same settings on both sides:

Click to apply same scan settings for both sides of your documents. After checking this option, any settings you have changed will automatically applied to both the front side and the rear side. For example, if you choose your ideal resolution to be 300 dpi, this will be applied both to the front side and rear side of your document.

4.3.2 Other Image Options

Binarization This is the process of converting a grayscale or color image to a bi-tonal image. There are several different methods of performing this conversion. Options: Dynamic Threshold, Dynamic Threshold (AD), Fixed Processing, Halftone 1~5, Error Diffusion.

Dynamic Threshold: Selecting **Dynamic Threshold** allows the scanner to dynamically evaluate each document to determine the optimal threshold value to produce the highest quality image. This is used to scan mixed document containing faint text, shaded background, or color background with a single setting. If Dynamic Threshold is selected, Threshold, Brightness, and Contrast are not available.

Dynamic Threshold (AD): Selecting **Dynamic Threshold (AD)** to perform the enhanced mode of the Dynamic Threshold feature. However, using this mode may slow down your scanning speed.

Sensitivity of Dynamic Threshold

Occasionally your scanned image may contain small dots or speckles. To remove these spots, increase the sensitivity value by moving the bar to the right. The value ranges from 1 to 30. The default is 20. **Fixed Processing:** Used for black-andwhite and other high contrast documents. A single level is set to determine the blackand-white transition. The threshold is programmable over the entire density range. **Fixed Processing** sets Contrast to 0. If **Fixed Processing** is selected, Contrast is not available.

Halftone: In addition to the black and white display, Halftone can present a somehow gray shade of image by using different size of dots. Halftone image looks like the picture we have seen in the newspaper. Options include Halftone 1, Halftone 2, Halftone 3, Halftone 4, Halftone 5.


Error Diffusion: Error Diffusion is a type of Halftone. Error Diffusion gives good image texture and makes text in images more readable than Halftone.



Halftone Image




Error Diffusion Image



Threshold Used to convert a grayscale image to a bi-tonal image. The value ranges from 0 to 255. A low threshold value produces a lighter image, and can be used to subdue backgrounds and subtle, unneeded information. A high threshold value produces a darker image, and can be used to help pick up faint images.

Adjust the threshold setting by dragging the Threshold sliding bar to the left or right to achieve the desired threshold setting.



200 dpi, Threshold:50, Brightness: 0

200 dpi, Threshold:100, Brightness: 0

Gray


Document Type: Choice: Normal, Photo, Document Three options of document type are provided when you choose Gray as the image type for your scanned document. **Choice: Normal, Photo, Document.**

- **Document:** Choose Document if your original contains pure text or a mixture of text and graphic since it is an optimal setting for regular business document. When using Document, only Threshold can be adjusted.
- **Photo:** Choose Photo if your original contains photo to reproduce your photo in vivid grayscale image. When using Photo, no Threshold and Contrast can be adjusted.
- **Normal:** When using **Normal**, Threshold, Brightness, and Contrast can be adjusted.

Threshold: The value ranges from 0 to 255. The default is 230. A low threshold value produces a lighter image, and can be used to subdue backgrounds and subtle, unneeded information. A high threshold value produces a darker image, and can be used to help pick up faint images. Adjust the threshold setting by dragging the **Threshold** sliding bar to the left or right to achieve the desired threshold setting.

		Second Seco	• 5000000000000000000000000000000000000
-	Concession of the	Taken and gets Manifest	-
		The same server	
	Carlot Statement	201-21 201-21	
	And in case of the local division of the loc		
	All of the local division of the	Adjustment of the local division of the loca	
	All in pass on		
	AP 100 PEP IN.		
	Address of the other will be a real	10.0.0	
	SP AND	an- an and	
	Read in case of the local division of the lo		
	- Notes and the second	100	
	The second second		
		Lancada Char, Marca	
		100	
		State and a	
	THE PART		
	Contraction of the local division of the loc	Card Lines	
	And a second second	10.0 million	
	- and the second		
	- Conception - Con	(pro. 1914)	
	- And States		
	And and	streng Mill Million A	AL 201.00
		100.000	
		Street Oliver 1 College 11	
	The second se		
		. (and h (and a 197	a sheet
	Transmission and	Sand-Look Solida Colora	and a long
	Concession of the local division of the loca	And And Area and Annual	
	Transmission and	Sand-Look Solida Colora	a star

Normal



	107 101 2440 104	
	NOT THE OWNER WAT	Elizaria filme (Pfilmen)
		Late loan \$1.00. Bell took (Tax.
		1174
	And one spect	
		Ruppe
	Lan are and	6-5 U.MM
	Tel a tra	
	Put market	
	Statute and a statute	100 cost
	Contraction of the local division of the loc	Statute of the Village Visit reaction
	Total Contraction	Called of the local design
-	Company of the	garle spec, hors
and the second second	the local division of	And your 1970 load both 1970
	The local division in which the real division in which the real division is not the real division of the real division in the real division is not the real division of the real division is not the real division of the real division is not the real division of t	THE AVE. 177 LANSING MICH
	Support of the local division of the local d	710 ATT 1000 ANT



• hereite	• 325 weeks. • 322 *****
• •	· · · · · · · · · · · · · · · · · · ·
111111111	TALITY . DURING THE
	And and an
	· ····································

		Participant descent descent factor
	A.P. ro. 1999 1990	
		Ethnick Washinth although
		Report of Colleges, print, page and
	All march	
		1011 - 1073 . Mits date.
	Series Prompt	ani wit wit and
		104
		\$211.0mg \$11.0mg
		Life root 21 mm. Best lines 11mm.
-	from two agents	
		6.0% 6.0%
		211. mills
	Paragent carding	10 June -
	Los pri part	Laura Lucrenal
		613 (1179)
		Rep.
	From draship	
		Wanted Will Observed, 510, 511, 47
		Disease Officer 7 (1986a) 72 and resultance
interes 1	Concernance assess	mani-room, alterna close soom did was

Document (Threshold: 230)



Normal




Photo



Document (Threshold: 230)

Adjusts the lightness or darkness of an **Brightness** image. The higher the value, the brighter the image. Drag the slider to the right or left to increase or decrease the brightness. The range is from -100 to +100. Contrast Adjusts the range between the darkest and the lightest shades in the image. The higher the contrast, the bigger the different grayscale. Drag the slider to the right or left to increase or decrease the contrast. The range is from -100 to +100.




Inclusion		
·		· · · · · · · · · · · · · · · · · · ·
		· ····································
		A second and a second
		and and a second second
10400	A monthly	distant America
		A CONTRACTOR OF A CONTRACTOR O
		· · · · · · · · · · · · · · · · · · ·
	Contractory of the local division of the loc	
		ALC: NOS

Contrast: -50

(Normal)

Contrast: 0

(Normal)



Contrast: +50



Resolution A good control of the resolution results a good detail of an image that scans. The resolution is measured by dots per inch (dpi). Normally, the greater the dpi number, the higher the resolution and the image file size. Be aware that greater resolution takes more time to scan, and more disk space for the scanning image. For your information, an A4 size color image scanned at 300 dpi at True Color mode consumes approximately 25 MB of disk space. A higher resolution (usually means over 600 dpi) is only recommended when you need to scan a small area at True Color mode.

Choose a resolution value from the drop down list. The default value is 200 dpi. Available resolutions are 75, 100, 150, 200, 300, 400 and 600. Or you may choose your desired value by clicking the box in the right side of the drop down list and press the arrow key to select your desired value and then click the Add button to include it in the drop down list. **Note:** The resolution is up to 300 dpi if an imprinter or a MICR reader is installed or connected to the scanner.



Resolution: 75 dpi



Resolution: 150 dpi

Invert Reverses the brightness and the colors in the image. The default setting is Black on a White background. Reverse mode is White on a Black background. For color images, each pixel will be changed into its complementary color at the command of Invert.

'I am not worthy to have you enter my

that is God, I beg all my brothers - those w e who work manually, clerics and lay brothers ards being humble in all things; not to glorify r to become interforly proud because of good w sometimes says or does in them or through tl ord: "Do not rejoice... in the fact that the de : 10:20) Let us be firmly convinced of the fact

Black on White

"I am not worthy to have you enter m

that is God, I beg all my brothers – those v who work manually, clerics and lay brothen rds being humble in all things; not to glorify to become interiorly proud because of good w sometimes says or does in them or through t rd: "Do not rejoice… in the fact that the de 10:20) Let us be firmly convinced of the fac

White on Black

Scan Choice:

- Source
- Auto Document Feeder: Used to scan multiple pages.
- Flatbed: Used to scan a single page. For • example, pages from newspaper clipping, paper with wrinkles or curls.
- Used to scan several Flatbed (book): inside pages from book.
- **Automatic:** Allow the scanner automatically set its scan source. If Automatic is selected and there is document in both the auto document feeder (ADF) and the flatbed, then the scan source will be automatically set to ADF. If Automatic is selected and there is document only in flatbed, then the scan source will be set to flatbed.
- Merge Two Sides into One Image: If you have a sheet-fed duplex scanner with front input tray, you can scan an A3 size document with an innovative method. Thus, fold your A3 size document into A4, and then load the paper in the front tray. Choose Merge Two Sides from the Scan Source option and then the scanner is able to scan both sides of your document and merge two A4 images into one A3 image.


When you select Merge Two Sides into One Image, the Cropping or Multi-feed function will be disabled

Note: This feature must be used with a carrier sheet. Regarding how to load a document with a Carrier Sheet, refer to Section 4.6.2, Other Paper Selection.

Note the options vary based on type of scanner.

Note: If you have purchased a duplex sheet-fed scanner, choose [Merge Two Sides] on the [Scan Source], then the scanner is able to scan both sides of your document and merge them into a single image.

If "Merge Two Sides into One Image" is selected, its choice will be available including "Merge Horizontally", "Merge Vertically", "Merge Vertically (Back Side Flip)". If the reverse side of your document is upside down, choose "Merge Vertically (Back Side Flip)" and the back side will be automatically rotated 180 degrees and merged.



Merge Vertically

Merge Horizontally

Note the options vary based on type of scanner.

Color Matching

The purpose of Color Matching is getting the accurate color. This option uses the default parameters (ICC profile) to adjust the colors of the image.

Choice: None, Document, Photo

- None: Choose "None" to disable this option.
- **Document:** Choose "Document" if your original contains pure text or a mixture of text and graphic since it is an optimal setting for regular business document.
- **Photo:** Choose "Photo" if your original contains photo to reproduce your photo in vivid color image.



Normal



After Color Matching

4.3.3 Scanning color images

The following options are available for scanning color images.

- Brightness
- Contrast
- Resolution
- Invert

4.3.4 Scanning grayscale images

The following options are available for scanning gray images.

- Brightness
- Contrast
- Resolution
- Invert

4.3.5 Scanning B&W images

The following options are available for scanning B&W images.

- Binarization (Dynamic Threshold)
- Resolution
- Invert

Or

- Binarization (Fix Processing)
- Threshold
- Brightness
- Resolution
- Invert

4.3.6 Editing Profiles


The Scanner Properties dialog box allows you to change and save your frequently used scan settings into a profile. You can edit these profiles by renaming or deleting them.

To add a new profile,

- 1. Customize your settings. (For example, change your resolution, image type, cropping method, scan size, or other scan settings.)
- 2. Click the Image tab and then choose "Profiles" to prompt the "Edit Your Profile" dialog box.

Scanner Properties			-				
inage Paper Setting Informatio	6						
Frant Auto Color Detection	Brataton:	Dynamic Threahold	•				
E Front Color	Senativity	20 +					
Port Gay							
Rest BAW	2 colorest	2.9					
	Const	*	Edit Your Profile				
Peer Ads Color Detection	RestAtion (dpl)	200	Eur Tour Prome				
Fee Cala	Inet	Back on White					
New Gray	1 mm	DIRECTOR THE	Profile:	Duplex, BbBW, 200 dpi	•	Add	Delete
Pear SER						lename	Reset
Same settings for both sides							
	* Auto Document Freide						
	<hr/>	1					
Putter	Cathon	•				1	Exit
						-	
Detado		-	OK. Carcel				

3. Click "Add" to enter the name of the profile and then choose "Save".



4. The new profile will be saved and shown in the "Profiles" dropdown list box.

To load a profile,

1. From the Image tab dialog box, choose your favorable profile from the "Profiles" dropdown list box.

Profile:	Duplex, B&&W, 200 dpi	- Add	Delete
	Duples, 1834W/200 dpi Duples, Color, 200 dpi Duples, Gray, 200 dpi Simples, Ra&W/, 200 dpi Simples, Color, 200 dpi Simples, Gray, 200 dpi	Rename	Reset

2. Your favorable profile will be immediately loaded and displayed on Scanner Properties dialog box.

To delete a profile,

1. From the Image tab dialog box, click "Profiles" to prompt the Edit Your Profile dialog box.

t Your Profile			
rofile:	Flatbed	• Add	Delete
		Rename	Reset
			Exit

- 2. Choose the profile you want to delete from the dropdown list box.
- 3. Click "Delete". A Confirm message "Are you sure you want to delete this profile?" is prompted.
- 4. Choose "Yes" to delete or "Cancel" to quit.

To rename a profile,

1. From the Image tab dialog box, click "Profiles" to prompt the Edit Your Profile dialog box.

rofile:	Betsy	- Add	Delete
	Betzy Duplex, B&&W, 200 dpi Duplex, Color, 200 dpi Duplex, Gray, 200 dpi	Rename	Reset
	Flatbed		
	Simplex, B&&W, 200 dpi Simplex, Color, 200 dpi Simplex, Gray, 200 dpi		Exit

- 2. Choose the profile you want to rename from the dropdown list box and then click the Rename button.
- 3. Enter new name for the profile.

Rename a Profile	X
Please enter the new	name of the profile:
Original Name:	Betsy
New Name:	
	Save Cancel

4. Choose "Save" to save the new profile or "Cancel" to quit.

Note:

- The preset default profiles include Flatbed, Simplex-B&W, 200 dpi, Simplex-Gray, 200 dpi, Simplex-Color, 200 dpi, Duplex-B&W, 200 dpi, Duplex-Gray, 200 dpi, Duplex-Color, 200 dpi. If you have a simplex or a sheetfed scanner, the duplex or the flatbed option will not be available.
- If any setting for a current profile has been changed, a [*] sign will be marked before the name of current profile, for example, [* Duplex, Color, 200 dpi]. If desire, click the [OK] or [Scan] button and a dialog box will be prompted to let you save the new profile.

4.4 The Compression Tab

The Compression tab allows you to compress your scanned image and choose the level of compression. Bi-tonal images are normally compressed using CCITT standard called Group 4 (G4). Color and grayscale images are often compressed using JPEG technology. Move the **JPEG Quality** slider to the right or left to increase or decrease the level of compression. Note the greater the compression level, the lower image quality. Default is 50%.

Note that the compression depends on your image editing application. If your image editing application does not support the type of compression format, then either a warning message will appear or the image quality of the compressed file will not be acceptable.

JPEG (Joint Photographic Editor Group). This group developed and lent their name to a file compression standard for color and grayscale images that is widely used by scanners, and software applications. On Microsoft Windows-based systems, a file with the extension .jpg has normally been compressed using this standard.

For scanning color or gray images, the following compressions are available:

- None
- JPEG

For scanning B&W images, the following compressions are available:

- None
- G4

age Compression Paper Set	ting Information		- 22
Front Auto Color Detection	Compression:	None	•]
Front Color	JPEG Quality:		
Front Gray			
Front B&W	1		
Rear Auto Color Detection			
Rear Color			
Rear Gray			
Rear B&W			

The Compression tab dialog box

4.5 The Color Dropout Tab

4.5.1 Color Dropout Selection


The [**Color Dropout**] tab allows you to select either green, red, blue, or a color of your choice to remove the details of the selected color from a scanned image. This feature is used to sharpen your text when using OCR (Optical Character Recognition) software. Note this feature applies only to the gray or black and white image.

Choice: None, Auto, Remove Red, Remove Green, Remove Blue, Custom

- **None**: Does not remove any color.
- **Auto**: Automatically outputs the image with the details of the primary color removed.
- **Remove Red/Remove Green/Remove Blue**: Outputs the image with the details of the specified color removed.
- **Custom**: Specify the color you wish to remove by entering its RGB (Red, Green, and Blue) value respectively.

Advanced Options:

- Quality Mode: Range: 0~20. Default: 10
 When [Quality Mode] is selected, you can determine the color to be dropped out using the [Filter Threshold] slider. A lower value will drop more of the selected color out, while a higher value will leave more of the selected color in.
- **Normal Mode**: Use an optimized setting to determine the color.



Preview the color dropout result:


To preview the color dropout result, please follow these steps:

- Click the [Scanner Properties] icon () on the upper left corner, and choose [Tab] to show available tab names.
- 2. Choose [**Preview**] to show the Preview tab.
- 3. Click the [**Preview**] tab to show the Preview page.
- 4. Load your document to the scanner and click the [**Preview**] button to get a preview image.
- On the [Image] tab, click [Gray] or [Black and White] image mode and then choose [Custom] on the [Color Dropout] tab. A [Preview window] button will be displayed.
- 6. Click the [**Preview window**] button to prompt the [**Preview**] window with the previewed image.

- 7. Move your cursor over the preview image. Your mouse cursor now becomes an Eyedropper.
- 8. Click to select a color which you wish to remove.
- 9. Click and hold your mouse button to view the result after removing the specified color. If the result is satisfactory, click **[OK]** to close the Preview window.



The Preview Window




The Color dropout result

nage	Compression	Color Dropout	Paper	Preview Setti	ing Informati	on		
	Front Auto Color	Detection	Color Dr	ropout:	None		•	
	Front Color				🔽 Adv	anced Processing		
	Front Gray		Mode:		Noma		Ŧ	
V	Front B&W		Filter Th	reshold:		io 🔹		Þ
			Red:		-	71 🔺		
	Rear Auto Color	Detection	Green:			184		
	Rear Color		Blue:			184		
	Rear Gray				<u></u>			
m	Rear B&W	-						

The Color Dropout dialog box

To select a color on the Color palette,

 Click the Color Dropout tab from the Scanner Properties dialog box.



 Choose Gray or B&W from the Image Selection box and click "Custom" from the Color Dropout drop-down menu. The Color palette appears.



 Move your cursor over the palette. The cursor becomes a cross sign.

mage	Compression	Color Dropout	Paper	Preview	Setting	Information		
Front Auto Color Detection		Color Dropout:			Custom			
	Front Color					Advanced Processing		
	Front Gray		Mode:			Normal ~		
V	Front B&W		Filter Threshold:			10 4		
			Red:			82 🜩	_	
	Rear Auto Color	Detection	Green:			193 🜩		
	Rear Color		Bue:			62 🔆		
	Rear Gray		-	_				
	Rear B&W				-			
						Preview Window		

4. Click to choose a color. The RGB values are changed simultaneously.

4.6 The Paper Tab

The Paper tab allows you to define values relating to image output (i.e., Auto Crop or not, Scan Area, OverScan, Multi-Feed Detection).

Copping: Automatic Carrier Sheet Mode Scan Area: Image: Potrait Image: Potrait <t< th=""><th>mage Compression C</th><th>olor Dropout Paper</th><th>Preview Setting In</th><th>formation</th><th></th></t<>	mage Compression C	olor Dropout Paper	Preview Setting In	formation	
Scan Area: None	Cropping:	Automatic		•	
Image: Construction of the second		Carrier Sheet M	lode		
X-Offset: 0.00 Width: 8.50 14.00 Y-Offset: 0.00 Length: 14.00	Scan Area:	None		•	
Y-Offset: 0.00 → Length; 14.00 → Adjustment: Left: 0.00 → Top: 0.00 → Right: 0.00 → Bottom; 0.00 → Background Setting: White Background → Unit: Inches → Feeding Feeding Feeding Feeding Feeding		Portrait		e -	
Adjustment: Left: 0.00 x Top: 0.00 x Right: 0.00 x Bottom: 0.00 x Background Setting: White Background ▼ Unit: Inches ▼		X-Offset:	0.00	Width:	8.50
Right: 0.00 Bottom: 0.00 Background Setting: White Background • Unit: Inches •		Y-Offset:	0.00	Length:	14.00
Background Setting: White Background Unit: Inches Feeding	Adjustment:	Left:	0.00 🌲	Top:	0.00
Unit: Inches V		Right:	0.00	Bottom:	0.00
Feeding	Background Setting:	White Backgroun	d 👻]	
	Unit:	Inches]	
Transport Timeout:	Feeding				
	Transport Timeout:	•	Þ	0 Seconds	
Defaults					OK Can

The Paper tab dialog box

4.6.1 Cropping

Cropping allows you to capture a portion of the document being scanned. Choice: Automatic, Automatic (36"), Fixed to Transport, EOP (End of Page) Detection, Automatic Multiple, Relative to Documents.

Options	Description
Automatic	Automatic adjusts the cropping window according to different document sizes and automatically straighten a skewed document. Use this option for batches of mixed-sized documents.
Automatic (36")	Automatically adjusts the cropping window according to different document sizes smaller than 36" and automatically straighten a skewed image. Use this option for batches of mixed-sized document.
	<i>Note: The availability of this feature varies due to scanner model.</i>
Fixed to Transport	This feature allows you to define the area or zone to be imaged. Use for batches of same-sized documents. If you select this option, you can use the arrow keys to define the x and y offset values, width and length to redefine your scanned area. The Display window will show image placement as you change the values.
EOP (End of Page) Detection	This feature allows you to define the area or zone to be imaged. Use for batches of same-width but different length documents. If you select this option, you can use the arrow keys to define the x and y offset values, width and length to redefine your scanned area. The Display window will show image placement as you change the values.

Automatic Multiple	This option allows you to place various sized documents such as photos, ID Cards, or business cards on the flatbed (if available) and lets you create multiple individually cropped images in one scan. Note: To correctly create multiple images,
	please make sure there is at least 12mm (0.5") of space between each document.
Relative to	This option allows you to crop different
Document	areas on your documents and deliver these images in B&W, Gray, or Color separately. For example, there are applications which require you to store the entire document in B&W and a part of the document in color to save storage space. This is useful for documents where a photograph or signature appears in a consistent area on the document such as resumes, and so on.

The following options are only available when **Fixed to Transport** is selected.

- **X-Offset** the distance from the left end of the scanner to the left edge of the scanning area.
- **Y-Offset** the position from the top end of the document to the top end of the scanning area.
- Width the width of the scanning area.
- **Length** the length of the scanning area.
- **Center:** automatically calculates the x-offset for center-fed feeding based upon document size selected.
- relocate the scan area by click the arrow key on the cross sign while retain the scan size. View the result from the Display window.

The Adjustment option is available when **Automatic** is selected.

 Adjustment —adds a positive/negative margin value Top/Bottom or toward left/right of the image. Adjustment is used when the automatic document feeder is used. Adjustment reduces the possibility of corner clipping on skewed images. To set Adjustment values, use the UP/Down buttons to select where you want to apply Adjustment values: Top/Bottom or Left/Right, and then select the amount of inches/mm/pixels applied. Select a value within the range of 0.00 to 1.00 / -1.00. **Relative to Document:** (used for batches of same-sized documents)


This option allows you to crop different areas on your documents and deliver these images in B&W, Gray, or Color separately. For example, there are applications which require you to store the entire document in B&W and a part of the document in color to save storage space. This is useful for documents where a photograph or signature appears in a consistent area on the document such as resumes, and so on.

The following procedure describes how to reproduce the entire document in B&W and a portion of document (picture) in color.


- 1. On the Paper tab, choose "Relative to Document" or "Fixed to Transport" from the Cropping option.
- Choose your scan size from the Scan Area option. The selected scan size will be displayed in a red rectangular box. This is also the scan size of your entire document. (For example, ISO B5. If you have not chosen a scan area and leave the selection as None, then the default area will be the scanner's maximum.)

nage Paper Pr	review Setting Information		
Front Auto Co	olor Detection	0 1 2 3 4 5 5 7 8 9	
Front Color		•	
Front Gray		14	
Front B&W		2 -	
Rear Auto Co	olor Detection	3-	
Rear Color		4-	A red
Rear Gray		6-	Areu
Rear B&W			rectangula
Scan Area:		7-	
JIS B5 - 182 x 25	57 mm		box
Portrait	Landscape	9 -	
Coffset:	0.67	10 -	
-Offset:	0.00	"-	
Nidth:	7,17	12	
Length:	10.12	14	
Unit:	Inches		
The second second	applies to all modes		


3. Click the Preview tab to display the Preview window. A black rectangular box appears to indicate the max. scan size your have just selected.



4. Click the Preview button to view the entire image in low resolution to correctly crop your relative scan area.



- Select image type from the Image Selection box. The selected image will appear in highlighted color. (For example, Front Color)
- Place your cursor on the Preview window and click your left mouse button. A cross sign will appear as illustrated. Create your relative scan size diagonally by dragging the left mouse button to your preferable size. The selected area will appear in a red box as illustrated.



- 7. Check the B&W image from the Image Selection box to scan the entire document.
- 8. Click the Scan button to start scanning the document in two image types and sizes. (See the result in below.)



The entire document in B&W



The relative area in color

4.6.2 Other Paper Selection

Carrier Sheet Mode:

Check this option to automatically crop the scan window according to your document size when scanning non-standard document (fragile, irregular-size document) with a carrier sheet (optional). Note: The availability of this option varies due to scanner model.


Loading Documents Using a Carrier Sheet

A Carrier Sheet is a plastic sheet specifically used for loading non-standard document onto the scanner. It allows you to scan document that can not be scanned in the regular way. Also, documents larger than A4 size, such as A3 and B4, can be scanned by folding in half, inserting into the Carrier Sheet, and scanning in duplex mode. You can also scan documents that can be damaged quite easily such as photographs, or irregular size documents that are difficult to load directly such as clippings.


To scan document using a Carrier Sheet,

For documents larger than A4/Letter size, such as A3


- a. Fold the sheet to be scanned in half.
- b. Fold the sheet tightly and smooth out crease. Otherwise, the sheet may be skewed during scanning.



1. Open the Carrier Sheet and place the document inside. Align the top of the document to the top of the Carrier Sheet (the printed area). For documents larger than A4/letter size, such as A3 Align the top of the document to the top of the Carrier Sheet (the printed section) and the folded portion to the right edge of the Carrier Sheet so that the document fits into the Carrier Sheet at the upper corner.



For non-standard document Center your document in the Carrier Sheet.



- 2. Load the Carrier Sheet with the gray section (printed section) facing downwards.
- 3. Adjust the paper guides to the width of the Carrier Sheet. Adjust the paper guides so that there is no space between the guides and the Carrier sheet. Space between the guides and Carrier Sheet may cause the Carrier Sheet to become unaligned during scanning, and skew the scanned image.
- 4. Start the scan.

Notice:

- [Carrier Sheet] is available for the models that support the Carrier Sheet.
- Some functions are disabled when [Carrier Sheet] is checked.
- This option may not work properly on some applications.

Scan Area

Choose your desired paper size with the drop-down list box. Or you may select a custom paper size by clicking the **Scan Area** box and then click **Add** to include in the choice.

Choices are listed below:

None
US Letter- 8.5"x 11"
US Legal – 8.5" x 14"
ISO A4 – 21 x 29.7 cm
ISO A5 – 14.8 x 21 cm
ISO A6 – 10.5 x 14.8cm
ISO A7 – 7.4 x 10/5 cm
ISO B5 – 17.6 x 25 cm
ISO B6 – 12.5 x 17.6 cm
ISO B7 – 8.8 x 12.5 cm
JIS B5 – 18.2 x 25.7 cm
JIS B6 – 12.8 x 18.2 cm
JIS B7 – 9.1 x 12.8 cm
Scanner Maximum
Long Page (<118")

Long Page (<118"):

When you need to scan documents whose length exceeds scanner maximum, please choose Long Page. Note if Long Page is selected, the Multi-Feed Detection will not be available. (Note: This option and the maximum allowable document length vary due to type of scanner.)

When **Long Page (<118")** is selected, be sure to specify your document size in the **Length** and **Width** field.

Notice when scanning long page document:

- 1. Pull out the extension in the ADF Paper Tray.
- 2. Secure enough space around the Output Tray to prevent the ejected paper from falling off the Output Tray.
- 3. To ensure the performance, in color mode, set the resolution to be 300 dpi or lower; in Black and White mode, set the resolution to be 600 dpi or lower.
- 4. Depending on your system environments, application, or your specified paper size, there may be insufficient memory to perform scanning.

OverScan

Overscan allows you to add a specific margin at top and bottom or right and left (Options vary based on the type of scanner) of the edge of the image. This is used to reduce possible corner clipping on the skewed images and often applied to a batch of skewed document to be scanned in the auto document feeder. Select a value between 0 and +5 mm. Note the overscan result will not be shown in the Display window and that the availability of the function varies based on type of scanner.

Pre-Feed

Choice: Enable, Disable. If enable is selected, you can set the amount of time the scanner starts pre-feeding your paper after your documents has been loaded into the feeder. The default is

disable. Note: The availability of this option varies due to scanner model.

Transport Timeout

Set the amount of time the scanner will wait and then start auto scan after the first scan job is completed. If you have many separate documents need to be scanned at the same scan settings, this feature is especially useful. The default is 0. The value ranges from 0 to 30 seconds.

Note:

- 1 Within the specified timeout period, if you load your document to the feeder, the scanner starts scanning automatically.
- 2 If your scanner has a flatbed option and you place your paper on the flatbed, after the timeout period, you need to click the Scan button on the TWAIN user interface to start scanning.

Background Setting

This option allows you to set your scan background. Choice: White Background, Black Background.

Note: For a sheet-fed scanner with an auto document feeder, this option is currently available only in the "Auto crop" mode. For a scanner with a flatbed platen, this option is available either in the "Auto crop" or the "Fixed to Transport" mode.



White Background



Black Background

4.7 The Multi-Feed Detection Tab

Multi-Feed Detection

Multi-Feed Detection allows you to detect overlapped document that go through the auto document feeder. Multi-Feed usually occurs due to stapled documents, adhesives on documents, or electro-statically charged document. Note : The availability of the function varies based on type of scanner.

ige Paper Mu	Iti-Feed Detection	Preview	Setting	Information			
Multi-Feed Detect	tion						
Additional Len	igth Detection:			None			
Utrasonic Def	ection						
	ing after Multi-Feed Feed Paper:		Auto				
Clear the Multi-							
Clear the Multi- Multi-Feed Alarm:		C	:\Windo	ws\Media\ding.wav	*	Browse	

Additional Length Detection

Additional Length Detection allows you to define the length of document being multi-fed. This value indicates the additional length exceeding your scan area. The Display window will show the size of the document as you change the value. A value of 0 indicates no additional length detection. The Additional Length Detection is best used when scanning same-size documents in the auto document feeder.

Ultrasonic Detection

Ultrasonic Detection allows you to set overlapped document by detecting paper thickness between documents. Note: The availability of the function varies based on type of scanner.

There are two options available if Multi-Feed is detected.

• Stop Scanning after Multi-Feed

If this is selected, the scanner will stop the feeder and prompt a multi-feed warning message. In addition, the multi-feed paper will be ejected from the scanner automatically.

Note: The availability of the [**Auto Clear Multi-Feed Paper**] feature varies based on scanner type. If your scanner does not support this feature, remove the multi-feed paper manually.

If this is not selected, the scanner will continue scanning the entire document though multi-feed is detected. After the entire document has been scanned, a multi-feed dialog box will be prompted to indicate the page number which has been detected multi-feed and need to be rescanned.

Multi-Feed Alarm

If a wave file is added, the scanner will make a sound alarm if multi-feed is detected yet no Warning dialog box will be displayed.

How to add the sound alarm :

- 1. Click the Browse button on the right side of the speaker icon. The Open dialog box appears.
- 2. Choose your wave file.
- 3. Click the Open button. The wave file is added.

Units

Defines the primary measurement system. Inches, Millimeters, and Pixels are available.

4.8 The Preview Tab

The Preview tab allows you to preview (a low-resolution scan) your image before final scan. This preview image lets you allocate your scan area. You can choose your scan area by the "Scan Area" drop down list box or placing your cursor on the Display window and dragging it diagonally on the Display window. Then, a red rectangle box will appear to indicate the selected area.

Note: If you choose "Automatic Cropping" on the "Paper Tab", then to select a scan area on the Preview tab is not allowed.

nage	Compression	Color Dropout	Paper	Preview	Setting	Information	1
	Front Auto Color	Detection			0	1 2 3 4 5 6 7 8 9	
1	Front Color]			0-1-	պետկավափակակություն	
	Front Gray				1-	The second secon	
V	Front B&W				2 -	na desta de la de la de la de la de la dela de la dela de	
	Rear Auto Color	Detection			3-	The man was near the second se	
	Rear Color					Contraction of the second	
	Rear Gray]			5-	the bar of blocks and	The Display
	Rear B&W				6		Window
Scar	n Area:				7	Later and a second	, maon
ISO	A4 - 210 x 297	mm		•		By provided bardso and a first press. An advancement of the second se	
• F	ortrait	Landsci	вре	_	9-	New York Street	
X-Of	fset:	0.12	*		10	(adaptation page many basis) data (balance and the second seco	
Y-Of	fset:	0.00	*			and the plane of the contract of the second se	
Widt	h:	8.27	* *		12		
Leng	th:	11.69	٢		14		
Unit		Inches		•	-		
-	elected area ap	plies to all mode:	S				

The Preview Tab


4.9 The Enhancement Tab

The Enhancement tab allows you to set following additional image processing settings.

nage	Paper	Multi-Feed D	etection	Preview	Enhancement	Setting	Information	
	<mark>h Hole F</mark> unch Ho	lemoval le Removal						
Back	ground S	etting						
Back	kground	Processing:	None		*			
Sen	aitivity:		4		۴	0		
Fill C	olor		White	9	*			
	eckle e Numbe	c)	0	Pixels	5	Line Re None	emoval	
Desp		-	0	Pivele		Line Re		
Noise	e Radius	1	1	÷ Pixels	8		100 Millimeters	

The Option tab dialog box

PunchYou can remove punch holes from the outputHolescanned image when scanning punched document.RemovalNote the availability of this feature varies
depending on your scanner model.



Punch holes can not be removed when:

- Resolution is set lower than 150dpi
- The hole is near the edge of the document
- The holes are not aligned along the edge of the document
- Punch Hole Removal is available only when "Auto Crop" is enabled. If either "Fixed to Transport", "EOP (End of Page) Detection", "Automatic Multiple", "Relative to Documents" is selected from the Cropping option on the Paper tab, the Punch Hole Removal option will be disabled.

Shadow RemovalWhen 「Flatbed」 on the 「Scan
Source」 option is selected on the
「Image」 tab, the 「Shadow
Removal」 option will be enabled. Click
to remove the shadow on the book spine
when scanning a book.



Background Processing: The [Background Processing]

option allows you to smooth background color or remove it to make image clearer. The option is especially useful for documents with color forms such as invoices.

Choices: None (default), Smooth, Removal

- None no background processing will be performed (default)
- **Smooth** produces images with a more uniform background color. This option improves image quality.
- **Removal -** identifies the background color and then removes it.

Sensitivity: Choice: 0, 1, 2, 3, 4. Default: 0

- The higher the value, the more background color will be kept.

Mode: Auto, Moiré

If [**Smooth**] is selected in the [**Background Processing**] option, then the choices for the [**Mode**] option includes Auto, and Moiré.

- **Auto** uses the factory preprogrammed mode to proceed background smoothing.
- **Moiré** Remove the moiré patterns that appear on the background of the image when scanning printed material.

If [**Removal**] is selected in the [**Background Processing**] option, then the [**Mode**] option will be replaced with [**Fill Color**]. Choices: White, Auto.

- White identifies the background color and substitutes it with white.
- **Auto -** identifies the background color and substitutes it with the color of the largest background zone.



Background Processing: None



Background Processing: Smooth

Free Annual procession that Benefit that a	1-5866-14	Mature Tartage Service Antone 11	ill strange
Series Series	No 023 578-2368	D	to make
true AVISION INC		T Pologies	The second s
ICIENCE BASED INI	NULTRY PARK	Webberg Dates Dates De	and to be a second s
20 CREATION 1 83		Contraction Vancourses	
- HSIN CHU CITY	25. TH	T Papers	mbat
tem TH	E	OBTAR ON ON ME OF	allow a
Rebert Chu SMC Inc.		0988-0415-5806-0913 December 2015	
No. 16, R&D R		the land blig blocks	
Tainan Taiwan, R.O.C.	En Joben	- charles	
	00-1-1-00	For Comparison Instructions, was based of HD page.	568
		8040 8360 0526	n. 040
white Characteric	- http://	Contraction of the local division of the loc	

Background Processing: Removal Fill Color: White

Note: Background color in small zone will not be processed or removed.

Edge Check White or Black if you wish to add white or Fill black edge on the border of your scanned image. Enter the value from 0 to 5 mm. Default value is 0.

ashee.	
N wais skill relatives sky fram the Lancelence of the LSPAs, when there had each heater, analyging the Unit (September) config. Lakeren the sefer are the list.	pendes.
And it was very "Miles,	If while BRI requesting them the functionate of the PODA, when there had been borrow, whenepsing and interception coording between the right and the last.
We your had finder over - Field for the memory Alles on the sporty, Landes for the risk.	And it was very ballen.
On every memory of the city where L éved small sheet calculated, none, croase his investerial too and sequences.	between her beine cars - thes for the manual. Alles for the sporty, Lawson /er the retu-
Losing a very of El-	On anexy come: of the ellip where 1 lived artial shops sold sate tri, have, sheers and wonderful that and separates.
Instrumentary and the set of	A sense was an of ME the stars have a sense any any any and the star on the biblic the stars have a sense any
Namena and a state of the second state of the	competition from Chrve.
The streng methods, into world have spars the marring strapping and ${\rm matting}_{\rm p}$ where ${\rm get}$ is well to a	However, each The wing and authors, while voluce baker speed the rearrang shappens and concise, when you to not have
None of the small lists those they do not low one to vertice any non-three scated. Accuse a on IV does have being related to the scate accused only the three memory benefit in the supermetion well of mend up in the micro-scate.	Naity of the shall fixed shaps there do not have time to relative more have closed, schwarz, as If within Happy Databa balance shallow schwarz, bind inverses bought in the supervised and were out to an other inverse.
Somethings on the way have been cover, a gap as a goality builder with sola wood or 1 grap many children and organ.	Béretilines ar my way hash inverses, i star at a posity batcher who usis accuses the maps choices and apps.
We know wells the real coast at a shop just access the med. I have never new new citize extension in the shop there have been taying my citizes.	The traction racis the read means of a shap just access the stand. I have never serving other subservers in the shap when I have been build my children.
long other doing that, which is also a 7.38 in the events, the soor strumentically dark	using before costing there, which is alread 7.33 in the evening, the steep is interacclasely cost
Driginal	Edge Fill: 5mm (Black)

Original

4-59


Despeckle

Occasionally small dots or specks appear in the background of a scanned image. Remove unwanted speckles provides a cleaner image for OCR (Optical Character Recognition) processing, and also helps to reduce compressed file size.

Define the speckles (also known as image noise) you wish to remove by specifying its number (size) and radius (range). The measuring unit is pixel. The higher the number, the more speckles will be removed.

A plague on thee! Hast thou never an eye in thy head? Canst not hear? -The First Part of King Henry the Fourth: 2.1.26-27 A carrier to Gadshill, the host of a tavern.

Before Despeckle (noise number:0, noise radius:1)



After Despeckle (noise number:22, noise radius:10)

Note:

- The function is currently available for Black and White image only.
- To scan at rated speed, it is recommended to set the noise radius up to 10 pixels.

Line Removal: When **Black and White** image mode is selected on the [**Image**] tab, the [**Line Removal**] option will be enabled. Line Removal erases lines on the image and then reconstructs characters so the OCR (Optical Character Recognition) accuracy can be improved.


Choices: None, Form, Horizontal, Vertical

None – the default mode which does not remove any line.

Form – remove any form in the document.

Horizontal – select [**Horizontal**] and then enter the length of horizontal line to remove only the horizontal line exceeding your specified length.

Vertical – select [**Vertical**] and then enter the length of vertical line to remove only the vertical line exceeding your specified length.



4.10 The Rotation Tab

The Rotation tab allows you to set the following image rotating options:

Rotation					Setting	Inform		
-						63. 		
Hotatio	n Deg	rees :	None		▼ M	ode:	Quick	*
Image Co	ontrol	Options						
Split Im	age:		None		•			
Flip Side	Rotati	ion						
Image Ci	ontrol (Book Options		AV OR	anfold			
	or							

RotateChoose the rotation angle from the drop downImagelist if you wish to rotate your scanned image.

Choice: None, 90°CW(clockwise), 90°CCW(counter clockwise), 180°, Auto based on contents. Auto rotate every even page.

→
2
$\boldsymbol{\omega}$
Rotate 90°CW
153
Rotate 180°

Auto based on contents: Automatically rotate images based on the contents of document. When [¬] Auto based on contents _¬ is selected, its modes will be enabled to let you select more options.

Mode: Quick, Full Text, Complexity

Quick – the default mode to let you rotate images at the fastest speed.

Full Text – the enhanced mode for documents with mixed text orientation.

Complexity – the enhanced mode yet at the slowest speed for document with complex image or text orientation.

Auto rotate every even page:

Automatically rotate 180° on every even page. This is especially useful when you scan the inside pages from a book. As a result, if you choose "Flatbed (book)" from the "Scan Source" option, "auto rotate every even page" will be selected as default.

Note: This option varies based on type of scanner.



4-64

Split By splitting an image, two separate images are created horizontally or vertically. This is useful for documents containing two pages per image when you want to save them as two images (one page for one image). Choice: None, Horizontal, Vertical. Default is None.

Horizontal: Divide one image into the upper half and the lower half.

Vertical: Divide one image into the left half and the right half.





Split Horizontally

Split Vertical

Flip Side
RotationSelect "fanfold" to rotate the image of the
reverse side to 180 degrees.

This is applied to double-sided document which are viewed in portrait are sometime fed into the scanner in landscape or vice versa.

Choice: Book, Fanfold.

If "Book" is selected, the image of the reverse side will not be rotated.

The following illustration shows the documents which should be viewed in portrait are fed into the scanner in landscape



ImageCheck the Mirror box if you wish to reverse the rightControland left side of your image.Option



Original



The Mirror Effect

4.11 The Separation Tab

The Separation tab allows you to enable the detection engine to detect the blank page, barcode, and patch code and then notify the software application which supports document separation to separate your multi-page documents. Choices: Blank Page Removal, Barcode Detection, Patch Code Detection.

nage	Paper	Multi-Fe	ed Dete	ction	Preview	Rotation	Separation	Enhancemen	t Setting	Informat	tion
Blank	Page R	emoval									
	ank Pa	ge Remo	val Three	shold:			i a in i		7. 19. 16		50 %
Barco	de Dete	ction									
E	nable			[Select	Barcode Ty	ype	Zone :	All		-
Patch	code D	etection									
E	nable										

Blank Page
RemovalChoices: None, Blank Page Removal Threshold,
Image Size.None – Do not remove the blank pages.Threshold - Move the slider to the left or right
to define your threshold for the blank page.Image Size – Range: 1~ 10000 KB. Specify
your desired image size to detect the page as a
blank page. For example, if 3 KB is selected,
any page less than 3 KB will be recognized as
blank page.

When the bar code has been detected successfully, a file [avbarcode.ini] will be created and stored in the following path:

Windows XP: C:\Documents and Settings\All Users\Application Data\%PRODUCTNAME%

Vista, Windows 7, Windows 8, Windows 10: C:\ProgramData\%PRODUCTNAME%

Barcode Detection:

Check [**Enable**] to detect barcode and notify the software application for advanced processing. Please note the whole document will be checked and no specific detection area needs to be designated.

Barcode Types:

The following barcode types can be detected.

Two-dimensional codes

- Aztec
- DataMatrix
- PDF417
- QR Code

One-dimensional barcodes:

- Add-2
- Add-5
- Airline 2 of 5
- Australian Post 4-State Code
- BCD Matrix
- Codabar
- Code 128 (A,B,C)
- Code 2 of 5
- Code 32
- Code 39
- Code 39 Extended
- Code 93
- Code 93 Extended
- DataLogic 2 of 5


- EAN 128 (GS1, UCC)
- EAN-13
- EAN-8
- GS1 DataBar
- Industrial 2 of 5
- Intelligent Mail (One Code)
- Interleaved 2 of 5
- Inverted 2 of 5
- ITF-14 / SCC-14
- Matrix 2 of 5
- Patch Codes
- PostNet
- Royal Mail (RM4SCC)
- UCC 128
- UPC-A
- UPC-E

Barcode Zone:

Specify the barcode zone to be detected.

Select **FAII** to checks the whole document and detects barcodes. Or you may speed up the process by specifying a detection area since only the specified area is checked.

Choice: All, Top, Bottom, Left, Right, Bottom Right, Bottom Left, Top Right, Top Left



Choice for barcode zone on a page:

Note:


- Recommended resolution: 200~600 dpi for regular barcode, 300~600 dpi for QR code
- Skewed barcodes may not be recognized correctly.
- Using the same sheet repeatedly may decrease the recognition accuracy due to accumulated dirt on the sheets. If the sheet is not recognized correctly or gets smudged, replace it with a new sheet.

Patch code Detection:

Check [**Enable**] to detect patch codes and notify the software application for advanced processing.

A patch code is a pattern of parallel, alternating black bars and spaces (i.e. a barcode) that is printed on a document. Patch code sheet is most commonly used as a document separator in a stack of document. You can find various sizes of patch codes (PDF) by choosing [Start] menu>[All Programs]>[Avision Scanner Series]>[Patch code] in succession.

Simply print the PDF file to produce the patch code sheet. Insert the patch code sheets to wherever you want the file to separate.



Notes to print the patch codes:

- Use blank white paper.
- Set the scaling to 100%. The sheet is not recognized correctly when printed in a size smaller than the original.
- Do not use toner saving mode. The sheet is not recognized correctly when the print is too light.
- Do not use thin paper in order to avoid bleed-through from the back.
- When you copy a patch code sheet that you printed out, make sure to copy by the same size and brightness as the original copy.
- Use the same sheet repeatedly may decrease the recognition accuracy due to accumulated dirt on the sheets. If the sheet is not recognized correctly or gets smudged, replace it with a new sheet.

4.12 The Setting Tab

The Setting tab allows you to set the following settings:

Cache Memory Size Memory Size Energy Saving Control Energy Saver Enable Energy Saver Off	Default 15 minutes
Energy Saving Control	
Enable Energy Saver Enable Power Off	✓ 15 minutes
ENERGY STAR	4 240 minutes
Show Scanning Progress Show Warning Message Elect Paper Opposte	Tabs: Corport Color Dropout Mult-Feed Detection Preview Rotation Separation Erhancement Imprinter

The Setting tab dialog box

Energy Saving Control	Check the Enable Energy Saver box and move the slider to set the amount of time to start the energy saver after your last action. The range is from 1 to 240 minutes. The default value is 15 minutes.
Enable Power Off	Check the Enable Power Off box and move the slider to set the amount of time to automatically turn off the scanner after your last action. The range is from 1 to 480 minutes. The default is 240 minutes (4 hours). Note the value of "Power Off" has to be greater than or equal to the value of "Energy Saving".

Cache	Mode: None, Page Number, Memory
Cache	Size.
	This option allows you to assign a specified memory size from the available RAM to process the image data. By specifying a smaller memory size, you can free more memory for other applications you are running. By specifying a larger memory size, you can have more memory to process the image data especially when you have a large amount of documents needed to be scanned.
	You can also specify your memory size by the page number. For your information, an A4 color document scanning at 300 dpi consumes approximates 24MB.
	Image Count When the selected cache mode is "none", the image count option allows you to assign number of pages you need to scan. For example, if you wish to scan the first two pages, simply move the page slider to 2, and the scan action will be stopped when the scanning of the first two pages have been completed.

Show Scanning Progress	Check and the scanning progress bar will be shown during scanning.
Show Warning Message	Check to show the warning messages such as "ADF pad count exceeds 50,000 scans (the number varies based on type of scanner). Please replace the ADF pad and reset the pad count."
Save Settings after Closing	Check to save your scanner properties settings after leaving the dialog box. Next time when you open the Scanner Properties dialog box, the previously saved settings will be shown.

4.13 The Imprinter Tab

The Imprinter tab allows you to print alphanumeric characters, date, time, document count and custom message on your scanned image if digital imprinter is selected or at the back of your document if external imprinter is selected.

mage Paper Setting	Imprinter Information			
Digital Imprinter				
Content				
Print All				
Custom:				
Counter:	0001	Date/Time:	None	-
Custom Font:	Normal			
	1.0000000			
Advanced			Print Position	
Font Attributes:	Normal	*	Position:	Middle +
String Orientation:	Normal		X Offset:	0 mm
			Y Offset	0 mm
			-r-onsoc	
Sample				
0001				
				More
				More

Choice: External Imprinter, Digital Imprinter. If you have installed an external imprinter, choose external imprinter. If you do not have an imprinter, choose digital imprinter. Note External Imprinter provides a vertical and rear-side print capability while digital printer provides a horizontal and front-side print capability.

Contents

Print All	Check Print All to automatically print the text at all pages of your documents. Uncheck Print All to print the text for the first page of your documents only.
Custom	Enter your custom text to be included in your print string.
Counter	Show the document count for the scan session. This value is increased sequentially by the scanner.

Date/Time	Choose if you wish to include the date and time in your print string. Format: YYYYMMDDHHSS For example, 20090402170645-check0001 indicates year, month, date, hour, seconds, your custom text and the counter.
Custom Font	Choose your desired font. Choice: Normal, Fixed Width Fixed Width (Mono spaced) fonts have a fixed character spacing. So each character occupies the same width.

Advanced

Font	Choose your font attributes. Choice:
Attributes	Normal, Underline, Double, and Bold.

String Orientation	Choose your string orientation. Choice: Normal, Rotated, Vertical, Vertical Inversion, 90 degrees CW, 90 degrees CCW		
	2010abc	2010abc	
	Normal Rotated		
	2 0 1 0 a b c	с 9 0 1 0 7 0	
	Vertical	Vertical Inversion	
	2010abc	2010abc	
	90 degrees CW 90 degrees CCW		
	If you check the digital imprinter to stamp text on your scanned image, the illustration of normal and rotated string is shown below:		of
	2010abc	2010abc	
	Normal	Rotated	

Print Position	Choose the position you wish to print your string. Move the slider to the right to increase the value or to the left to decrease the value. Range: 0~355mm, default:0 mm The value indicates the height from the bottom of your paper to the last letter of your string. This option is available only if an external imprinter is installed.		
		0001abc 2010 ▲	The value of Print Position

Print Position (for digital imprinter)

Choose the position of your printed string. **Choice: Top, Middle, Bottom, Custom.** If Custom is selected, enter the X and Y offset value to specify the position.

4.14 The Information Tab

The Information tab displays the following system and scanner information.

	Paper	Setting	Imprinter	Information	
Info				*	
CPU:				Intel(R) Core(TM) i3-2120 CPU @ 3.30GHz	
RAM:				1023 MB	
OS:				Microsoft Windows 7 Enterprise Service Pack 1 (Build	7601)
OS Lan	guage:			English (United States)	
Disk Dri	ive:			Fixed drive C:\Total:30717MBFree:10439MB	
				Fixed drive Y:\Total:102398MBFree:10541MB	E
				Fixed drive Z:\Total:102398MBFree:23311MB	
Free Dis	sk Spac	ce:		10439 MB	
Applicat	tion Na	me:		Avision Capture Tool 1.6 (1.9)	
TWAIN	Driver	Version:		6.11.0329'16	
I/O Driv	ver Vers	sion:		0, 9, 2016, 324	
Port Typ	pe:			USB	
ID / Add	dress:			USB	
Optical	Resolut	tion:		600 dpi	
Scanne	r Mode	d:		AD215	
Serial N	lumber:			NO25	*

The Information tab dialog box

The "Report" button :

If you encounter any error message while using the scanner, click the Report button. A report.txt file [Windows XP: C:\Documents and Settings\All Users\Application Data\%PRODUCTNAME%; Vista, Windows 7, Windows 8, Windows 10: C:\ProgramData\%PRODUCTNAME% (C: system drive)] will be generated. Please send this file to the nearest service center for trouble shooting.


The "Reset Roller Count" button :

After scanning over a recommended number of pages (refer to subsequent section 7.4 Replacing the ADF Roller) through the ADF, the ADF roller may be worn out and you may experience problems with document feeding. In this case, it is highly recommended to replace the ADF roller with a new one. (Note the replacement of the ADF roller has to be performed only by authorized service center. Therefore, please return your scanner for roller replacement.) After replacing the ADF roller, click the "**Reset Roller Count**" button to reset the roller count.

Note: The lifetime and the replacing procedure vary based on type of scanne

5. Using the Buttons

The following picture shows the 4 buttons and 1 function screen on the scanner.



5.1 Installing Button Manager V2


Button Manager V2 provides you an easy way to scan your document and then link the scanned image to your designated software application. All this can be done by a simple touch of the button on the scanner. Yet, before you scan, it is recommended to check the button configurations first to ensure a proper file format and a destination application.

5.2 Checking the Button Configurations before Scanning

 Button Manager V2 runs from the system tray. After Button Manager V2 and the scanner driver are properly installed, Button Manager V2 is started and the Button icon will be displayed on the system tray at the bottom right corner of your computer screen.



2. Left-click the Button Manager V2 icon to prompt the following Button Panel.



 The Button Panel shows the first five scanning buttons. Right-click the button (function) you wish to check. The Button Properties window appears.

		Name of the	Selected Button		
	Button Properties - iScan (OC	R)		×	
Button	Basic Image Adjustment Co	lor Dropout Image Processing Mor	re Settings		
Name —	iScan (OCR)	Resolution(dpi):			
Image Mode —	Auto	Paper Size: Auto Cro	op & Deskew 🛛 👻		
Selection	Color	Duple:	×	Ba	asic Scan
Box	□ Oray □ OBack and White	Advanced Settings: 🔲 Use T	WAIN Setup	Pa	arameters
Folder and	File Location				
file name	Directory: C:\Docum	nents and Settings/void/My Documents/	My Pictures Browse		
for the	File Name: Image_##	****	More		
scanned image	File Format: OCR (For	iScan Only)	Properties		
Soop To	Destination: 🚵 iScan		🖌 Setup		
Scan To destination and settings	Description: Open you (after OC	r application, scan and insert the scann R) directly to your application.	ed image or editable text 🔜		
OCR	OCR Language: Chinese 1 OCR Zone: None	Traditional 💽 Scan Count: 0	Sample		
settings	No. of Recognized Character		5		
			OK Cancel		

If you wish to change the setting, use this window to reset the setting for the file format, destination application, or other scan settings.

4. Click the OK button to leave the window.

5.3 Scanning From One Touch of the Buttons

- 1. Adjust the paper guide for the width of paper and load the document with their tops into the automatic document feeder.
- Check the button name on the LCD screen to ensure if you are selecting the proper scan settings and destination application. (For example, if you wish to scan with Button, "Scan to App", which opens Microsoft Paint and displays the scanned image in the window of Microsoft Paint, the LCD screen should show "Scan to App").
- 3. Press the **Scan** button on the scanner.
- 4. After the scanning is finished, the Microsoft Paint software will be launched and the scanned image appears in the main window of Microsoft Paint as below.

General	Document feeding mode	Flatbec
Specifications:	Technology	
and a second	Optical resolution	
	Scanning speed	
	RAM	
	ADF min. paper size	4.5 incl
	ADF max. paper size	8.5 inc
	Flatbed max. paper size	8.5 inch
	ADF capacity	
and the second	Operation environment	10
	Storage environment	-2
	Noise	
	Dimensions(H x W x D)	
	Weight	
Сору	First copy out	Color mod
Specifications:	Color copy speed	
and the second	B/W copy speed	
	Copy resolution	
	Copy scaling	
	Multiple copies	

Note:

- 1. For details information on how to use the Button Manager V2, please refer to the user's manual in the supplied CD.
- 2. You may also use Button Manager V2 on your desktop by starting Button Manager V2 from All Programs or double clicking the Avision Scanner Utility from the Control Panel.

6. Maintenance

6.1 Cleaning the Glass

The procedures

- Use a clean and lint-free cloth wet with isopropyl alcohol. (95%)
- 2) Open the document cover as shown in Figure 6-1. Wipe the document glass.
- 3) Close the document cover. Your scanner is now ready for use.



Figure 6-1 The cleaning area

7. Troubleshooting

7.1 Questions and Answers

Question:	Why does my scanned image	
	always come out too dark?	
Answer:	 Please adjust the screen settings to sRGB. Please adjust the brightness settings on the screen from application software. 	

Question:	When I choose optical resolution to be 600 dpi, the "auto crop" and "deskew" functions will be disabled.
Answer:	Since to perform auto crop and deskew consumes great deal of system memory, it is suggested if you wish to perform "auto crop" and "deskew" functions, please choose your optical resolution to be smaller than 600 dpi to prevent a error message.

7.2 Technical Service

Before contacting Avision, please prepare the following information by referring to Section 4.14, The Information Tab:

- Scanner serial & revision number (located on the bottom of the scanner);
- Hardware configuration (e.g., your host CPU type, RAM size, free disk space, display card, interface card);
- The name and version of your scanning software application;
- The version of your scanner driver.

Please call us at:

Headquarter

Avision Inc. No. 20, Creation Road I, Science-Based Industrial Park, Hsinchu 300, Taiwan, ROC TEL: +886 (3) 578-2388 FAX: +886 (3) 577-7017 E-MAIL: service@avision.com.tw Web Site: http://www.avision.com.tw

US and Canada Area

Avision Labs, Inc. 6815 Mowry Ave., Newark CA 94560, USA TEL: +1 (510) 739-2369 FAX: +1 (510) 739-6060 E-MAIL: support@avision-labs.com Web Site: http://www.avision.com

China Area

Hongcai Technology Limited

7A,No.1010, Kaixuan Road, Shanghai 200052 P.R.C. TEL :+86-21-62816680 FAX :+86-21-62818856 E-MAIL :sales@avision.net.cn Web Site: http://www.avision.com.cn

Europe Area

Avision Europe GmbH

Bischofstr. 101 D-47809 Krefeld Germany TEL: +49-2151-56981-40 FAX: +49-2151-56981-42 E-MAIL: info@avision-europe.com Web Site: http://www.avision.de

Espaço Brasil

Avision Brasil Ltda.

Avenida Jabaquara, 2958 - Cj. 75 - Mirandópolis – CEP: 04046-500 - São Paulo, Brasil TEL: +55-11-2737-6062 E-MAIL: suporte@avisionbrasil.com.br Web Site: http://www.avisionbrasil.com.br

8. Specifications

All specifications are subject to change without notice. For the most up-to-date and detailed specifications, please refer to our web site at http://www.avision.com

Model Number	BT-1007B
Scanner Type	Flatbed
Scanning Mode	Color/Grey/Black & White
Optical Resolution	600 dpi
Light Source	LED
Maximum Scanning Size	297 x 420 mm (11.7 x 16.5 in.)
Interface	High Speed USB 2.0
Power Requirement	24Vdc, 2.0A
Humidity	20% to 80% RH
Operation Temperature	10°C to 35°C
Dimension (WxDxH)	585 x 485 x 96 mm (23 x 19.1 x 3.8 in.)
Weight	7 kg (15.4 lb.)