


### **Document Scanner**

### **User's Manual**



Regulatory model: DT-1106B / DT-1110B

### Avision Inc.

### Trademarks

Microsoft is a U.S. registered trademark of Microsoft Corporation.

Windows, Windows Vista, Windows 7, Windows 8 and Windows 10 are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries. IBM, IBM PC are registered trademarks of International Business Machines Corp.

Other brands and product names herein are trademarks or registered trademarks of their respective holders.

### Copyright

All rights reserved. No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, electronic, mechanical, magnetic, optical, chemical, manual, or otherwise, without the prior written permission of Avision Inc.

Material scanned by this product may be protected by governmental laws and other regulations, such as copyright laws, the customer is solely responsible for complying with all such laws and regulations.

### Warranty

The information contained in this document is subject to change without notice.

Avision makes no warranty of any kind with regard to this material, including, but not limited to, the implied warranties of fitness for a particular purpose.

Avision shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this material.

#### Federal Communications Commission (FCC) compliance information statement Part 15

The product has been tested and found to comply with the limits for a Class A digital device pursuant to Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference and (2) this device must accept any interference received including interference that may cause undesired operation.

The FCC Class A limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual may cause harmful interference in which case the user will be required to correct the interference at his own expense.



As an ENERGY STAR<sup>®</sup> Partner, Avision Inc. has determined that this product meets the ENERGY STAR guidelines for energy efficiency.

# CE

### **European Union Regulatory Notice**

Products bearing the CE marking comply with the following EU Directives:

- Low Voltage Directive 2014/35/EC
- EMC Directive 2014/30/EC
- Restriction of the use of certain hazardous substances (RoHS) Directive 2011/65/EU

CE compliance of this product is valid if powered with the correct CE-marked AC adapter provide by Avision.

The Product satisfies the Class A limits of EN55032, EN55024 and safety requirements of EN62368-1.

\*This machine is certified as Class 1 LED product. This means that this machine does not produce hazardous laser radiation.

### **CE Warning**

This is a class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

### Disposal of Waste Equipment by Users in Private Union



This symbol on the product or on its packaging indicates that the product can not be disposed of with your other household waste. Instead it should be sent to appropriate facilities for recovery and recycling in an effort to protect human health and the environment. Fore more information about where you can drop off your waste equipment for recycling, please contact your local city office, your household waste disposal service or the shop where you purchased the product.

### **System Requirements**

CPU:	Intel <sup>®</sup> Core™ 2 Duo or higher
Memory:	32 bit: 2 GB 64 bit: 4 GB
Optical Drive:	DVD-ROM Drive
USB Port:	USB port 2.0 (compatible with USB 1.1)
Operating	Microsoft Windows XP(SP3), Windows Vista, Windows 7, Windows 8 (32 bits/64 bits), Windows 10 (32 bits/64 bits)

### Product Safety Guide

Please clearly read all these instructions, and follow all instructions and warnings before installing and using the device.

The following indications are used in this document to obviate any chance of accident or damage to you and/or the device.

<sup>≜</sup> <i>WARNING</i>	Indicates potentially hazardous situations, which if instructions are not followed, could result in death or serious injury.
⚠ CAUTION	Indicates a potentially hazardous situation which, if instructions are not followed, may result in minor or moderate injury or damage to property.

### <sup>▲</sup> WARNING

- Use only the AC power adapter that came with your device. Using any other AC power adapter could cause fire, electrical shock, or injury.
- Use only the AC power cord and USB cable that came with your device and avoid abrasions, cuts, fraying, crimping, and kinking. Using any other AC power cord and USB cable could cause fire, electrical shock, or injury.
- Do not place objects on top of the AC power cord, and do not allow the AC power adapter or the AC power cord to be stepped on or run over.
- Place the device and its AC power adapter near an electrical outlet where the AC power adapter can easily be unplugged.
- If you use an extension cord with the device, make sure that the total ampere rating of the devices plugged into the extension cord does not exceed the cord's ampere rating.
- Place the device close enough to the computer so that the interface cable can easily reach between the device and the computer.

- Do not place or store the device or its AC power adapter:
  - Outdoors
  - Near excessive dirt or dust, water, or heat sources
  - In locations subject to shocks, vibrations, high temperature or humidity, direct sunlight, strong light sources, or rapid changes in temperature or humidity
- Do not use the device with wet hands.
- Never disassemble, modify, or attempt to repair the AC power adapter, device, or device option by yourself, except as specifically explained in the device's documentation. This could cause fire, electrical shock, or injury.
- Do not insert objects into any opening, as they may touch dangerous voltage points or short-out components. Beware of electrical shock hazards.
- Unplug the device and the AC power adapter, and refer servicing to qualified service personnel under the following conditions:
  - The AC power adapter or plug is damaged.
  - Liquid has entered the device or the AC power adapter.
  - Object has entered the device or the AC power adapter.
  - The device or the AC power adapter has been dropped, or the case has been damaged.
  - The device or the AC power adapter does not operate normally (i.e. appearance of smoke, strange smell, odd noise, etc.), or exhibits a distinct change in performance
- Unplug the device and the AC power adapter before cleaning.

### **A** CAUTION:


- Do not locate the device on rackety or aslope tables. Do not locate the device on unstable surface. The device may fall down and this may result in injury.
- Do not place heavy objects on the unit. It may cause unbalance and the device may fall down. This may result in injury.
- Store the AC Power cord/USB cable bundled out of the reach of children to avoid the risk of injury.
- Keep plastic bags bundled out of the reach of children or throw them away to avoid the danger of suffocation.
- If you are not going to use the device for a long period, unplug the AC power adapter from the electrical outlet.


### 1. Introduction

Congratulations on your purchase of the color image scanner. Avision is one of the leading companies to make high quality color image scanner. With this scanner, you can you scan your multi-page documents from the auto document feeder at a rated speed or scan irregular singlepage document from the flatbed.

Before you install and operate the new scanner, please take a few minutes to read through this manual. It provides proper instructions for you to unpack, install, operate and maintain the scanner.

The following figure indicates the package contents. Please check all the items against your checklist. If you do not receive all the items, please contact your authorized local dealer immediately.





- 1. Scanner Main Unit
- 2. Software CD/Quick Guide
- 3. USB Cable
- 4. Power Adapter & Power Cord

#### Note:

- 1. Only use the AC adapter DA-48M24 by APD included in the machine. Using other AC adapters may damage the machine and void the warranty.
- 2. Please unpack the packing carefully, and check the contents against the checklist. If any items are missing or damaged, please contact your dealer immediately.
- 3. To access more service supports, visit www.avision.com to register your Avision's product.

### 2. Scanner Installation

### Precautions

- Keep the scanner out of direct sunlight. Direct exposure to the sun or excessive heat may cause damage to the unit.
- Do not install the scanner in a humid or dusty place.
- Be sure to use the proper AC power source.
- Place the scanner securely on an even, flat surface. Tilted or uneven surfaces may cause mechanical or paper-feeding problems.
- Retain the scanner box and packing materials for shipping purposes.

### 2.1 Unlocking your scanner

To protect the scanning unit from damage during transportation, a lock switch is designed to keep the scanning unit from moving. To unlock the scanner, move the lock switch to the unlock position as shown in Fig. 2-1.



Figure 2-1 Unlocking the Scanner



Scanning unit at this position before locking the scanner

Figure 2-2 Home position

**Note:** If the scanning unit is not located at the front of the scanner before transporting the scanner, be sure to do the follows:

- 1. Turn on the scanner. The scanning unit should move to the front of the scanner.
- 2. Press the lock switch down to the "Lock position".
- 3. The scanner is now ready to transport.

### 2.2 Installing the Scanner Driver and Connecting the Cables


#### NOTE:

- 1). The Windows system CD may be required when installing on some PC's.
- 2). To ensure your computer can identify the USB scanner, please install scanner driver first before connecting the scanner to your computer.
- 3). The scanner driver contains TWAIN, ISIS and WIA driver. After the installation of scanner driver is completed, this scanner allows you to scan via a TWAIN, ISIS, or a WIA interface. Start your TWAIN-compliant image editing software application to select a TWAIN or WIA user interface or your ISIS software to select an ISIS user interface. You may also launch Microsoft's Scanner and Camera Wizard to scan via a WIA user interface.

### 2.2.1 Connecting to Power


#### Before connecting, make sure the power switch is off.

Plug the small end of the power adaptor into the power jack of your scanner. Insert the other end to an appropriate power outlet.



### 2.2.2 Turning on the Power

Press the Power Switch button on the front panel, the Power LED will be lit. To turn off the scanner, press the Power Switch button for about 3 seconds, the Power LED will be off.



### 2.2.3 Installing the Scanner Driver

- 1. Place the supplied CD-ROM onto your CD-ROM drive.
- The software installation graphic appears. If not, run "setup.exe".




#### Contents on the installation graphic:

- **Install Scanner Driver:** To communicate with your scanner, you need to install the scanner driver.
- Install Button Manager V2: To use the buttons on the scanner, you need to install Button Manager V2. To ensure Button Manager V2 works properly, please FIRST install scanner driver before installing Button Manager V2.
- **Install AVScan X:** To scan and organize your multi-page document(s), you can install the software application to manage them easily and effectively.
- View Manual: Click "View Manual" to view or print the detailed user manual for the scanner and Button Manager V2 respectively.
- Click Install Button Manager V2 to install the Button Manager V2 software and then click Install Scanner Driver to install the scanner driver on your computer.

### 2.2.4 Connecting to Computer

1. Connect the **square end** of the USB cable to the USB port of your scanner. Connect the **rectangle end** to the USB port of your computer.



- 2. The computer should detect a new USB device and prompt a **"New Hardware Found"** message.
- 3. By following the on-screen instructions, click the **Next** button to continue. When the certification screen appears, click **Continue Anyway** to complete the installation.
- 4. When the **Finish** dialog is prompted, click the **Finish** button.

### 3. Completing Your First Scan

### 3.1 Loading Your Paper

### 3.1.1 Notice on Using the ADF


Before using the ADF, please make sure that your paper meets the following specifications:

- Document(s) can range in size from 148 x 210mm (5.8 x 8.3 in.) to 297 x 420 mm (11.7 x 16.5 in.)
- Document(s) can range in weight from 60~105 g/m<sup>2</sup> (16 to 28 lbs)
- Document(s) should be square or rectangular and in good condition (not fragile or worn).
- Document(s) should be free of curl, wrinkle, tears, wet ink, or punch holes.
- Document(s) should be free of staples, paper clips, paper sticky notes.

### 3.1.2 Placing Your Document in the ADF Paper Tray


#### Fanning Your Document

Standard paper size should feed easily through the scanner. To avoid occasional paper jam when automatically feeding multiple documents, loosen the paper before loading.



### **Document Feeding**

Place your document with the text face up and make the top of the page point to the document feeder as shown below. Center your document with the paper guides and make sure the edge of document touch the paper guides.



### 3.2 Placing paper on the document glass

Place your document face down on the document glass and align the document to the reference mark as indicated.



### 3.3 Verifying Your Scanner Installation

To verify if your scanner installation is correct, Avision provides you a useful test program called Avision Capture Tool. With this tool, you can perform simple scans and view the captured images. In addition, it helps you complete your scan at a rated speed.


The following procedure describes how to verify your scanner installation. If the installation is not correct, please review the preceding section to check if the cable connection and scanner driver have been successfully installed.

Before you begin, be sure the scanner is on.

 Select Start>Programs>Avision xxx Scanner>Avision Capture Tool. The Select Scanner Model dialog box will be displayed.



2. Select your driver type and scanner model and click OK. The following Avision Capture Tool dialog box will be displayed.




- Choose your desired file format from the File Format drop down list box. (Default is JPEG, other choice includes TIFF, MTIFF, PDF, MPDF, GIF, and BMP.) The supported file formats vary depending on your scanner model.
- Type your desired folder name and file name in the File Path box. (Default is C:\Documents and Settings\User Name\My Documents\My Scan\Image.)

**Note:** If you do not wish to save the scanned image, deselect the Save button since default is Save Enable. In this case, the thumbnail view will be disabled. And therefore, after viewing all the scanned images, only the last one will remain on the screen.

5. Click the Setup button (<sup>Setup</sup>) or choose Setup from the File menu to prompt the Scanner Properties dialog box.

	Grie Scanner Properties	1		×
Image Selection Box	Front Auto Color Detection Front Color Front Gray Front Gray Front BAW Rear Auto Color Detection Rear Color Front BAW	Binatization: Senativity: Brightness Contrast: Resolution (dpl): Invert:	Dynamic Threshold         ▼           20             0             200         ▼           Black on White         ▼	8 9 11
	Same settings for both sides Scan Source Profiles	Auto Document Feede	• • • • • • • • • • • • • • • • • • •	Cancel

- From the Image Selection Box, choose your desired image type for your scanned image. (Default is Front B&W) If you have a duplex scanner, choose Front and Rear to scan both sides of your document.
- 7. Click OK to quit the Scanner Properties dialog box. (To learn more details about the Scanner Properties dialog box, please see the subsequent chapter, *Using the Scanner Properties Dialog Box*.)
- 8. Place your document face down on the document glass or face up in the auto document feeder.
- In the Scan Validation dialog box, click the Scan button
   ( scan ) or choose Scan from the File menu.
- 10. The document will be scanned and displayed in the Scan Validation screen. After the scanned images have been displayed, your scanner installation verification is completed.



11. You can view the scanned image in Fit Page (

Actual Size (100%) button ( $\square$ ) from the Viewing toolbars at the right side.

12. Click the Close box or Quit from the File menu to exit the Scan Validation Tool.

3.4	Α	Glance	of the	Scanner	<b>Properties</b>	<b>Dialog Box</b>
-----	---	--------	--------	---------	-------------------	-------------------

Front Auto Color Detect	on Binarization:	Dynamic Threshold	*
Front Color	Sensitivity:	20 1	
Front Gray	Brightness.	0 4	
Front B&W	Contrast:		
Rear Auto Color Detect	an Resolution (dpi):	200	•
Rear Color	Invert:	Black on White	•
Rear Gray			
Rear B&W			
Same settings for both sid	es		
Scan	Source: Auto Document Feed	er 🔽	
Profil	Custom	-	i
- Prove			

1. Tab Options	Choice: Image, Compression, Color Dropout, Paper, Multi-Feed Detection, Preview, Options, Settings, Information.
2. Image Selection Box	Choose your image type and the side of document you wish to scan. Options vary based on type of scanner.
3. Brightness	Adjust the brightness level from -100 to +100.
4. Contrast	Adjust the contrast level from -100 to +100.
5. Resolution	Determine the quality of the scanned image. The industry standard is 200 dpi.
6. Invert	Reverse the color of your scanned image.
7. Scan Source	Choice: Auto Document Feeder, Flatbed, Flatbed (Book), Automatic (varies due to different scanner model)
8. Defaults	Reset all values on the tabs to the factory default settings.

### 4. Using the Scanner Properties Dialog Box

The Scanner Properties dialog box allows you to configure the scanner's settings. It consists of several tabbed windows each of which will be described in this chapter.

**Note:** In this chapter, all options are available based on a duplex (double-side) scanner. If you have purchased a simplex (single-side) scanner, all options are available for single sided only.

ber Setting	Information					
Auto Color De	tection	Binarization:	Dynamic	Threshold	•	
Color		Sensitivity:	20	•		۲
Gray		Brightness				F
B&W				*		
	tection	Resolution (dpi):	200			
		Invert:	Black on	White	•	
		Auto Document Feede	r	•		
F	Profiles	Custom		•		
	Auto Color De Color Gray B&W Auto Color De Color Gray B&W ettings for bot	Auto Color Detection Color Gray B&W Auto Color Detection Color Gray B&W ettings for both sides	Auto Color Detection Binarization: Color Senstivity; Gray Bightness: Contrast: Contrast: Contrast: Contrast: Contrast: Invert: Baw contrasts Contrast: Auto Color Detection Resolution (doi): Invert: Color Color Detection Resolution (doi): Invert: Color Color Detection Resolution (doi): Invert: Color Color Detection Resolution (doi): Color Color Detection Resolution (doi): Color Color Col	Auto Color Detection Binarization: Dynamic Color Senstivity; 20 Gray Bightness: 0 Contrast: 0 Contrast: 200 Contrast: 200 Invert: Black on Baw ettings for both sides. Scan Source: Auto Document Feeder	Auto Color Detection     Binarization:     Dynamic Threshold       Color     Senstivity;     20 4       Gray     Bightness:     0 4       BAW     Contrast:     4       Color Detection     Resolution (dpi):     200       Color     Invert:     Black on White       BAW     Scan Source:     Auto Document Feeder	Auto Color Detection     Binafization:     Dynamic Threshold       Color     Senstivity:     20        BaW     Dightness:     0        Cohrast:     4       Auto Color Detection     Resolution (dpi):       Color     Invert:       Baw     Each on White       Color     Invert:       Back on White     •

The Scanner Properties dialog box

	Front Aut	o Color De	etection	Binarization:	Dynamic	Threshold	•	
	Front Cold	or		Sensitivity:	20	4		•
	Front Gra	у		10.11.1				
1	Front B&V	N		Brightness:	0	4		F
				Contrast:		*		۲
	Rear Auto	o Color De	etection	Resolution (dpi):	200		•	
	Rear Cold	or		Invert:	Black on	14.0		
	Rear Gra	y		invert:	Black on	vvnite	•	
1	Rear B&V	v						
S	ame settir	_	th sides Scan Source:	Auto Document Feede	r	•		
			Profiles	Custom		•		

### 4.1 Buttons on the Scanner Properties Dialog Box

The buttons on the Scanner Properties dialog box

Buttons	Description
Defaults	Click the <b>Defaults</b> button, the factory default settings will be shown on each tab.
Cancel	Click the <b>Cancel</b> button to leave the Scanner Properties dialog box.

The following table shows the default settings :

Tab name	Default settings
Image	Image : Front B&W
	Binarization : Dynamic Threshold
	Resolution : 200 dpi
	Invert : Blank on White
	Scan Source : Auto Document Feeder
	Threshold : None
	Brightness : None
	Contrast : None
Compression	None
Color Dropout	None
Paper	Cropping : Automatic
	Deskew : Yes
	Orientation : Portrait
	OverScan : 0.00
	Note: The availability of this option
	varies due to scanner model.
	Unit : Inch
Multi-Feed Detection	None
Preview	None
Options	Rotation Degrees : None
	Blank Page Removal : None
	Edge Fill : White , 0 mm
	Image Control Option : None
Setting	Enable Energy Saver : Enable, 15
	minutes after last scan action
	Show Scanning Progress : Yes
	Show Warning Message : Yes
	Save Settings after Closing : Yes
Imprinter	Digital Imprinter

### 4.2 Showing or Hiding Tabs

The [**Scanner Properties**] dialog box is displayed in default with three basic tabs - Image, Paper, and Information. To show more tabs, click the [**Scanner Properties**] icon to access more scan settings.

To show more tabs,

- Click the [Scanner Properties] icon (Section 2) on the upper left corner, and choose [Tab] to show available tab names. The available tabs include Compression, Color Drop out, Preview, Rotation, Separation, Multi-Feed, Options, Settings, and Imprinter. (Note: the options vary based on scanner model.)
- Choose the tab you want to display. The selected tab will be shown with a check mark and then displayed in the [Scanner Properties] dialog box.
- **3.** To access the settings, click the selected tab on the top of the [**Scanner Properties**] dialog box. The page of the selected tab will be displayed.

To hide a tab window,

- Click the [Scanner Properties] icon ( ) on the upper left corner, and choose [Tabs] to show available tab names.
- 2. Choose the tab you want to hide. Then, the selected tab will be hided in the [Scanner Properties] dialog box.

Note: The **[Image]**, **[Paper]**, and **[Information]** tab can not be hided since they preprogrammed to be displayed by default.

#### User's Manual

Tabs	<u>- 16</u>	Compression Color Dropout				
Move Close Alt+F4		Multi-Feed Detection	ynamic	Threshold	•	
Front Color		Preview Rotation	20	•		۲
Front Gray Front B&W		Separation	0	4		Þ
Front B&W		Enhancement Setting		4		۲
Rear Auto Color De	tec	Imprinter	200		•][	
Rear Gray		Invert:	Black on	White	•	
Come collines for both						
Same settings for both S	n sides can Source	e: Auto Document Feeder		•		
S		Auto Document Feeder		•		
S	can Source	Plate Decament record		•		
S	can Source	Plate Decament record		•		
S	can Source	Plate Decament record		•		

### 4.3 The Image Tab

The Image tab allows you to choose the front side and (or) the rear side of your document, the type of image, and to set several basic scan settings. Note that except for the resolution, you can set individual scan settings for the front side and the rear side. For example, all settings in the Image tab, Compression tab, Color Dropout tab can be set individually for the front and the rear side. However, the settings in the Paper tab, the Option tab, and the Setting tab have to be set the same for the front and rear side.

Front Auto Color Detection	Binarization:	Dynamic	Threshold	•	
Front Color	] Sensitivity:	20	4		۲
Front Gray Front B&W	Brightness:	0	4		F
al.f	Contrast:		*		۴
Rear Auto Color Detection	Resolution (dpi):	200		•][	
Rear Color Rear Gray	] Invert:	Black on	White	•	
Rear B&W	1				
Hear B&W Same settings for both sides Scan Sourc	e: Auto Document Feede	ſ	•		
Same settings for both sides	e: Auto Document Feede	if	•		
Same settings for both sides Scan Sourc		if 			


The Image tab dialog box

#### 4.3.1 The Image Selection Box

	Front Auto Color Detection
✓	Front Color
	Front Gray
	Front B&W
ш	- Tork Darr
	Rear Auto Color Detection
	Rear Auto Color Detection

The Image Selection box includes the image type and document side option. If you wish to scan both the front side and the rear side of your color document, you can check both Front Color and Rear Color at the same time. Note the options vary based on type of scanner.

### Example 1 : Scanning a two-sided color document, both sides in color



### Example 2 : Scanning a two-sided color document, one in B&W, the other in color




Image Type	Description
Color	Choose Color if you wish to scan a color image for your original in color.
Gray	Choose Gray image if your original contains actual shades of gray.
B&W	Choose B&W if your original contains only text, pencil or ink sketch.

It had it. If it have no frame the barradients of the 1975s, when these had an is breaks, adverging the including of our Cr., because the next and the t and Plane Lary Tolpes, Neurona had folder over - Place for the mesons, Albert of the courty, Lancos for Karles. On anous warm-of the day class is and instal strate to Academi, Alth, or calls had warmedid and and courted and the court of the day class is a strategies. No vor of the Focusion have a strong sense of East and blockly and a huge price in both day In section, us well as bread there were stronge. The shart of rough, doned with flow an institute 40.5 bit is particle. So being us had never scene rouse parts. Harrisson, M., & Harrisson, J., & Bern, S. and Bernmann, P. Karaka, Panas, M. S. Sangara, and S. Sangara. Bond S. Andreas, and S. Sangara. Bond S. Sangara. Social Sciences and Sciences and Sciences and Sciences and Sciences and Sciences and Sciences. Sciences and Sciences and Sciences and Sciences and Sciences and Sciences. Sciences and S for cos, in the present acces, same stand-case factors and over restrictly blev about whether the they all process produce factors factory. The Salida Galactel and of an elegand to be seen souther the limit of the second In resistance, the vesters in a set of a relax law, it was not true to a stational, the present that a vert assigned in the foreign the lawsame effect of the or angle of the foreign and way when down. of the new of the first second motifics and and any 20 years ago The hear-reases that paid for it - that problem drives that people starting to key hear-se-tively new real, designed and well priorit - one straight of to despect a sparse these all publics for a form. Ministeries graphy The struct and medical, whereastly have spect the monthly should got a safety, where go to wait task. Farry of the proof local strate they do not have to us to next any more threat scientish documents on TV down happentiation features and an and they give more more bright in the successful of their down of the downward. formations on my way to I fitte at a positive balance with a data of HACE OFFICE THE GOLD. Has leading only the first Cold of a 7000 Just, to Call University of 1 June reveal mean any silities OCCOMPLIATE The sharp offices 1 June 2000 Just (or Call University) any call Line. this the events, the two 's becausedy dues





B&W

Gray

Color

#### Front/Rear Auto Color Detection:

Click to automatically detect and scan the front or the rear page of your color document in color image mode. If your document is in colors, the scanner will automatically scan the document into a color image. If your document is non-color, you can choose the output to be either B&W or Gray from the Non-Color Selection option. This option is useful when you have a mixture of color and non-color document.

Note: If you choose Front Rear Auto Color Detection, you can not specify the image mode of your rear page and vice versas.

#### Modes of Auto Color Detection:

If [Front/Rear Auto Color Detection] is selected, its modes will be displayed. Choice includes Normal, Ignore Paper Color. For paper with background color such as invoices, choosing [Ignore Paper Color] will automatically remove the background color and enhance the detection accuracy.

	INVOICE				I	NVOICE		
	(45): 03:323:43 ENVOICE of 55th Spars Fach for Automotion South	Bule : 3uly 30, 2002		6956 03-123-43 INVOICE of 51	lais Spare Paris for Auto	Date metitor Seals	34by 38, 20	42
	For account and sink of Moores. ABC Manufacturing Co., Lab			For account and tasks	of Masers. ABC Manuf	actualing Co., Liff.		
	3236 Illiett Austras , South, WR 90011 U.S.A. Tol : 253-923-66	99 est 2336 Tux : 253-922-6688		3234 Ellinit Assure , 1	inalle, WA PIELE U.S.A.	Tel: 253-923-6699 est.2336 E	hx:253-922-6	488
	Alls Mr Boold Warg Shippel by SSTTubuelegier Inc. For U.Line Express			Alls: Mr. Deal Way	1			
				Shipped by SSTTed	In U-Lin	Dar U-Line Express		
	Sulling on or about 3 sky 30, 2002 Trens Talson, R. O.C.	IN USA		Sailing on or about	3-dy 30, 2002 Bree	Taines, R.O.C. is	USA.	
	L/C No. Condruct No. A1233			L/C No.	Cost	red No. A1233		
	Made & Nee. Decembring of Goods	Oundity This Dies Amend		[	Bucciption of G		Voit Inice	
	Manuel (Jun Ho 200)	1 cm 100 20.00 100240.00		Mathy-It Net.	Buerrigtion of G	cols Quality		Asserant USD-60-00
	and Amond ( hen Mr. 2013	3 etc. UND 30 00 UND 40 00		47.0 200	mott ( Barm Ho. 201 )	3.00	1812-00.00	1812-60-00
	forth Diment ( Ben Ho. 202 )	3 refor (000 20 30) (000 40 20)		family /m	pert (Bem 240.202.)	) : 0	00230.00	00240.00
	P/036-A2233			P/0 No. A2233				
	COM-1 Made in Tairen			Critio.1 Made in Talman				
	ROC.			8.0.C.				
	Tetal	5 rel: 153829.00		Total		5.00		USB02040
	Sample of the Community Value. Value for Continue Pargies Waly. Contro of Weights. Taking, R.B.C. N.W.: Contro of Cont. Noncommun.			Sungle of No Consus Walas Ine Contens J Country of Bright .: 3 NW: GW: Measurement :	ngasa Gağı. Inkana, R.O.C.			
No	ormal			l gnore color	sing	le bac	kg	round

### **Sensitivity of Auto Color Detection**

If your documents contain primarily B&W text and small amount of light or pale colors and you do not wish them to be recognized as color image to save the file size, you can increase the sensitivity value by moving the bar to the right to let these images to be detected as B&W. The value ranges from 1 to 100. The default is 37.



### Original

Standard	IEEE 80	2.11 b/g/n standards compliant	Standard	IEEE 802.11 b/g/n standards compliant					
Wireless LAN	1TIR Mode		Wireless LAN	1T1R	1T1R Mode				
Frequency Range	2.400 ^	<ul> <li>2.4835GHz ( subject to local regulations)</li> </ul>	Frequency Range	2.400	2.400 ~ 2.4835GHz ( subject to local regulations)				
	802.11	n: 20MHz/40MHz		802.1	802.11n: 20MHz/40MHz				
Number of Selectable Channels	802.1 1b/g:	USA, Canada (FCC):11 channels (2.412GHz+2.462GHz) Europe (CE): 13 channels (2.412GHz+2.472GHz) Japan (TELEC): 14 channels (2.412GHz+2.4833GHz)	Number of Selectable Channels	802.1 1b/g:	Europe (CE): 13 channels (2 412GHzw2 472GHz)				
Data Rate	802.11	n: up to 150Mbps 5: 1, 2, 5,5, 11Mbps 3: 6, 9, 12, 18, 24, 36, 48, 54Mbps	Data Rate	802.1	802.11n: up to 150Mbps 802.11b: 1, 2, 5,5, 11Mbps 802.11g: 6, 9, 12, 18, 24, 36, 48, 54Mbps				
Transmit Power(EIRP)	11g OF	40 MCS7 : +13 dBm DM: +15 dBm K: +18 dBm	Transmit Power(EIRP)		11n HT40 MCS7 : +13 dBm 11g OFDM: +15 dBm 11b CCK: +18 dBm				
Security	WEP 64	/128, TKIP, WPA, WPA2 mixed,802.1x and 802.11i	Security	WEP 6	WEP 64/128, TKIP, WPA, WPA2 mixed,802.1x and 802.11i				

## Sensitivity: 1Sensitivity: 100(The image is recognized<br/>as a color one)(The image is recognized<br/>as a black and white one)

### Same settings on both sides:

Click to apply same scan settings for both sides of your documents. After checking this option, any settings you have changed will automatically applied to both the front side and the rear side. For example, if you choose your ideal resolution to be 300 dpi, this will be applied both to the front side and rear side of your document.

### 4.3.2 Other Image Options

Binarization This is the process of converting a grayscale or color image to a bi-tonal image. There are several different methods of performing this conversion. Options: Dynamic Threshold, Dynamic Threshold (AD), Fixed Processing, Halftone 1~5, Error Diffusion.

**Dynamic Threshold:** Selecting **Dynamic Threshold** allows the scanner to dynamically evaluate each document to determine the optimal threshold value to produce the highest quality image. This is used to scan mixed document containing faint text, shaded background, or color background with a single setting. If Dynamic Threshold is selected, Threshold, Brightness, and Contrast are not available.

**Dynamic Threshold (AD):** Selecting **Dynamic Threshold (AD)** to perform the enhanced mode of the Dynamic Threshold feature. However, using this mode may slow down your scanning speed.

### Sensitivity of Dynamic Threshold

Occasionally your scanned image may contain small dots or speckles. To remove these spots, increase the sensitivity value by moving the bar to the right. The value ranges from 1 to 30. The default is 20. **Fixed Processing:** Used for black-andwhite and other high contrast documents. A single level is set to determine the blackand-white transition. The threshold is programmable over the entire density range. **Fixed Processing** sets Contrast to 0. If **Fixed Processing** is selected, Contrast is not available.

Halftone: In addition to the black and white display, Halftone can present a somehow gray shade of image by using different size of dots. Halftone image looks like the picture we have seen in the newspaper. Options include Halftone 1, Halftone 2, Halftone 3, Halftone 4, Halftone 5.


**Error Diffusion:** Error Diffusion is a type of Halftone. Error Diffusion gives good image texture and makes text in images more readable than Halftone.



Halftone Image



Error Diffusion Image



# **Threshold** Used to convert a grayscale image to a bi-tonal image. The value ranges from 0 to 255. A low threshold value produces a lighter image, and can be used to subdue backgrounds and subtle, unneeded information. A high threshold value produces a darker image, and can be used to help pick up faint images.

Adjust the threshold setting by dragging the Threshold sliding bar to the left or right to achieve the desired threshold setting.



200 dpi, Threshold:50, Brightness: 0

200 dpi, Threshold:100, Brightness: 0

### Gray

**Document Type: Choice: Normal, Photo, Document** Three options of document type are provided when you choose Gray as the image type for your scanned document. **Choice: Normal, Photo, Document.** 

- **Document:** Choose Document if your original contains pure text or a mixture of text and graphic since it is an optimal setting for regular business document. When using Document, only Threshold can be adjusted.
- **Photo:** Choose Photo if your original contains photo to reproduce your photo in vivid grayscale image. When using Photo, no Threshold and Contrast can be adjusted.
- **Normal:** When using **Normal**, Threshold, Brightness, and Contrast can be adjusted.

**Threshold:** The value ranges from 0 to 255. The default is 230. A low threshold value produces a lighter image, and can be used to subdue backgrounds and subtle, unneeded information. A high threshold value produces a darker image, and can be used to help pick up faint images. Adjust the threshold setting by dragging the **Threshold** sliding bar to the left or right to achieve the desired threshold setting.

		Construction of the second secon
-	Concession in the	Called and publication in the
	And Street of St	647-64
	April 1 and 1	553.00
	And in case of the local division of the	And Advantations (The Otto and
	All in part in	
	And an other states	to second the second to be seen
	AP AMP	10.0.7 (100)
	Name of Column 2	21.21.20.20.20
	and the second second	100
	Constructive World.	
	The state of	Lancas d'un materia l'an
	Conception of the local division of the loca	
	\$11.00x.000	2.0M
	and the second s	21-221
	- DEPER	
	Concept And	10 4 11 TW
	per product.	ALC: NO.
	Concepted and the second secon	COLUMN AND A
	Concession of the local division of the loca	1 - C. BR
	And and	Manual 2010, 000-101, 201, 101, 101, 101, 101, 101, 101,
	Annual States and	And
	Sunna Santa	
	Concession and the owner of the	and have york
	The second se	and state press (and some plant)
	And in case of the local division of the loc	
	Contraction of the local division of the loc	and and loss and many sale lower converse little many sets on August 2000

		<ul> <li>Construction of the product of the pro</li></ul>
-	Instantianty real	Table in the surger law
and so its	Service	102 mag area
	burning and	10.0 10710
	the second second	ALL AND A CALLER A
	ST IN ART IS	All and a linear print and seen
		\$1.5 Aut 1 1.45 Aut 210 1.000 perc.
	Streets	ALC: NO. AND AND
	Name or other division of	
	Transmitted and	And Milester Milest
	and the second second	89
The second	Conception of	Saturban Man, Address Pan.
and so its	Conception in the local division in the loca	100
	Los recent	Line Heat
	Cop. Lating	All and a second
14	Tax and taxed	
taken.	Mark and appendix	and the
		Latin Miles
	Para Datas	All Marine Wei, Marine 200, 500, 57
	Summer of the lot of the	
	Conversion internet	
		Early and a set part
	Concession and	
-	Concession and	And such 1998, tone look 1998.
Law -	Concession and	

		<ul> <li>Substitution of the state of th</li></ul>
Contraction of the	Daniel Surg and	And and investors 1
Section .	Annual Statement	Tell man west
	Carlos Mariant	10.0
	Reported added	100 T-100
	AN COLOR	
	25-10-320-00	AT MALE AND A THAT THAT IN AN A
	AP IN ARE IN	Trinds Tool (The 1974)
	Tableting part on	Banks Cilcon Physics and
	All yearshipsee and a second	In a Water
	Same summer	01-01, made
		ant with mights.
	i had	44
		871-146-87 mil
And the owner of the		And were of our shad that then
Sandara -		
	The pair sector	6.7%
	Con worker	(Disching)
	Landa -	pr. est.
-	Fortune care	
Texas .	Caller and grant .	Laure Linned
and the second s	State of the second sec	0.1279
	The matches	Tate Unit Witter
	Free digits	
	Rame agent	Woman Will, Oliverant, 202, 201, 47
	Statute rolls has pet-	Link ages
Annal .		Harris March 10044 To an equilated
- Sections	President and a second s	
		arth-seat mark
Appendix .		
		131 prov 2000, 4400
dankane (	Sectors and	Melition, Elite Concession, Stee

Document (Threshold: 230)



Normal



Photo



Document (Threshold: 230)

Brightness Adjusts the lightness or darkness of an image. The higher the value, the brighter the image. Drag the slider to the right or left to increase or decrease the brightness. The range is from -100 to +100.
Contrast Adjusts the range between the darkest and the lightest shades in the image. The higher the contrast, the bigger the different grayscale. Drag the slider to the right or left to increase or decrease the contrast. The range is from -100 to +100.





Contrast: -50

Contrast: 0

(Normal)

Control de la con

Contrast: +50

**Resolution** A good control of the resolution results a good detail of an image that scans. The resolution is measured by dots per inch (dpi). Normally, the greater the dpi number, the higher the resolution and the image file size. Be aware that greater resolution takes more time to scan, and more disk space for the scanning image. For your information, an A4 size color image scanned at 300 dpi at True Color mode consumes approximately 25 MB of disk space. A higher resolution (usually means over 600 dpi) is only recommended when you need to scan a small area at True Color mode.

Choose a resolution value from the drop down list. The default value is 200 dpi. Available resolutions are 75, 100, 150, 200, 300, 400 and 600. Or you may choose your desired value by clicking the box in the right side of the drop down list and press the arrow key to select your desired value and then click the Add button to include it in the drop down list. **Note:** The resolution is up to 300 dpi if an imprinter or a MICR reader is installed or connected to the scanner.



Resolution: 75 dpi



Resolution: 150 dpi

Invert Reverses the brightness and the colors in the image. The default setting is Black on a White background. Reverse mode is White on a Black background. For color images, each pixel will be changed into its complementary color at the command of Invert.

#### "I am not worthy to have you enter my

that is God, I beg all my brothers - those w e who work manually, clerics and lay brothers ards being humble in all things; not to glorify r to become interlorly proud because of good w sometimes says or does in them or through ti ord: "Do not rejoice--- in the fact that the de : 10:20) Let us be firmly convinced of the fact

### Black on White

#### "I am not worthy to have you enter m

that is God, I beg all my brothers – those v who work manually, clerics and lay brothen rds being humble in all things; not to glorify to become interiorly proud because of good w sometimes says or does in them or through t rd: "Do not rejoice-- in the fact that the de 10:20) Let us be firmly convinced of the fac

### White on Black

### Scan Choice:

- Source Auto Document Feeder: Used to scan multiple pages.
  - **Flatbed:** Used to scan a single page. For example, pages from newspaper clipping, paper with wrinkles or curls.
  - Flatbed (book): Used to scan several inside pages from book.
  - Automatic: Allow the scanner automatically set its scan source. If Automatic is selected and there is document in both the auto document feeder (ADF) and the flatbed, then the scan source will be automatically set to ADF. If Automatic is selected and there is document only in flatbed, then the scan source will be set to flatbed.
  - Merge Two Sides into One Image: If you have a sheet-fed duplex scanner with front input tray, you can scan an A3 size document with an innovative method. Thus, fold your A3 size document into A4, and then load the paper in the front tray. Choose Merge Two Sides from the Scan Source option and then the scanner is able to scan both sides of your document and merge two A4 images into one A3 image.


When you select Merge Two Sides into One Image, the Cropping or Multi-feed function will be disabled.

**Note:** This feature must be used with a carrier sheet. Regarding how to load a document with a Carrier Sheet, refer to Section 4.6.2, Other Paper Selection.

# Note the options vary based on type of scanner.

**Note:** If you have purchased a duplex sheetfed scanner, choose [Merge Two Sides] on the [Scan Source], then the scanner is able to scan both sides of your document and merge them into a single image.

If "Merge Two Sides into One Image" is selected, its choice will be available including "Merge Horizontally", "Merge Vertically", "Merge Vertically (Back Side Flip)". If the reverse side of your document is upside down, choose "Merge Vertically (Back Side Flip)" and the back side will be automatically rotated 180 degrees and merged.



Merge Vertically

Merge Horizontally

Note the options vary based on type of scanner.

### Color Matching

The purpose of Color Matching is getting the accurate color. This option uses the default parameters (ICC profile) to adjust the colors of the image.

### Choice: None, Document, Photo

- None: Choose "None" to disable this option.
- **Document:** Choose "Document" if your original contains pure text or a mixture of text and graphic since it is an optimal setting for regular business document.
- **Photo:** Choose "Photo" if your original contains photo to reproduce your photo in vivid color image.



Normal



After Color Matching

### 4.3.3 Scanning color images

The following options are available for scanning color images.

- Brightness
- Contrast
- Resolution
- Invert

### 4.3.4 Scanning grayscale images

The following options are available for scanning gray images.

- Brightness
- Contrast
- Resolution
- Invert

### 4.3.5 Scanning B&W images

The following options are available for scanning B&W images.

- Binarization (Dynamic Threshold)
- Resolution
- Invert

Or

- Binarization (Fix Processing)
- Threshold
- Brightness
- Resolution
- Invert

### 4.3.6 Editing Profiles

The Scanner Properties dialog box allows you to change and save your frequently used scan settings into a profile. You can edit these profiles by renaming or deleting them.

### To add a new profile,

- 1. Customize your settings. (For example, change your resolution, image type, cropping method, scan size, or other scan settings.)
- 2. Click the Image tab and then choose "Profiles" to prompt the "Edit Your Profile" dialog box.

Scanner Properties			100				
inage Paper   Setting   Informati	an.						
T Frank Auto Color Detection	Bratator.	Oyramic Threshold					
Front Color	Senativity	20 *	- ·				
Part Gay	1 Digitizent	1.9					
C Prove BAW	Contail						
	0.0070.000		Edit Your Profile				
Peer Ada Color Detection	Residion (dpi)	200					
El PearColor	ivet.	Black on White	Profile:	Duplex, B&&W, 200 dpi	-	Add	Delete
Plan Gray			t rone.	Doplex, Doow, 200 opr			0.0000
E Peachter	4					Rename	Reset
Same settings for both sides							
Scan Sout	Auto Document Fields	•					
Polies	Carlor	•					
	)						Exit
Defade		-	X Carcel				

3. Click "Add" to enter the name of the profile and then choose "Save".

Cancel

4. The new profile will be saved and shown in the "Profiles" dropdown list box.

### To load a profile,

1. From the Image tab dialog box, choose your favorable profile from the "Profiles" dropdown list box.

Profile:	Duplex, B&&W, 200 dpi	Add	Delete
	Duples, B&AW, 200 dpi Duples, Color, 200 dpi Duples, Gray, 200 dpi Simples, B&AW, 200 dpi Simples, Color, 200 dpi Simples, Gray, 200 dpi	Rename	Reset

2. Your favorable profile will be immediately loaded and displayed on Scanner Properties dialog box.

### To delete a profile,

1. From the Image tab dialog box, click "Profiles" to prompt the Edit Your Profile dialog box.

it Your Profile			
Profile:	Flatbed	Add	Delete
		Rename	Reset
			Exit

- 2. Choose the profile you want to delete from the dropdown list box.
- 3. Click "Delete". A Confirm message "Are you sure you want to delete this profile?" is prompted.
- 4. Choose "Yes" to delete or "Cancel" to quit.

### To rename a profile,

1. From the Image tab dialog box, click "Profiles" to prompt the Edit Your Profile dialog box.

Profile:	Betsy	Add	Delete
	Betry Duplex, B&&W, 200 dpi Duplex, Color, 200 dpi Duplex, Gray, 200 dpi Flatbed Simplex, B&&W, 200 dpi Simplex, Color, 200 dpi Simplex, Gray, 200 dpi	Rename	Reset

- 2. Choose the profile you want to rename from the dropdown list box and then click the Rename button.
- 3. Enter new name for the profile.

Rename a Profile	×
Please enter the new	name of the profile:
Original Name: New Name:	Betsy
	Save Cancel

4. Choose "Save" to save the new profile or "Cancel" to quit.

#### Note:

- The preset default profiles include Flatbed, Simplex-B&W, 200 dpi, Simplex-Gray, 200 dpi, Simplex-Color, 200 dpi, Duplex-B&W, 200 dpi, Duplex-Gray, 200 dpi, Duplex-Color, 200 dpi. If you have a simplex or a sheetfed scanner, the duplex or the flatbed option will not be available.
- If any setting for a current profile has been changed, a [\*] sign will be marked before the name of current profile, for example, [\* Duplex, Color, 200 dpi]. If desire, click the [OK] or [Scan] button and a dialog box will be prompted to let you save the new profile.

### 4.4 The Compression Tab

The Compression tab allows you to compress your scanned image and choose the level of compression. Bi-tonal images are normally compressed using CCITT standard called Group 4 (G4). Color and grayscale images are often compressed using JPEG technology. Move the **JPEG Quality** slider to the right or left to increase or decrease the level of compression. Note the greater the compression level, the lower image quality. Default is 50%.

Note that the compression depends on your image editing application. If your image editing application does not support the type of compression format, then either a warning message will appear or the image quality of the compressed file will not be acceptable.

JPEG (Joint Photographic Editor Group). This group developed and lent their name to a file compression standard for color and grayscale images that is widely used by scanners, and software applications. On Microsoft Windows-based systems, a file with the extension .jpg has normally been compressed using this standard.

For scanning color or gray images, the following compressions are available:

- None
- JPEG

For scanning B&W images, the following compressions are available:

- None
- G4

Scanner Properties Image Compression Paper Setting Information	
Front Auto Color Detection Front Color Front Gray Front BaW	None
Defaults	OK Cancel

### The Compression tab dialog box

### Compression:

To complete your scan at a rated speed, the scanned image is compressed by default during transmission. However, if you wish to obtain the highest image quality, you can choose to uncompress the image data before it is output.



### To Application:

Choose if you wish to compress the image data and transfer it from the TWAIN driver to the application. Note Bi-tonal images are normally compressed using CCITT standard called Group 4 (G4). Color and grayscale images are often compressed using JPEG technology. Move the [Image Quality] slider to the right or left to increase or decrease your image quality. Note the greater the image quality, the lower the compression level. Default is 50%.

Note that the compression depends on your image editing application. If your image editing application does not support the type of compression format, then the image of the compressed file will look abnormal.

## From Scanner: (*Note: The availability of this feature varies due to scanner model.*)

Choose if you wish to compress the scanned image and transfer it from the scanner to the TWAIN driver.

Choice: Uncompressed, \*Best Image Quality (Low Compression Level), Better Image Quality (Normal Compression Level), Normal Image Quality (High Compression Level). (\*: Factory Default)

🎃 Scan	ner Properties				×
Image	Compression	Paper Se	tting Information		
₹ ₹	Front Auto Color Front Color Front Gray Front B&W	Detection	To Application	None 🔻	
₹ ₹	Rear Auto Color i Rear Color Rear Gray Rear B&W	Detection			
			From Scanner Compression Mode:	Best Image Quality	
	Defaults			ОК	Cancel

### 4.5 The Color Dropout Tab

### 4.5.1 Color Dropout Selection


The [**Color Dropout**] tab allows you to select either green, red, blue, or a color of your choice to remove the details of the selected color from a scanned image. This feature is used to sharpen your text when using OCR (Optical Character Recognition) software. Note this feature applies only to the gray or black and white image.

### Choice: None, Auto, Remove Red, Remove Green, Remove Blue, Custom

- None: Does not remove any color.
- **Auto**: Automatically outputs the image with the details of the primary color removed.
- **Remove Red/Remove Green/Remove Blue**: Outputs the image with the details of the specified color removed.
- **Custom**: Specify the color you wish to remove by entering its RGB (Red, Green, and Blue) value respectively.

Advanced Options:

- Quality Mode: Range: 0~20. Default: 10
   When [Quality Mode] is selected, you can determine the color to be dropped out using the [Filter Threshold] slider. A lower value will drop more of the selected color out, while a higher value will leave more of the selected color in.
- **Normal Mode**: Use an optimized setting to determine the color.



Preview the color dropout result:

To preview the color dropout result, please follow these steps:

- Click the [Scanner Properties] icon ( ) on the upper left corner, and choose [Tab] to show available tab names.
- 2. Choose [**Preview**] to show the Preview tab.
- 3. Click the [**Preview**] tab to show the Preview page.
- 4. Load your document to the scanner and click the [**Preview**] button to get a preview image.
- 5. On the [Image] tab, click [Gray] or [Black and White] image mode and then choose [Custom] on the [Color Dropout] tab. A [Preview window] button will be displayed.
- 6. Click the [**Preview window**] button to prompt the [**Preview**] window with the previewed image.

- 7. Move your cursor over the preview image. Your mouse cursor now becomes an Eyedropper.
- 8. Click to select a color which you wish to remove.
- 9. Click and hold your mouse button to view the result after removing the specified color. If the result is satisfactory, click **[OK]** to close the Preview window.



The Preview Window



The Color dropout result

nage Compression Color Dropout	Paper Preview Set	ing Information	
Front Auto Color Detection	Color Dropout:	None	-
Front Color		Advanced Processing	
Front Gray	Mode:	Nomal	*
Front B&W	Filter Threshold:	10 *	4
	Red:	71	
Rear Auto Color Detection	Green:	184	
Rear Color	Blue:	184	
📄 Rear Gray			
Rear B&W			

### The Color Dropout dialog box

To select a color on the Color palette,

 Click the Color Dropout tab from the Scanner Properties dialog box.

inage	Compression Color Dropo	ut Paper Preview Se	ting Information	
	Front Auto Color Detection	Color Dropout:	None	-
	Front Color		Advanced Processing	
	Front Gray	Mode:	Normal	w
V	Front B&W	Filter Threshold:	10 *	+
		Red	71 🚔	
	Rear Auto Color Detection	Green	184	
	Rear Color	Blue:	184	
۲	Rear Gray	0		
	Rear B&W	1		
	Delaults		ОК	Cancel

2. Choose Gray or B&W from the Image Selection box and click "Custom" from the Color Dropout drop-down menu. The Color palette appears.

nage	Compression	Color Dropout	Paper	Preview	Setting	Information			
	Front Auto Color	Detection	Color Dr	opout:		Custom		-	)
	Front Color					Advanced	rocessing.		
	Front Gray		Mode:			Normal		-	
V	Front B&W		Filter Th	reshold:		10 4			•
	[n		Red:			136			
	Rear Auto Color	Detection	Green:			129			
	Rear Color		Blue:			119	3		
	Rear Gray	]							
	Rear B&W								
						Preview Window			

 Move your cursor over the palette. The cursor becomes a cross sign.

mage	Compression	Color Dropout	Paper	Preview	Setting Infor	mation			
	Front Auto Color	Detection	Color Dr	opout:	Cu	stom			•
	Front Color				7	Advances	Process	ing	
	Front Gray		Mode:		No	mal			
7	Front B&W		Filter Th	reshold:		10 4			,
			Red:			82	÷		
	Rear Auto Color	Detection	Green:			193	-		
	Rear Color		Bue:			62	-		
	Rear Gray		_	_					
	Rear B&W				Previe	w Windo			
	Defaults	_					-	OK.	 Cance

4. Click to choose a color. The RGB values are changed simultaneously.

### 4.6 The Paper Tab

The Paper tab allows you to define values relating to image output (i.e., Auto Crop or not, Scan Area, OverScan, Multi-Feed Detection).

	Information						
Cropping:	Automatic		•				
	Carrier Sheet	Mode					
Scan Area:	None		· · · · · · · · · · · · · · · · · · ·				
	Portrait	Landscap	e				
	X-Offset:	0.00	Width:	8.50 🜩			
	Y-Offset:	0.00	Length:	14.00			
Adjustment:	Left:	0.00	Top:	0.00			
	Right:	0.00	Bottom:	0.00			
Background Setting:	Automatic						
Unit:	Inches	•	]				
Feeding							
Transport Timeout:	•	۲	0 Seconds				
Tray Position:		<ul> <li>sheets</li> </ul>					

The Paper tab dialog box

### 4.6.1 Cropping

Cropping allows you to capture a portion of the document being scanned. Choice: Automatic, Automatic (36"), Fixed to Transport, EOP (End of Page) Detection, Automatic Multiple, Relative to Documents.

Options	Description
Automatic	Automatic adjusts the cropping window according to different document sizes and automatically straighten a skewed document. Use this option for batches of mixed-sized documents.
Automatic (36")	Automatically adjusts the cropping window according to different document sizes smaller than 36" and automatically straighten a skewed image. Use this option for batches of mixed-sized document.
	<i>Note: The availability of this feature varies due to scanner model.</i>
Fixed to Transport	This feature allows you to define the area or zone to be imaged. Use for batches of same-sized documents. If you select this option, you can use the arrow keys to define the x and y offset values, width and length to redefine your scanned area. The Display window will show image placement as you change the values.
EOP (End of Page) Detection	This feature allows you to define the area or zone to be imaged. Use for batches of same-width but different length documents. If you select this option, you can use the arrow keys to define the x and y offset values, width and length to redefine your scanned area. The Display window will show image placement as you change the values.

Automatic Multiple	This option allows you to place various sized documents such as photos, ID Cards, or business cards on the flatbed (if available) and lets you create multiple individually cropped images in one scan. Note: To correctly create multiple images, please make sure there is at least 12mm (0.5") of space between each document.
Relative to Document	This option allows you to crop different areas on your documents and deliver these images in B&W, Gray, or Color separately. For example, there are applications which require you to store the entire document in B&W and a part of the document in color to save storage space. This is useful for
	documents where a photograph or signature appears in a consistent area on the document such as resumes, and so on.

The following options are only available when **Fixed to Transport** is selected.

- **X-Offset** the distance from the left end of the scanner to the left edge of the scanning area.
- **Y-Offset** the position from the top end of the document to the top end of the scanning area.
- Width the width of the scanning area.
- **Length** the length of the scanning area.
- **Center:** automatically calculates the x-offset for centerfed feeding based upon document size selected.

  - relocate the scan area by click the arrow key on the cross sign while retain the scan size. View the result from the Display window.


The Adjustment option is available when **Automatic** is selected.

 Adjustment —adds a positive/negative margin value Top/Bottom or toward left/right of the image.
 Adjustment is used when the automatic document feeder is used. Adjustment reduces the possibility of corner clipping on skewed images. To set Adjustment values, use the UP/Down buttons to select where you want to apply Adjustment values: Top/Bottom or Left/Right, and then select the amount of inches/mm/pixels applied. Select a value within the range of 0.00 to 1.00 / -1.00. **Relative to Document:** (used for batches of same-sized documents)


This option allows you to crop different areas on your documents and deliver these images in B&W, Gray, or Color separately. For example, there are applications which require you to store the entire document in B&W and a part of the document in color to save storage space. This is useful for documents where a photograph or signature appears in a consistent area on the document such as resumes, and so on.

The following procedure describes how to reproduce the entire document in B&W and a portion of document (picture) in color.


- 1. On the Paper tab, choose "Relative to Document" or "Fixed to Transport" from the Cropping option.
- Choose your scan size from the Scan Area option. The selected scan size will be displayed in a red rectangular box. This is also the scan size of your entire document. (For example, ISO B5. If you have not chosen a scan area and leave the selection as None, then the default area will be the scanner's maximum.)




3. Click the Preview tab to display the Preview window. A black rectangular box appears to indicate the max. scan size your have just selected.



4. Click the Preview button to view the entire image in low resolution to correctly crop your relative scan area.



- 5. Select image type from the Image Selection box. The selected image will appear in highlighted color. (For example, Front Color)
- 6. Place your cursor on the Preview window and click your left mouse button. A cross sign will appear as illustrated. Create your relative scan size diagonally by dragging the left mouse button to your preferable size. The selected area will appear in a red box as illustrated.



- 7. Check the B&W image from the Image Selection box to scan the entire document.
- 8. Click the Scan button to start scanning the document in two image types and sizes. (See the result in below.)



The entire document in B&W



The relative area in color

### 4.6.2 Other Paper Selection

### Carrier Sheet Mode:

Check this option to automatically crop the scan window according to your document size when scanning non-standard document (fragile, irregular-size document) with a carrier sheet (optional). Note: The availability of this option varies due to scanner model.


### Loading Documents Using a Carrier Sheet

A Carrier Sheet is a plastic sheet specifically used for loading non-standard document onto the scanner. It allows you to scan document that can not be scanned in the regular way. Also, documents larger than A4 size, such as A3 and B4, can be scanned by folding in half, inserting into the Carrier Sheet, and scanning in duplex mode. You can also scan documents that can be damaged quite easily such as photographs, or irregular size documents that are difficult to load directly such as clippings.

### To scan document using a Carrier Sheet,

### For documents larger than A4/Letter size, such as A3

- a. Fold the sheet to be scanned in half.
- b. Fold the sheet tightly and smooth out crease. Otherwise, the sheet may be skewed during scanning.




1. Open the Carrier Sheet and place the document inside.


Align the top of the document to the top of the Carrier Sheet (the printed area).

## For documents larger than A4/letter size, such as A3

Align the top of the document to the top of the Carrier Sheet (the printed section) and the folded portion to the right edge of the Carrier Sheet so that the document fits into the Carrier Sheet at the upper corner.



For non-standard document Center your document in the Carrier Sheet.



- 2. Load the Carrier Sheet with the gray section (printed section) facing downwards.
- 3. Adjust the paper guides to the width of the Carrier Sheet. Adjust the paper guides so that there is no space between the guides and the Carrier sheet. Space between the guides and Carrier Sheet may cause the Carrier Sheet to become unaligned during scanning, and skew the scanned image.
- 4. Start the scan.

### Notice:

- [Carrier Sheet] is available for the models that support the Carrier Sheet.
- Some functions are disabled when [Carrier Sheet] is checked.
- This option may not work properly on some applications.

### Scan Area

Choose your desired paper size with the drop-down list box. Or you may select a custom paper size by clicking the **Scan Area** box and then click **Add** to include in the choice.

### Choices are listed below:

Nono
None
US Letter- 8.5"x 11"
US Legal – 8.5" x 14"
ISO A4 – 21 x 29.7 cm
ISO A5 – 14.8 x 21 cm
ISO A6 – 10.5 x 14.8cm
ISO A7 – 7.4 x 10/5 cm
ISO B5 – 17.6 x 25 cm
ISO B6 – 12.5 x 17.6 cm
ISO B7 – 8.8 x 12.5 cm
JIS B5 – 18.2 x 25.7 cm
JIS B6 – 12.8 x 18.2 cm
JIS B7 – 9.1 x 12.8 cm
Scanner Maximum
Long Page (<118")

### Long Page (<118"):

When you need to scan documents whose length exceeds scanner maximum, please choose Long Page. Note if Long Page is selected, the Multi-Feed Detection will not be available. (Note: This option and the maximum allowable document length vary due to type of scanner.)

When **Long Page (<118")** is selected, be sure to specify your document size in the **Length** and **Width** field.

### Notice when scanning long page document:

- 1. Pull out the extension in the ADF Paper Tray.
- 2. Secure enough space around the Output Tray to prevent the ejected paper from falling off the Output Tray.
- 3. To ensure the performance, in color mode, set the resolution to be 300 dpi or lower; in Black and White mode, set the resolution to be 600 dpi or lower.
- 4. Depending on your system environments, application, or your specified paper size, there may be insufficient memory to perform scanning.

### OverScan

Overscan allows you to add a specific margin at top and bottom or right and left (Options vary based on the type of scanner) of the edge of the image. This is used to reduce possible corner clipping on the skewed images and often applied to a batch of skewed document to be scanned in the auto document feeder. Select a value between 0 and +5 mm. Note the overscan result will not be shown in the Display window and that the availability of the function varies based on type of scanner.

### Pre-Feed

Choice: Enable, Disable. If enable is selected, you can set the amount of time the scanner starts pre-feeding your paper after your documents has been loaded into the feeder. The default is disable. Note: The availability of this option varies due to scanner model.

### Transport Timeout

Set the amount of time the scanner will wait and then start auto scan after the first scan job is completed. If you have many separate documents need to be scanned at the same scan settings, this feature is especially useful. The default is 0. The value ranges from 0 to 30 seconds.

#### Note:

- 1 Within the specified timeout period, if you load your document to the feeder, the scanner starts scanning automatically.
- 2 If your scanner has a flatbed option and you place your paper on the flatbed, after the timeout period, you need to click the Scan button on the TWAIN user interface to start scanning.

#### **Tray Position**

Specify number of sheets loaded in the paper tray in order to reduce the time to lift up the tray. **Choice: 50, 125, 250, 375, 500 sheets (default).** 

# BackgroundThis option allows you to set your scanSettingbackground. Choice: White Background,Black Background.

Note: For a sheet-fed scanner with an auto document feeder, this option is currently available only in the "Auto crop" mode. For a scanner with a flatbed platen, this option is available either in the "Auto crop" or the "Fixed to Transport" mode.



White Background



Black Background

### 4.7 The Multi-Feed Detection Tab

#### **Multi-Feed Detection**

Multi-Feed Detection allows you to detect overlapped document that go through the auto document feeder. Multi-Feed usually occurs due to stapled documents, adhesives on documents, or electro-statically charged document. Note : The availability of the function varies based on type of scanner.

Scanner Properties		
nage Paper Multi-Feed Detectio	n Setting Information	
Multi-Feed Detection		
Additional Length Detection:	None	
Ultrasonic Detection: 📃 Left	Middle Right	
Staple Detection	ed	
Multi-Feed Alarm:	C:\Windows\Media\chord.wav	Browse
Unit: Inche	8	
Defaults		OK Cancel

# Additional Length Detection

Additional Length Detection allows you to define the length of document being multi-fed. This value indicates the additional length exceeding your scan area. The Display window will show the size of the document as you change the value. A value of 0 indicates no additional length detection. The Additional Length Detection is best used when scanning samesize documents in the auto document feeder.

# Ultrasonic Detection

Ultrasonic Detection allows you to set overlapped document by detecting paper thickness between documents. Note: The availability of the function varies based on type of scanner.

- Stop Scanning after Multi-Feed
- If this is not selected, the scanner will continue scanning the rest document though multi-feed is detected. After the entire document has been scanned, a multi-feed dialog box will be prompted to indicate the page number which has been detected multi-feed and need to be rescanned.
- If this is selected, the following options will be displayed.

**Stop:** If this is selected, the scanner will stop scanning after a multi-feed is detected. No further dialog box will be prompted.

**Ask:** If this is selected, the image of the page which has been detected multi-feed will be displayed and three options are provided.

Continue Scan:	If the image of the multi-feed page is acceptable, select
	[Continue Scan] to continue scanning the rest pages.

Continue Scan(Discard Image):	If the image of the multi-feed page is not acceptable, select [Continue Scan (Discard Image)] to scan the rest pages yet the multi-feed page will be ignored and you need to rescan the page again.
Stop Scan:	The scanner stop scans. Remove the remaining pages in the scanner. Remove staples or any adhesive tapes on your document. Or fan your document and rescan the rest pages.

#### • Multi-Feed Alarm

If a wave file is added, the scanner will make a sound alarm if multi-feed is detected yet no Warning dialog box will be displayed.

#### How to add the sound alarm :

- 1. Click the Browse button on the right side of the speaker icon. The Open dialog box appears.
- 2. Choose your wave file.
- 3. Click the Open button. The wave file is added.

#### Units

Defines the primary measurement system. Inches, Millimeters, and Pixels are available.

# **Staple Detection**

The Staple Detection feature automatically halts the scanning process when an unremoved staple is detected. Left undetected, staples could cause errors that compromise the document, cause jams, or damage the device.

#### 4.8 The Preview Tab

The Preview tab allows you to preview (a low-resolution scan) your image before final scan. This preview image lets you allocate your scan area. You can choose your scan area by the "Scan Area" drop down list box or placing your cursor on the Display window and dragging it diagonally on the Display window. Then, a red rectangle box will appear to indicate the selected area.

Note: If you choose "Automatic Cropping" on the "Paper Tab", then to select a scan area on the Preview tab is not allowed.

mage (	Compression	Color Dropout	Paper	Preview	Setting	Information	
Fre	ont Auto Color	Detection			0	1 2 3 4 5 6 7 8 9	
Fre	ont Color	)			0 <u>_</u>	ulandradandan haring and	
Frc	ont Gray	j			1-	And a set of the set o	
V Fro	ont B&W				2-	<ul> <li>In designed on a set of the set</li></ul>	
Re	ear Auto Color	Detection				The second secon	
Re	ear Color				4 -	A set of the set of th	
Re	ear Gray				5-		The Displa
Re	ear B&W				6		Window
Scan A	vea:				7 -	All of the end of the charge. The car is a set of the charge and t	Window
ISO A	4 - 210 x 297	mm		•	8	sends is very service is during a broken and off sended to explore the conduction and the property service is an end of the sended to explore the conduction and the property service is a feat of the broken and the property service is an end of the broken and the property service is and the	
Port	trait	Landsc	ape	_	9 -	And the analysis of the second se	
X-Offse	st:	0.12	<b></b>			And a second sec	
Y-Offse	et : II	0.00	*		E E		
Width:		8.27			12 -		
Length		11.69			13 -		
Unit:		Inches		-			
Sele	ected area ap	plies to all mode	s				
						2	

#### The Preview Tab


# 4.9 The Enhancement Tab

The Enhancement tab allows you to set following additional image processing settings.

age	Paper	Multi-Feed D	etection	Preview	Enhancement	Setting	Information	
	h Hole F unch Ho	Removal ole Removal						
Back	ground S	Setting						
Back	ground	Processing:	None		*			
Sens	itivity:		4		۴	0		
Fill C	olor		White	е	*			
Deepe	Solida	Black		0 Millime	ters	line Pr	mound	
	Ø	Black		0 Millime	ters			
	eckle e Numbe		0	0 Millime		Line Re	emoval	
		er:	0			_		
Noise	e Numbe	er:		Pixels		_	<b>•</b>	

# The Option tab dialog box

PunchYou can remove punch holes from the output<br/>scanned image when scanning punched document.HoleScanned image when scanning punched document.RemovalNote the availability of this feature varies<br/>depending on your scanner model.



# Punch holes can not be removed when:

- Resolution is set lower than 150dpi
- The hole is near the edge of the document
- The holes are not aligned along the edge of the document
- Punch Hole Removal is available only when "Auto Crop" is enabled. If either "Fixed to Transport", "EOP (End of Page) Detection", "Automatic Multiple", "Relative to Documents" is selected from the Cropping option on the Paper tab, the Punch Hole Removal option will be disabled.

### Shadow Removal

When **Flatbed** on the **Scan Source** option is selected on the **Image** tab, the **Shadow Removal** option will be enabled. Click to remove the shadow on the book spine when scanning a book.



# Background Processing: The [Background Processing]

option allows you to smooth background color or remove it to make image clearer. The option is especially useful for documents with color forms such as invoices.

#### Choices: None (default), Smooth, Removal

- None no background processing will be performed (default)
- **Smooth -** produces images with a more uniform background color. This option improves image quality.
- **Removal** identifies the background color and then removes it.

#### Sensitivity: Choice: 0, 1, 2, 3, 4. Default: 0

- The higher the value, the more background color will be kept.

#### Mode: Auto, Moiré

If [**Smooth**] is selected in the [**Background Processing**] option, then the choices for the [**Mode**] option includes Auto, and Moiré.

- **Auto** uses the factory preprogrammed mode to proceed background smoothing.
- **Moiré** Remove the moiré patterns that appear on the background of the image when scanning printed material.

If [**Removal**] is selected in the [**Background Processing**] option, then the [**Mode**] option will be replaced with [**Fill Color**]. Choices: White, Auto.

- White identifies the background color and substitutes it with white.
- **Auto -** identifies the background color and substitutes it with the color of the largest background zone.



Background Processing: None




Background Processing: Smooth



Background Processing: Removal Fill Color: White

**Note:** Background color in small zone will not be processed or removed.

Edge Check White or Black if you wish to add white or Fill black edge on the border of your scanned image. Enter the value from 0 to 5 mm. Default value is 0.



# Edge Fill: 5mm (Black)


# Despeckle

Occasionally small dots or specks appear in the background of a scanned image. Remove unwanted speckles provides a cleaner image for OCR (Optical Character Recognition) processing, and also helps to reduce compressed file size.

Define the speckles (also known as image noise) you wish to remove by specifying its number (size) and radius (range). The measuring unit is pixel. The higher the number, the more speckles will be removed.

t plague on thee! Hast thou never an eye in thy head? Canst not hear? -The First Part of King Henry the Fourth: 2.1.26-27 A carrier to Gadshill, the host of a tavern.

Before Despeckle (noise number:0, noise radius:1)



After Despeckle (noise number: 22, noise radius: 10)

#### Note:

- The function is currently available for Black and White image only.
- To scan at rated speed, it is recommended to set the noise radius up to 10 pixels.

**Line Removal:** When **Black and White** image mode is selected on the [**Image**] tab, the [**Line Removal**] option will be enabled. Line Removal erases lines on the image and then reconstructs characters so the OCR (Optical Character Recognition) accuracy can be improved.

#### Choices: None, Form, Horizontal, Vertical

None – the default mode which does not remove any line.

**Form** – remove any form in the document.

**Horizontal** – select [**Horizontal**] and then enter the length of horizontal line to remove only the horizontal line exceeding your specified length.

**Vertical** – select [**Vertical**] and then enter the length of vertical line to remove only the vertical line exceeding your specified length.

Attn : Mr. Basid Wang		Atin : Mr. David Wang
Shipped by SST Technologies Inc.	For U-Line Express	Shippel by SST Technologies Inc. Per U-Line Express
Sailing on or aboutJuly 30, 2002 From Taiwan, R.O.C		Sailing on or about July 30, 2002 From Taiwan, R.O.C. to U.S.A.
L/C NoCondract No. A1233	<u> </u>	L/C NoCendract No. A1233
Marks & Nos. Description of Goods	Quantity Unit Inice Amount	Varilis & Nos. Bescription of Gools Quantity Unit Price Amount
Amrest (hen No.100) Amrest (hen No.101)	3 sets USD20.00 USD60.00 3 sets USD20.00 USD60.00	Amrest (hen No. 100) 3 sets USD20.00 USD60.00 ABC Amrest (hen No. 101) 3 sets USD20.00 USD60.00
Armrest ( hem No. 102 )	3 sets USD20.00 USD60.00	Amrest (hen No. 102) 3 sets USD20.00 USD60.00
Seattle P/O No. A1233		Seattle P/O No. A1233
C/No.1		C/No.1 Made in Taiwan
Made in Thiwan R.O.C.		R.O.C.
Tetal	5 sets USD120.00	Total 5 sels USD120.00
None		Remove Form
tin : Mr. David Wang		Attn : Mr. David Wang
áppel by SST Technologies Inc.	Fer U-Line Express	Shipped by SST Technologies Inc. Per U-Line Express
uiling on or about July 30, 2002 From Taiwan, R.O.	C. to USA.	Sailing on or about July 30, 2002 From Taiwan, R.O.C. to U.S.A.
C No. Contract No. A123	3	L/C No. Condract No. A1233
Marks & Nos. Description of Goods	Quantity Unit Inice Amount	Marks & Nos. Bescription of Goods Quantity Unit Price Amount
Amrest ( hem No. 100 ) Amrest ( hem No. 101 )	3 sets USD 20.00 USD 60.00 3 sets USD 20.00 USD 60.00	Amrest (hen No. 100) 3 sets USD20.00 USD60
Amrest ( hem No. 102 )	3 sets USD 20.00 USD 60.00	ABC Ammret(hem No. 101) 3 sets USD20.00 USD60 Ammret(hem No. 102) 3 sets USD20.00 USD60
Seattle 2/0 No. A1233		Seattle P/O No. A1233
C/No.1		C/No.1
fade in Taiwan R.O.C.		Made in Thiwan
Total	5 sets USD120.00	R.O.C. Total 5 sets USB120
I		100m 55m 05m20
Remove Horizo	ontal Line	Remove Vertical Line
(over 30 ı	mm)	(over 70 mm)

# 4.10 The Rotation Tab

The Rotation tab allows you to set the following image rotating options:

nage Paper	Multi-Feed Detection	Preview	Rotation	Enhancement	Setting	Infor	nation	
Rotation	14					063		
Rotation De	grees :	None			• N	lode:	Quick	*
Image Control	Options							
Split Image:		None			•			
Flip Side Rota	tion							
	200 0		F					
$A^A$	Book			AL OI	Fanfold			
Image Control	0.5		0.0					
	Options							
Mirror	Options							
	Options							
	Options							
	Options							
	Options							
	Options							
	Options							
	Options							
	Options							

RotateChoose the rotation angle from the drop downImagelist if you wish to rotate your scanned image.

Choice: None, 90°CW(clockwise), 90°CCW(counter clockwise), 180°, Auto based on contents. Auto rotate every even page.

123	<b>┝</b> ─── <u>→</u>
1 2 3	2
	$\boldsymbol{\omega}$
Original	Rotate 90°CW
ŝ	1 T 3
2	
<del></del>	
Rotate 90°CCW	Rotate 180°

Auto based on contents: Automatically rotate images based on the contents of document. When **Auto based on** contents is selected, its modes will be enabled to let you select more options.

#### Mode: Quick, Full Text, Complexity

**Quick** – the default mode to let you rotate images at the fastest speed.

**Full Text** – the enhanced mode for documents with mixed text orientation.

**Complexity** – the enhanced mode yet at the slowest speed for document with complex image or text orientation.

#### Auto rotate every even page:

Automatically rotate 180° on every even page. This is especially useful when you scan the inside pages from a book. As a result, if you choose "Flatbed (book)" from the "Scan Source" option, "auto rotate every even page" will be selected as default.

# Note: This option varies based on type of scanner.



text orientations

Document with dark or complex background Split By splitting an image, two separate images are created horizontally or vertically. This is useful for documents containing two pages per image when you want to save them as two images (one page for one image). Choice: None, Horizontal, Vertical. Default is None.

**Horizontal:** Divide one image into the upper half and the lower half.

**Vertical:** Divide one image into the left half and the right half.





Split Horizontally

**Split Vertical** 

# Flip SideSelect "fanfold" to rotate the image of theRotationreverse side to 180 degrees.

This is applied to double-sided document which are viewed in portrait are sometime fed into the scanner in landscape or vice versa.

#### Choice: Book, Fanfold.

If "Book" is selected, the image of the reverse side will not be rotated.

The following illustration shows the documents which should be viewed in portrait are fed into the scanner in landscape



ImageCheck the Mirror box if you wish to reverse the rightControland left side of your image.Option



Original



The Mirror Effect

# 4.11 The Separation Tab

The Separation tab allows you to enable the detection engine to detect the blank page, barcode, and patch code and then notify the software application which supports document separation to separate your multi-page documents. Choices: Blank Page Removal, Barcode Detection, Patch Code Detection.

mage	Paper	Multi-Feed D	Detection	Preview	Rotation	Separation	Enhancement	Setting	Information
Blank	Page R	emoval							
	lank Pa	ge Removal T	breehold:				-0		50 %
		genenovan	nicanola.						
Barco	de Dete	ction							
E	nable			Select	Barcode Ty	/pe	Zone :	All	-
Patch	code D	etection							
	nable								
	naule								
	Default							ОК	Cano

Blank Page<br/>RemovalChoices: None, Blank Page Removal Threshold,<br/>Image Size.None – Do not remove the blank pages.Threshold - Move the slider to the left or right<br/>to define your threshold for the blank page.Image Size – Range: 1~ 10000 KB. Specify<br/>your desired image size to detect the page as a<br/>blank page. For example, if 3 KB is selected,<br/>any page less than 3 KB will be recognized as<br/>blank page.

BarcodeCheck [Enable] to detect barcode and notifyDetectionthe software application for advancedprocessing. Please note the whole documentwill be checked and no specific detection areaneeds to be designated.

When the bar code has been detected successfully, a file [avbarcode.ini] will be created and stored in the following path:

Windows XP: C:\Documents and Settings\All Users\Application Data\%PRODUCTNAME%

Vista, Windows 7, Windows 8, Windows 10: C:\ProgramData\%PRODUCTNAME%

#### Barcode Types:

The following barcode types can be detected.

#### Two-dimensional codes

- Aztec
- DataMatrix
- PDF417
- QR Code

#### **One-dimensional barcodes:**

- Add-2
- Add-5
- Airline 2 of 5
- Australian Post 4-State Code
- BCD Matrix
- Codabar
- Code 128 (A,B,C)
- Code 2 of 5
- Code 32
- Code 39
- Code 39 Extended
- Code 93
- Code 93 Extended
- DataLogic 2 of 5


- EAN 128 (GS1, UCC)
- EAN-13
- EAN-8
- GS1 DataBar
- Industrial 2 of 5
- Intelligent Mail (One Code)
- Interleaved 2 of 5
- Inverted 2 of 5
- ITF-14 / SCC-14
- Matrix 2 of 5
- Patch Codes
- PostNet
- Royal Mail (RM4SCC)
- UCC 128
- UPC-A
- UPC-E

#### Barcode Zone:

Specify the barcode zone to be detected.

Select **FAII** to checks the whole document and detects barcodes. Or you may speed up the process by specifying a detection area since only the specified area is checked.

Choice: All, Top, Bottom, Left, Right, Bottom Right, Bottom Left, Top Right, Top Left



#### Choice for barcode zone on a page:

# Note:


- Recommended resolution: 200~600 dpi for regular barcode, 300~600 dpi for QR code
- Skewed barcodes may not be recognized correctly.
- Using the same sheet repeatedly may decrease the recognition accuracy due to accumulated dirt on the sheets. If the sheet is not recognized correctly or gets smudged, replace it with a new sheet.

# Patch code Detection:

Check [**Enable**] to detect patch codes and notify the software application for advanced processing.

A patch code is a pattern of parallel, alternating black bars and spaces (i.e. a barcode) that is printed on a document. Patch code sheet is most commonly used as a document separator in a stack of document. You can find various sizes of patch codes (PDF) by choosing [Start] menu>[All Programs]>[Avision Scanner Series]>[Patch code] in succession.

Simply print the PDF file to produce the patch code sheet. Insert the patch code sheets to wherever you want the file to separate.



#### Notes to print the patch codes:

- Use blank white paper.
- Set the scaling to 100%. The sheet is not recognized correctly when printed in a size smaller than the original.
- Do not use toner saving mode. The sheet is not recognized correctly when the print is too light.
- Do not use thin paper in order to avoid bleed-through from the back.
- When you copy a patch code sheet that you printed out, make sure to copy by the same size and brightness as the original copy.
- Use the same sheet repeatedly may decrease the recognition accuracy due to accumulated dirt on the sheets. If the sheet is not recognized correctly or gets smudged, replace it with a new sheet.

# 4.12 The Setting Tab

The Setting tab allows you to set the following settings:

mage Paper Setting Information Cache Mode: Memory Size	•
Memory Size:   Energy Saving Control  C Enable Energy Saver	Default     15 minutes
Enable Power Off	4 240 minutes
Show Scanning Progress Show Warning Message Eject Paper Opposte	Taba: Compression Color Dropout Multi-Feed Detection Preview Rotation Separation Schancement Importer

The Setting tab dialog box

Energy Saving Control	Check the <b>Enable Energy Saver</b> box and move the slider to set the amount of time to start the energy saver after your last action. The range is from 1 to 60 minutes.
Enable Power Off	Check the <b>Enable Power Off</b> box and move the slider to set the amount of time to automatically turn off the scanner after your last action. The range is from 1 to 480 minutes. The default is 240 minutes (4 hours). Note the value of "Power Off" has to be greater than or equal to the value of "Energy Saving".

Cache	Mode: None, Page Number, Memory Size
	This option allows you to assign a specified memory size from the available RAM to process the image data. By specifying a smaller memory size, you can free more memory for other applications you are running. By specifying a larger memory size, you can have more memory to process the image data especially when you have a large amount of documents needed to be scanned.
	You can also specify your memory size by the page number. For your information, an A4 color document scanning at 300 dpi consumes approximates 24MB.
	Image Count When the selected cache mode is "none", the image count option allows you to assign number of pages you need to scan. For example, if you wish to scan the first two pages, simply move the page slider to 2, and the scan action will be stopped when the scanning of the first two pages have been completed.

Show Scanning Progress	Check and the scanning progress bar will be shown during scanning.
Show Warning Message	Check to show the warning messages such as "ADF pad count exceeds 50,000 scans (the number varies based on type of scanner). Please replace the ADF pad and reset the pad count."
Save Settings after Closing	Check to save your scanner properties settings after leaving the dialog box. Next time when you open the Scanner Properties dialog box, the previously saved settings will be shown.

### 4.13 The Imprinter Tab

The Imprinter tab allows you to print alphanumeric characters, date, time, document count and custom message on your scanned image if digital imprinter is selected or at the back of your document if external imprinter is selected.

Custom: Counter: Normal	
Counter: 0001 Date/Time: None. Custom Font: Normal   Advanced Font Attributes: Normal   String Orientation: Normal   String Orientation:   Sample	
Custom Font: Normal   Advanced Font Attributes: Normal  String Orientation: Normal  Sample	
Advanced Font Attributes: String Drientation: Normal	
Font Attributes: Normal    Position: Mice   String Orientation:	
Font Attributes: Normal   Font Attributes: Normal   Position: Mice   Constant   Position: Mice   Position: Mice   Position: Mice   Sample   Position: Mice   Po	
String Orientation: Normal  V Offset:  V Offset: Sample	
Y.Offset:	idle 👻
Sample	0 mm
	0 mm
0001	
	More

**Choice:** External Imprinter, Digital Imprinter. If you have installed an external imprinter, choose external imprinter. If you do not have an imprinter, choose digital imprinter. Note External Imprinter provides a vertical and rear-side print capability while digital printer provides a horizontal and front-side print capability.

# Contents

Print All	Check <b>Print All</b> to automatically print the text at all pages of your documents. Uncheck <b>Print All</b> to print the text for the first page of your documents only.
Custom	Enter your custom text to be included in your print string.
Counter	Show the document count for the scan session. This value is increased sequentially by the scanner.

Date/Time	Choose if you wish to include the date and
	time in your print string.
	Format: YYYYMMDDHHSS For example,
	20090402170645-check0001 indicates year,
	month, date, hour, seconds, your custom
	text and the counter.
Custom	Choose your desired font.
Font	Choice: Normal, Fixed Width
	Fixed Width (Mono spaced) fonts have a
	fixed character spacing. So each character
	occupies the same width.

# Advanced

Font	Choose your font attributes. Choice:
Attributes	Normal, Underline, Double, and Bold.

String Orientation	Choose your string ori Choice: Normal, Rot Vertical Inversion, 9 degrees CCW	ated, Vertical,	
	2010abc	2010abc	
	Normal	Rotated	
	2 0 1 0 a b c	с 9 0 1 0 1 0	
	Vertical	Vertical Inversion	
	2010abc	2010abc	
	90 degrees CW	90 degrees CCW	
	If you check the digita text on your scanned in normal and rotated str	I imprinter to stamp image, the illustration of	of
	2010abc	2010abc	
	Normal	Rotated	

Print Position	string. Move the value or Range: 0~35 The value inc bottom of yo	the slider to to the left to 55mm, defau dicates the h ur paper to t option is avai	eight from the he last letter of your lable only if an
		0001abc 2010 ▲	The value of Print Position

# Print Position (for digital imprinter)

Choose the position of your printed string. **Choice: Top**, **Middle, Bottom, Custom.** If Custom is selected, enter the X and Y offset value to specify the position.

# 4.14 The Information Tab

The Information tab displays the following system and scanner information.

aper S	etting	Imprinter	Informatio	חנ	
			*		
			In	el(B) Core(TM) i3-2120 CPU @ 3.30GHz	
			M	crosoft Windows 7 Enterprise Service Pack 1 (Build 7601)	
uage:					
e:			Fo	ked drive C:\Total:30717MBFree:10439MB	
			Fb	ked drive Y:\Total:102398MBFree:10541MB	=
			Fo	ked drive Z:\Total:102398MBFree:23311MB	1
Space:			10	1439 MB	
n Name:			A	vision Capture Tool 1.6 (1.9)	
Driver Ver	sion:		6.	11.0329'16	
r Version	:		0.	9, 2016, 324	
в:			U	SB	
ess:			U	SB	
esolution	0		60	J0 dpi	
Model:			х	xx	
mber:			N	025	+
	e: Space: In Name: Priver Version :: ess: essolution Model:	s: Space: in Name: Nrver Version: r Version: :: ess: essolution: Model:	s: Space: In Name: Inver Version: Version: sess: esolution: Model:	10 Million 2010 Million 2010 Market 2010 M	Fixed drive C-\Total-30717MBFree:10439MB           Fixed drive C-\Total-30217MBFree:10541MB           Fixed drive C-\Total-102398MBFree:10541MB           Space:         10439 MB           n Name:         Avision Capture Tool 1.6 (1.9)           r/ver version:         0.9, 2016, 324           ses:         USB           esolution:         600 dpi           Model:         XXX

# The Information tab dialog box

#### The "Report" button :

If you encounter any error message while using the scanner, click the Report button. A report.txt file [Windows XP: C:\Documents and Settings\All Users\Application Data\%PRODUCTNAME%; Vista, Windows 7, Windows 8, Windows 10: C:\ProgramData\%PRODUCTNAME% (C: system drive)] will be generated. Please send this file to the nearest service center for trouble shooting.

### The "Reset Roller Count" button :

After scanning over a recommended number of pages (refer to subsequent section 7.4 Replacing the ADF Roller) through the ADF, the ADF roller may be worn out and you may experience problems with document feeding. In this case, it is highly recommended to replace the ADF roller with a new one. (Note the replacement of the ADF roller has to be performed only by authorized service center. Therefore, please return your scanner for roller replacement.) After replacing the ADF roller, click the "**Reset Roller Count**" button to reset the roller count.

#### Note :

The lifetime and the replacing procedure vary based on type of scanner.

# 5. ISIS Interface Operation

\* Please refer to the preceding chapter, Scanner Installation, to install ISIS scanner driver. You may start the supplied QuickScan software application to scan via the ISIS user interface.

The ISIS driver operation method is similar to the TWAIN's. Every function on the ISIS interface screen is briefly described as below:

Mode:	Brightness	OK
Black and White Dither:	Manual C Automatic	<u>D</u> efault
Halftone 4		Cancel
Dots per inch: 300	Darken Norm Lighten	<u>A</u> rea
Page Size:	Contrast	
A5 - 14.8 x 21.0 cm	G Manual C Automatic	
PIXDFLT Version 55.1.260.851 Avision FXN Driver V2.01.062402	128	

**Mode:** Select one of scan modes, including B&W, gray, color options.

Dither: 5 halftone levels available, can be disabled.

Dots per inch: Select your desired resolution.

Paper Size: Select your desired paper size.

Brightness: Adjust your scan image brightness or darkness.


**Contrast:** Adjust the range between the darkest and the lightest shades in the image.

Default: Click to reset all settings.

Area: Select your desired scan area or position.

## 6. Using the Buttons

The convenient buttons on the scanner is shown as below:



## 6.1 Installing Button Manager V2


Button Manager V2 provides you an easy way to scan your document and then link the scanned image to your designated software application. All this can be done by a simple touch of the button on the scanner. Yet, before you scan, it is recommended to check the button configurations first to ensure a proper file format and a destination application.

## 6.2 Checking the Button Configurations Before Scanning

 Button Manager runs from the system tray. After Button Manager and the scanner driver are properly installed, Button Manager is started and the Button icon will be displayed on the system tray at the bottom right corner of your computer screen.



2. Left-click the Button Manager icon to prompt the following Button Panel.



3. The Button Panel shows the first five scanning buttons. Right-click the button (function) you wish to check. The Button Properties window appears.

	Name of the Selected Button	
	Button Properties - iScan (OCR)	
Button Name	Basic Image Adjustment Color Dropout Image Processing More Settings  Scan (OCR)  Cimage Mode  300	
Image Mode Selection Box	Image: Color     Paper Size:     Auto Crop & Deskew       Color     Duplex       Stray     Advanced Settings:     Use TWAIN	Basic Scan Parameters
Folder and file name for the scanned image	File Location         Directory:       C.\Documents and Settings\void\My Documents\My Fictures         File Name:       Image_#####         More         File Format:       OCR(For iScan Only)	
Scan To destination and settings	Destination:       A is is an       Setup         Description:       Open your application, scan and insert the scanned image or editable text       A is in the scanned image or editable text         (after OCR) directly to your application.       Image: Setup       Image: Setup	
OCR settings	OCR Language: Chinese Traditional Scan Count: 0 OCR Zone: None Keyword: Sample No. of Recognized Characters After Keyword: 5 OK Cancel	

If you wish to change the setting, use this window to reset the setting for the file format, destination application, or other scan settings.

4. Click the OK button to leave the window.

## 6.3 Scanning From One Touch of the Buttons

- 1. Adjust the paper guide for the width of paper and load the document with their tops into the automatic document feeder.
- Check the number on LCD screen on the scanner to ensure if you are selecting the proper scan settings and destination application. (For example, if you wish to scan with button #3 "Scan to App" which opens Microsoft Paint and displays the scanned image in the window of Microsoft Paint, the LCD screen should show #3).
- 3. Press the **Scan** button on the scanner.
- 4. After the scanning is finished, the Microsoft Paint software will be launched and the scanned image appears in the main window of Microsoft Paint as below.

General	Document feeding mode	Flatbe
Specifications:	Technology	
	Optical resolution	
	Scanning speed	
	RAM	
	ADF min. paper size	4.5 inc
	ADF max. paper size	8.5 inc
	Flatbed max, paper size	8.5 inch
	ADF capacity	
	Operation environment	1
	Storage environment	-2
	Noise	
	Dimensions(H x W x D)	
	Weight	
Сору	First copy out	Color mor
Specifications:	Color copy speed	
	B/W copy speed	
	Copy resolution	
	Copy scaling	
	Multiple copies	

### Note:

- 1. For details information on how to use the Button Manager V2, please refer to the user's manual in the supplied CD.
- 2. You may also use Button Manager V2 on your desktop by starting Button Manager V2 from All Programs or double clicking the Avision Scanner Utility from the Control Panel.

## 7. Maintenance

## 7.1 Cleaning the Glass

### The procedures

- Use a clean and lint-free cloth wet with isopropyl alcohol. (95%)
- 2. Open the document cover as shown in Figure 7-1. Wipe the document glass.
- 3. Close the document cover. Your scanner is now ready for use.



Figure 7-1 The cleaning area


## 7.2 Cleaning the ADF

The scanner parts may be contaminated with ink, toner particles or paper coatings. As a result, the scanner needs to be cleaned occasionally particularly in the following cases:

- 1. Documents do not feed smoothly or easily;
- 2. Several documents feed at one time.

## The cleaning procedures

- Wet a soft lint-free cloth with some isopropyl alcohol. (95%)
- 2. Open the front ADF unit as shown below and wipe the feeding rollers. Rotate the rollers forward with your finger and repeat the above cleaning procedures until the entire rollers are cleaned. Be careful not to snag or damage the pick springs.
- 3. Wipe the pad in the direction from top to bottom. Be careful not to hook the pick springs.
- 4. Close the front ADF unit.
- 5. Close the document cover. Your scanner is now ready for use.




## 7.3 Replacing the ADF detachable pad module

After scanning approximately 50,000 pages through the ADF, the pad spring may be worn out and you may experience problems with document feeding. In this case, it is highly recommended to replace the pad module with a new one. For ordering the pad module, please consult your nearest dealer and follow the procedure in below to replace it.

## **Removing Procedure**


- 1. Open the ADF front cover.
- 2. Remove the ADF detachable pad module by pulling out the upper part of the pad clamp as shown in the figure below.




## 7.4 Replacing the ADF roller

After scanning approximately 200,000 pages through the ADF, the ADF roller may be worn out and you may experience problems with document feeding. In this case, it is highly recommended to replace the roller with a new one. Please follow these steps to replace and install the ADF roller.

- 1. Open the ADF front cover.
- 2. Move the ADF roller tab up as indicated.




3. Hold the roller and slightly move it forward to detach the roller.




## Assembling Procedure

To install the ADF roller, please follow these steps.

1. Insert one end of the ADF roller to its slots and then the other end.



2. Press down the tab. If properly installed, a snap-in sound could be heard.




# 8. Troubleshooting

# 8.1 Removing the abnormal lines on your scanned image

If your scanned image is shown with abnormal lines on it, it is probably caused by the dust or toner particle on the strip of document glass.

To remove the dust or toner particle,


- 1. Dip a soft clean cloth with isopropyl alcohol (95%).
- 2. Wipe the strip of document glass as shown below.
- 3. Close the document cover. The product is now ready for use.




#### 8.2 Clearing a Paper Jam

In the event of a paper jam, follow the procedures below to remove the paper:

- 1. Gently open the ADF front cover to the left.
- 2. Carefully pull the paper out of the ADF unit.



3. Close the ADF front cover. The product is now ready to use.



## 8.3 Questions and Answers

Question:	When the scanner is powered on, it makes noises and won't stand ready.	
Answer:	There are two possibilities:	
	1) You might fail to push the scanner shipping lock to its "unlocked" position. If this is the case, pull the scanner status switch to its "unlocked" position first.	
	<ol> <li>The scanner is not placed on an even, fla desktop surface. This may cause the scanner to malfunction.</li> </ol>	

Question:	While scanning, the scanner often makes noises, or it scans back and forth.
Answer:	Usually this means the memory of your computer is not enough or the speed of your CPU too slow. Please try to increase your memory to at least 32M or replace your CPU with Pentium or later.

Question:	Why is it that the scanned image always comes out to be too dark?
Answer:	<ol> <li>Please adjust the screen settings to SRGB.</li> <li>Please adjust the brightness settings on the screen from application software.</li> </ol>

Question:	The scanner works well except for the line art image. The lines in the image seem to be much thicker than the original one.
Answer:	Increase the Brightness or adjust the Threshold setting to improve line art image.

Question:	Paper becomes jammed during scanning.
Answer:	<ul><li>1.Open the ADF unit.</li><li>2.Pull out the jammed paper carefully.</li><li>3.Close the ADF unit.</li></ul>

Question:	More than one sheet of paper was fed into the scanner.
Answer:	<ol> <li>Open ADF unit.</li> <li>Remove the multi-fed sheets of paper.</li> <li>Close the ADF unit.</li> <li>Flatten the corners and edges; loosen the paper before reloading it in the guide.</li> <li>Check the feeding roller condition and do the cleaning if necessary.</li> </ol>

## 8.4 Technical Service

Before contact Avision, please prepare the following information:

- Scanner serial & revision number (located on the bottom of the scanner);
- Hardware configuration (e.g., your host CPU type, RAM size, free disk space, display card, interface card);
- The name and version of your scanning software application;
- The version of your scanner driver.

Please call us at:

## Headquarter

Avision Inc. No. 20, Creation Road I, Science-Based Industrial Park, Hsinchu 300, Taiwan, ROC TEL: +886 (3) 578-2388 FAX: +886 (3) 577-7017 E-MAIL: service@avision.com.tw Web Site: http://www.avision.com.tw

### US and Canada Area

Avision Labs, Inc. 6815 Mowry Ave., Newark CA 94560, USA TEL: +1 (510) 739-2369 FAX: +1 (510) 739-6060 E-MAIL: support@avision-labs.com Web Site: http://www.avision.com

#### **China Area**

Hongcai Technology Limited 7A, No.1010, Kaixuan Road, Shanghai 200052 P.R.C. TEL :+86-21-62816680 FAX :+86-21-62818856 E-MAIL :sales@avision.net.cn Web Site:http://www.avision.com.cn

### Europe Area

#### **Avision Europe GmbH**

Bischofstr. 101 D-47809 Krefeld Germany TEL: +49-2151-56981-40 FAX: +49-2151-56981-42 E-MAIL: info@avision-europe.com Web Site: http://www.avision.de

#### Espaço Brasil

#### Avision Brasil Ltda.

Avenida Jabaquara, 2958 - Cj. 75 - Mirandópolis – CEP: 04046-500 - São Paulo, Brasil TEL: +55-11-2925-5025 E-MAIL: suporte@avision.com.br Web Site: http://www.avision.com.br

# 9. Specifications

All specifications are subject to change without notice. For the most up-to-date and detailed specifications, please refer to our web site at http://www.avision.com

Model Number	DT-1106B(Simplex)
	DT-1110B(Duplex)
Scanner Type	Flatbed & ADF
Scanning Mode	Color/Grey/Black & White
Optical Resolution	600 dpi
Output Resolution	72~1200 DPI (adjustable in 1 dpi increments)
Technology	Contact Image Sensor
Light Source	LED
ADF Max. Scan Size	297 x 420 mm (11.7 x 16.5 in.)
Interface	High Speed USB 2.0
Power Requirements	24Vdc, 2.0A
Humidity	10~85%RH
Operation Temperature	10~35°C
Dimension (W*D*H)	585 x 499 x 195mm
	(23 x 19.6 x 7.7 in.)
Weight	DT-1106B: 11.5Kg (25.4 lb.)
	DT-1110B: 11.7Kg ( 25.8 lb.)